**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## T4TREAM L Shaped Desk Reclaimed Barnwood

# T4TREAM 59" Executive L Shaped Desk with Drawers

Model: L Shaped Desk Reclaimed Barnwood

Brand: T4TREAM

## 1. Introduction

Thank you for choosing the T4TREAM 59" Executive L Shaped Desk. This desk is designed to optimize corner space, offering a spacious and organized workspace for home offices, studies, or entertainment areas. It features a durable FSC-Certified engineered wood construction with a distressed finish, multiple storage options including drawers and a cabinet, and a convenient built-in charging station.




Image 1.1: The T4TREAM L Shaped Desk, showcasing its design and ample workspace.

## 2. Important Safety Information

- Always follow the assembly instructions carefully.
- This desk is heavy and may require two people for safe assembly and movement.
- Keep the desk away from direct heat sources, open flames, and excessive moisture to prevent damage to the wood and finish.
- Do not place excessively heavy objects on the edges of the desk to prevent tipping or structural damage.
- Ensure all screws and fasteners are securely tightened before use and periodically check them for looseness.
- Avoid standing or climbing on the desk.
- Keep small parts and hardware out of reach of children during assembly.

## 3. Parts List and Package Contents

Your T4TREAM L Shaped Desk is securely packaged in multiple sturdy boxes (typically 2 or more) to ensure safe delivery. Upon receiving your package(s), please verify all components against the detailed parts list provided in the separate assembly manual included with your desk. This list will include:

- Desk panels (desktop, side panels, back panels, drawer fronts, cabinet doors)
- Hardware (screws, dowels, cam locks, drawer slides, hinges, handles)
- Charging station unit and associated wiring
- Assembly tools (e.g., Allen wrench)
- Detailed assembly instructions manual

If any parts are missing or damaged, please contact T4TREAM customer support immediately for assistance.

## 4. Setup and Assembly

Assembly of the T4TREAM L Shaped Desk requires careful attention to the provided instructions. It is highly recommended that two adults perform the assembly due to the size and weight of the components.

### 4.1 Preparation

- Clear a spacious area for assembly, preferably near the desk's final location.
- Unpack all components and lay them out on a soft, clean surface (e.g., a blanket or cardboard) to prevent scratches.
- Identify all parts and hardware using the labels and the included parts list.
- Ensure you have all necessary tools as specified in the manual.

### 4.2 Assembly Steps

Refer to the step-by-step assembly manual provided in your package for detailed instructions, diagrams, and specific hardware usage for each step. The general process involves:

1. Assembling the base cabinets (pedestals) for each side of the L-shape.
2. Attaching the desktop sections to the assembled base cabinets.
3. Installing the drawer slides and assembling the drawers.
4. Installing the cabinet door hinges and attaching the cabinet doors.
5. Integrating the charging station into the designated desktop cutout.
6. Attaching handles and any decorative elements.

Follow the numerical sequence in the manual precisely. Do not overtighten screws unless specified, and ensure all connections are snug for stability.




Image 4.1: Product dimensions and packaging information, useful for planning assembly space.

## 5. Operating Instructions

### 5.1 Workspace Utilization

The L-shaped design provides a generous 59" x 59" desktop, allowing for distinct work zones. Utilize one section for your computer setup and another for writing, reading, or other tasks to enhance productivity and reduce clutter.

### 5.2 Charging Station

The desk features a built-in charging station with 2 USB ports and 2 standard outlets. To use, simply plug the charging station's power cord into a wall outlet. You can then connect your devices (laptops, phones, tablets, etc.) directly to the USB ports or outlets for convenient power access.




Image 5.1: Detail of the integrated charging station and curved edge design.

## 5.3 Drawers and Storage Cabinet

The desk is equipped with multiple drawers and a large storage cabinet to help keep your workspace organized and clutter-free.

- **Box Drawers:** Use these for smaller office supplies, stationery, and personal items.
- **File Drawer:** The dedicated file drawer is designed to accommodate letter-size files, notebooks, and other documents you need to keep readily accessible.
- **Storage Cabinet:** The spacious storage cabinet features adjustable shelves, allowing you to customize the height to fit various items, from books to larger office equipment. The buffer hinges ensure silent and pinch-free closing.



## LARGE STORAGE CABINET

Spacious storage with adjustable shelves for customizable height. And the buffer hinge ensure silent, pinch-free closing.

## LETTER SIZE FILE DRAWER

More drawers are designed to store your files, notebooks, calculators and other items you want to keep close at hand.



Image 5.2: Views of the large storage cabinet and the letter-size file drawer.

## 6. Maintenance and Care

Proper care will ensure the longevity and appearance of your T4TREAM L Shaped Desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the distressed finish.
- **Wood Care:** Protect the wood surface from direct sunlight, extreme temperature changes, and high humidity, which can cause warping or cracking. Use coasters under drinks and placemats under hot items.
- **Hardware:** Periodically check all screws, bolts, and fasteners to ensure they remain tight. Retighten as necessary to maintain stability.
- **Drawers and Hinges:** If drawers become stiff, a small amount of silicone lubricant can be applied to the slides. Ensure hinges operate smoothly; do not force cabinet doors.

## 7. Troubleshooting

This section addresses common issues you might encounter with your desk.

| Problem | Possible Cause | Solution |
|---|---|---|
| Desk is wobbly or unstable. | Loose fasteners; uneven floor. | Ensure all assembly screws are tightened. Use furniture glides or shims under legs to level the desk on uneven surfaces. |
| Drawers do not slide smoothly. | Misaligned drawer slides; debris in tracks; overloaded drawer. | Check that drawer slides are correctly installed and aligned. Clean tracks of any dust or debris. Do not exceed the drawer weight capacity (30-50 lbs). Apply silicone lubricant if needed. |
| Charging station is not working. | Not plugged in; power outlet issue; device cable issue. | Ensure the charging station's power cord is securely plugged into a functional wall outlet. Test the wall outlet with another device. Try a different USB cable or power adapter for your device. |
| Cabinet door does not close properly. | Misaligned hinges; obstruction. | Adjust the hinges as per the assembly manual. Check for any items obstructing the door's path. |

If you encounter an issue not listed here, or if the suggested solutions do not resolve the problem, please contact T4TREAM customer support for further assistance.

## 8. Specifications

| Feature | Detail |
|---|---|
| Brand | T4TREAM |
| Model | L Shaped Desk Reclaimed Barnwood |
| Product Dimensions (D x W x H) | 59"D x 59"W x 30"H |
| Color | Reclaimed Barnwood |
| Style | Victorian |
| Base Material | FSC-Certified Engineered Wood |
| Finish Type | Distressed Finish |
| Tabletop Thickness | 1.18 Inches |
| Maximum Weight Recommendation (Tabletop) | 150 Pounds |
| Drawer Weight Capacity | 30-50 Pounds |
| Number of Drawers | 4 (including 1 file drawer) |

| Feature | Detail |
|---|---|
| Storage Options | 4 drawers, Large Storage Cabinet |
| Special Features | Built-in Charging Station (2 USB ports + 2 outlets), Beveled edge table corner |
| Assembly Required | Yes |
| Includes All Assembly Tools | Yes |

## 9. Warranty and Support

T4TREAM is committed to providing high-quality products and customer satisfaction. While specific warranty details may vary, please refer to your purchase documentation or the product listing for information regarding the warranty period and coverage for your desk.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, our support team is ready to assist you. Please contact T4TREAM customer service through the retailer's platform or via the contact information provided in your product packaging.

© 2025 T4TREAM. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0F1TGSSWM**

More documents and user manuals: **https://manuals.plus/**