

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KraftGeek](#) /

› [KraftGeek Magnetic Phone Tripod \(Model 226M\) User Manual](#)

KraftGeek 226M

KraftGeek Magnetic Phone Tripod (Model 226M) User Manual

Your guide to setting up and using your KraftGeek Magnetic Phone Tripod.

1. INTRODUCTION

Thank you for choosing the KraftGeek Magnetic Phone Tripod. This versatile accessory is designed to enhance your mobile photography and videography experience, offering stability, flexibility, and ease of use. This manual provides essential information for proper setup, operation, and maintenance of your device.

2. WHAT'S IN THE BOX

- KraftGeek Magnetic Phone Tripod
- Detachable Bluetooth Remote Control
- Metal Rings (for non-MagSafe compatible devices)
- USB-C Charging Cable (for remote)

3. PRODUCT FEATURES

- **Auto-Open Design:** Effortless, one-tap deployment into tripod mode.
- **Strong Magnetic Mount:** Equipped with powerful N52 magnets for secure, clamp-free attachment, compatible with iPhone 12/13/14/15/16/17 series (Pro, Max, Mini) and Pixel 10 Pro. Includes metal rings for other smartphones.
- **Dual-Axis Adjustment:** Two hinge joints allow for smooth 180° tilt and effortless phone rotation, enabling low angles, overhead shots, and instant orientation changes.
- **Extended Height:** Extends from a compact 13 inches (33 cm) to an impressive 66 inches (168 cm).
- **Compact & Lightweight:** Folds down to just 13 inches and weighs only 15.85 oz (449g), making it highly portable. Constructed with a durable aluminum alloy telescopic pole and lightweight plastic tripod legs.
- **Stable Tripod Base:** Features 11-inch collapsible legs for a wider footprint and enhanced balance, with anti-slip rubber feet for stability on various surfaces.
- **Magnetic & Detachable Bluetooth Remote:** Control photos and videos from up to 33 feet (10 meters)

away. The remote docks securely to the stick.

4. SETUP GUIDE

4.1 Deploying the Tripod

1. Hold the tripod vertically with the base facing downwards.
2. Gently tap the base on a flat surface. The legs will automatically deploy and lock into position.



Figure 1: The tripod legs automatically deploy with a single tap on the base.

4.2 Attaching Your Smartphone

1. Ensure your smartphone is MagSafe compatible (iPhone 12 series or newer) or has a MagSafe

compatible case.

2. Align the back of your phone with the magnetic mount on the tripod head. The strong N52 magnets will securely snap your phone into place.
3. For non-MagSafe devices, attach one of the provided metal rings to the back of your phone or phone case, then attach your phone to the magnetic mount.



Figure 2: Securely attach your MagSafe-compatible smartphone to the magnetic head.

4.3 Pairing the Bluetooth Remote

1. Remove the Bluetooth remote control from its magnetic dock on the tripod handle.
2. Turn on the remote control (usually by pressing and holding a button until an indicator light flashes).
3. On your smartphone, go to Bluetooth settings and search for available devices.

4. Select the KraftGeek remote (or similar name) to pair. The indicator light on the remote will stop flashing once paired.



Figure 3: The detachable Bluetooth remote control for hands-free operation.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height

1. Gently pull the telescopic pole upwards to extend it to your desired height.
2. Push the pole downwards to retract it. Ensure the legs are fully deployed for maximum stability when using as a tripod.

Versatile Height

Adjust, Elevate,
Capture



Figure 4: The tripod can extend up to 66 inches for various shooting needs.

5.2 Adjusting Angles and Orientation

1. The magnetic head allows for 360° rotation of your phone. Simply turn your phone to switch between portrait and landscape modes.
2. Utilize the dual-axis hinge joints to tilt the phone mount up to 180° for various shooting angles, including overhead or low-angle shots.



Figure 5: The dual-axis design provides flexible angle adjustments.

5.3 Using as a Selfie Stick

1. Collapse the tripod legs by pushing them together until they form a compact handle.
2. Extend the telescopic pole to your desired length.
3. Use the Bluetooth remote to capture photos or start video recording.

Magnetic Phone Mount

Secure Setup Instantly



Figure 6: The tripod easily converts into a handheld selfie stick.

5.4 Folding for Storage

1. Retract the telescopic pole completely.
2. Gently push the tripod legs together until they lock into their compact, folded position.
3. Ensure the Bluetooth remote is securely docked in its magnetic slot.



Figure 7: The tripod folds down to a compact 13 inches for easy portability.

6. MAINTENANCE

- **Cleaning:** Wipe the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- **Remote Battery:** Recharge the Bluetooth remote using the provided USB-C cable when the battery is low.

7. TROUBLESHOOTING

- **Tripod legs not deploying:** Ensure the base is tapped firmly on a flat surface. Check for any

obstructions.

- **Phone not attaching securely:** Verify your phone or case is MagSafe compatible. If not, use the provided metal ring. Ensure the magnetic surface is clean and free of debris.
- **Bluetooth remote not pairing:** Make sure the remote is charged and turned on. Check your phone's Bluetooth settings and try re-pairing. Ensure the remote is within the 33 ft (10m) operating range.
- **Tripod instability:** Ensure the legs are fully extended and locked. Use on a flat, stable surface.

8. SPECIFICATIONS

Feature	Detail
Brand	KraftGeek
Model Number	226M
Color	Black
Material	Aluminum
Item Weight	14.8 Ounces (419.57 grams)
Weight Limit	1.5 Kilograms
Maximum Height	66 Inches (168 Centimeters)
Minimum Height	13 Inches (33 Centimeters)
Folded Size	13 Inches
Tripod Head Type	Magnetic
Compatible Devices	iPhone 12/13/14/15/16/17 series (Pro, Max, Mini), Pixel 10 Pro, other Smartphones (with metal ring)
Special Features	Foldable, Lightweight, Remote Control, Slip Resistant, Telescopic
UPC	850070027021

9. WARRANTY AND SUPPORT

The KraftGeek Magnetic Phone Tripod comes with a 1-year warranty. For warranty claims, technical support, or any inquiries, please contact KraftGeek customer service through the retailer where the product was purchased or visit the official KraftGeek website.