

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OUKITEL](#) /

› [OUKITEL Smartwatch BT11 User Manual](#)

## OUKITEL BT11

# OUKITEL Smartwatch BT11 User Manual

Your comprehensive guide to setting up, operating, and maintaining your OUKITEL Smartwatch BT11.

## INTRODUCTION

Thank you for choosing the OUKITEL Smartwatch BT11. This device combines the functionality of a smartwatch with integrated Bluetooth headphones, offering a versatile solution for communication, fitness tracking, and entertainment. This manual provides detailed instructions to help you get the most out of your new device.

**Innovatives 2-in-1-Design, kann sowohl als Smartwatch als auch als Bluetooth-Headset verwendet werden**



The OUKITEL Smartwatch BT11, a 2-in-1 device featuring a smartwatch and integrated Bluetooth headphones.

## PACKAGE CONTENTS

Please check the package for the following items:

- OUKITEL Smartwatch BT11 (with integrated Bluetooth headphones)
- Charging Cable
- User Manual

# Multifunktionale Smartwatch



Illustration of the OUKITEL Smartwatch BT11 and its charging cable, representing the typical package contents.

## SETUP

### 1. Initial Charging

Before first use, fully charge your OUKITEL Smartwatch BT11. Connect the magnetic charging cable to the charging points on the back of the watch and plug the USB end into a power adapter (not included) or a computer's USB port. The watch display will indicate charging status.

A full charge typically takes approximately 2 hours. The watch has a 150mAh battery, providing up to 5-9 days of usage depending on activity.

### 2. App Installation and Pairing

To unlock the full potential of your smartwatch, download the companion application on your smartphone. Search for the official OUKITEL smartwatch app in your device's app store (Google Play Store for Android or Apple App Store for iOS).

1. Install the application on your smartphone.
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the OUKITEL app and follow the on-screen instructions to create an account or log in.
4. In the app, navigate to the device pairing section and select your OUKITEL Smartwatch BT11 from the list of available devices.
5. Confirm the pairing request on both your smartphone and the smartwatch.

Once paired, the watch will synchronize data with your phone, and you can customize settings, view health data, and manage notifications through the app.

## OPERATING INSTRUCTIONS

---

### 1. Basic Watch Functions

- **Power On/Off:** Press and hold the side button to power the watch on or off.
- **Screen Activation:** Raise your wrist or press the side button to wake the screen.
- **Navigation:** Swipe left, right, up, or down on the 1.47-inch AMOLED touchscreen display to navigate through menus and features. Tap to select.
- **Watch Faces:** Customize your watch face through the companion app or by long-pressing the watch face on the device and swiping to select.

# Multifunktionale Smartwatch



Wettervorhersage



Musikwiedergabe



Zeitmessgerät



Remote-Fotoshooting



The 1.47-inch AMOLED HD display offers vibrant visuals and customizable watch faces.

## 2. Using the Integrated Bluetooth Headphones

The OUKITEL Smartwatch BT11 features a unique 2-in-1 design with integrated Bluetooth headphones.

- Removal:** Gently remove the headphones from their charging slots on the sides of the watch.
- Wearing:** Place the comfortable liquid silicone ear cups into your ears.
- Connection:** The headphones will automatically connect to your paired smartphone via Bluetooth.
- Functions:** Use the headphones to answer calls, listen to music, or activate your smartphone's voice assistant.
- Storage:** After use, return the headphones to their slots on the watch for charging and secure storage.

# IP68 Wasserdicht

Die Wasserdichtigkeitsstufe IP68 erfüllt Ihre täglichen Anforderungen



Hand Washing



Rain



Sweat



The 2-in-1 design allows for seamless use of the integrated Bluetooth headphones for calls and audio.

## 3. Fitness and Health Monitoring

- **Sports Modes:** The watch supports over 100 sports modes, including jogging, swimming, cycling, and yoga. Select your activity from the watch menu to track real-time data such as steps, distance, calories burned, and heart rate.
- **Heart Rate Monitor:** The integrated heart rate monitor continuously tracks your heart rate. View your current and historical heart rate data on the watch or in the companion app.
- **Sleep Monitor:** Wear the watch to bed to monitor your sleep patterns. The sleep monitor analyzes sleep stages and provides insights into your sleep quality, accessible via the app.
- **Pedometer:** Automatically tracks your daily steps, distance, and calories burned.

# 1,47 Zoll AMOLED HD Display

Sie können das Zifferblatt nach Belieben ändern.



The smartwatch supports over 100 sports modes, accurately tracking various activities.

## 4. Additional Smartwatch Features

- Notifications:** Receive call, message, and app notifications directly on your wrist when connected to your smartphone.
- Weather Forecast:** View current weather conditions and forecasts.
- Music Playback Control:** Control music playing on your smartphone (play, pause, skip tracks).
- Timer/Stopwatch:** Utilize built-in timing functions.
- Remote Photo Shooting:** Use the watch as a remote shutter for your smartphone camera.



BT11



The OUKITEL Smartwatch BT11 offers various multifunctional features including weather, music control, and remote camera.

## MAINTENANCE

### 1. Cleaning

Regularly clean your smartwatch and headphones to ensure optimal performance and hygiene. Use a soft, lint-free cloth to wipe the screen and watch body. For the headphones, gently clean the ear cups and charging contacts with a dry cotton swab.

Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the device's finish and internal components.

### 2. Water Resistance (IP68)

The OUKITEL Smartwatch BT11 is IP68 rated, meaning it is dust and water-resistant. It can withstand immersion in water up to 1.5 meters for up to 30 minutes. This makes it suitable for activities like hand washing, rain exposure, and swimming in shallow water.

*Important Considerations:*

- Do not expose the watch to hot water, steam, or high-pressure water jets.
- Avoid using the watch in saunas, hot tubs, or during diving.
- After exposure to water, especially saltwater, rinse the watch with fresh water and dry it thoroughly before charging or using the headphones.
- The water resistance is not permanent and may decrease over time with normal wear and tear.

# Unterstützt über 100 Sportmodi



The OUKITEL Smartwatch BT11 supports over 100 sports modes, including the GoMore algorithm for accurate tracking and recording of training data.



The IP68 waterproof rating ensures the smartwatch can withstand daily water exposure like hand washing, rain, and sweat.

### 3. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the device when the battery level is low. Store the watch in a cool, dry place when not in use for extended periods.

## TROUBLESHOOTING

### 1. Watch Not Turning On

- Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- Press and hold the side button for 10-15 seconds to attempt a forced restart.

### 2. Unable to Pair with Smartphone

- Make sure Bluetooth is enabled on your smartphone.
- Ensure the smartwatch is powered on and within range of your phone.
- Restart both your smartphone and the smartwatch.
- Clear the Bluetooth cache on your smartphone (if applicable) and try pairing again.
- Ensure the OUKITEL app is updated to the latest version.

### 3. Headphones Not Connecting or No Audio

- Ensure the headphones are properly seated in the watch for charging.
- Remove the headphones and re-insert them to reset their connection.
- Check your smartphone's Bluetooth settings to ensure the headphones are connected.
- Verify the audio output on your smartphone is set to the connected headphones.

### 4. Inaccurate Health Data

- Ensure the watch is worn snugly on your wrist, but not too tight.
- Clean the sensor on the back of the watch.
- For best results, wear the watch on your non-dominant wrist.

### 5. Screen Unresponsive

- Restart the watch by pressing and holding the side button.
- Ensure the screen is clean and dry.

## SPECIFICATIONS

<b>Model Name</b>	BT11
<b>Display</b>	1.47 Inches AMOLED HD Display
<b>Connectivity</b>	Bluetooth
<b>Water Resistance</b>	IP68
<b>Battery Capacity</b>	150mAh Lithium Polymer
<b>Battery Life</b>	Up to 5-9 days (depending on usage)
<b>Compatible Devices</b>	Smartphone

Item Weight	130 g
Device Interface	Touchscreen

## WARRANTY AND SUPPORT

OUKITEL provides the following services for your Smartwatch BT11:

- **Return Policy:** 30-day no-reason return policy.
- **Warranty:** Two-year warranty from the date of purchase.
- **Technical Support:** Long-term technical support.
- **Customer Service:** 24-hour online customer service.

For any inquiries or assistance, please contact OUKITEL official customer service channels.

© 2025 OUKITEL. All rights reserved.