

[Manuals.plus](#) /

› [Babymoov](#) /

› Babymoov Moov & Protect Anti-UV Cooling Beach Tent User Manual (Model A038219_US)

Babymoov A038219_US

Babymoov Moov & Protect Anti-UV Cooling Beach Tent User Manual

Model: A038219_US

INTRODUCTION

Thank you for choosing the Babymoov Moov & Protect Anti-UV Cooling Beach Tent. This innovative tent is designed to provide a safe, comfortable, and protected environment for your baby or toddler during outdoor activities. Featuring UPF 50+ sun protection, an integrated mosquito net, and cooling technology, it's an ideal solution for the beach, park, or backyard. Please read this manual carefully before use to ensure proper setup, operation, and maintenance.

SAFETY INSTRUCTIONS

- Always stake down the tent for stability, especially in windy conditions.
- Use the mosquito net to protect from insects.
- Keep children and the tent away from direct sunlight for extended periods to prevent overheating.
- Never leave children unattended in the tent. Adult supervision is always required.
- Ensure adequate ventilation by utilizing the adjustable awning and mesh panels.
- Do not use the tent near open flames or heat sources.

WHAT'S IN THE BOX

- Babymoov Moov & Protect Anti-UV Cooling Beach Tent
- 4 Stakes for securing
- Carry Bag



Easy to use

POP-UP system folds and un-folds the tent in seconds.

Figure 1: Included components: Tent, Carry Bag, and Stakes.

SETUP INSTRUCTIONS

The Babymoov Moov & Protect tent features a convenient pop-up system for quick and easy setup.

1. **Unpack the Tent:** Carefully remove the tent from its carry bag. The tent is designed to pop open automatically. Hold it away from your face and others when releasing it from the bag.
2. **Position the Tent:** Place the tent on a flat, clear surface.
3. **Secure with Stakes:** Locate the four loops at each corner of the tent's base. Insert a stake through each loop and push it firmly into the ground to secure the tent, especially on grass or sand.
4. **Install Mosquito Net:** If desired, attach the integrated mosquito net. Secure the net to the inside top of the tent using the clips provided.
5. **Adjust Awning:** The tent features an adjustable awning on the back. To use, release the button at the bottom of the awning. Pass the strap in the middle of the awning through the button at the top of the tent to raise it to the desired height.

POP AND GO SYSTEM

Pop it up in seconds and fold it down just as fast.



Accessories Included: On The Moov Carry Bag & 4 Stakes For Securing

Figure 2: Pop-up system and folding steps.

Your browser does not support the video tag.

Video 1: Detailed instructions on how to set up and fold the Babymoov Moov & Protect Tent.

OPERATING INSTRUCTIONS

The Moov & Protect tent offers several features for optimal comfort and protection:

- **UV Protection:** The tent is made with UPF 50+ silver-coated material, blocking over 99% of UVA and UVB rays.
- **Cooling Technology:** The moisture-wicking groundsheet and optimal ventilation keep the interior up to 2.5 times cooler than standard tents.
- **Insect Protection:** The fine mesh mosquito net can be zipped closed to keep insects and sand out.
- **Adjustable Awning:** Reposition the awning as needed to provide continuous shade throughout the day.
- **Spacious Design:** The tent is designed to comfortably accommodate one or more children and one adult, making it suitable for various family needs.



UPF 50+UV-resistant tent with optimal ventilation and a cooling floor.

Shade provided thanks to multiple adjustable awning positions.




Figure 3: Optimal air circulation for a cool interior.

Up to 45°F cooler
in the Moov & Protect tent *

75°F

inside

88°F

outside



*Test conducted in an external laboratory.

Figure 4: The tent's cooling effect, showing a significant temperature drop inside.



Figure 5: Integrated mosquito net provides protection from insects and sand.

MAINTENANCE

- **Cleaning:** Wipe down the tent fabric with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Ensure the tent is completely dry before folding and storing to prevent mold and mildew.
- **Storage:** Store the tent in its original carry bag in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

Difficulty Folding the Tent:

The pop-up design can sometimes be tricky to fold back into its compact shape. Refer to the 'How to set up and fold the Babymoov Moov & Protect Tent' video in the Setup section for a visual guide. The general method involves holding two opposite sides, twisting them, and then bringing them together to form a smaller circle. Practice may be required.

Tent Instability:

Ensure all four stakes are firmly inserted into the ground through the designated loops. In very windy

conditions, consider placing heavy objects (like sandbags or bags filled with sand) inside the tent or around its base for added stability.

Mosquito Net Not Closing Properly:

Check that the clips securing the top of the mosquito net are properly fastened. Ensure the zipper is free from fabric obstructions when closing.

SPECIFICATIONS

Feature	Detail
Model Number	A038219_US
Item Weight	2.2 Pounds
Item Dimensions (L x W x H)	59.1"L x 42.9"W x 35.83"H
Material Type	Polyester (Fabric), Metal (Frame/Pole)
UV Protection	UPF 50+ (Blocks >99% UVA/UVB)
Water Resistance Level	Water Repellent
Color	Green Lagoon
Recommended Uses	Backyard Playtime, Beach Trips, Camping, Picnics and Parks, Travel



Figure 6: Tent dimensions for planning space.

WARRANTY & SUPPORT

Babymoov is committed to providing high-quality products. The Babymoov Moov & Protect Anti-UV Cooling Beach Tent comes with a **Lifetime Warranty** on all Babymoov pieces, ensuring long-lasting use and peace of mind. For any questions, concerns, or warranty claims, please visit the official Babymoov website or contact their customer support directly.

Official Babymoov Store: [Babymoov Store on Amazon](#)