Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung Galaxy F16 5G

Samsung Galaxy F16 5G User Manual

Model: Galaxy F16 5G

Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Samsung Galaxy F16 5G smartphone. Please read this guide thoroughly to ensure optimal performance and longevity of your device.
The Samsung Galaxy F16 5G features a sAMOLED FHD+ display, a 50MP main camera, a 5000mAh battery, and is powered by the Mediatek Dimensity 6300 processor, running on Android 14.

What's in the Box

Verify that all items are present in your product packaging:

- Handset (Samsung Galaxy F16 5G)
- Data Cable (USB Type C to C)
- SIM Ejection Pin
- Quick Start Guide



Figure 1: Included items in the Samsung Galaxy F16 5G box. This includes the smartphone, a USB Type-C to Type-C data cable, a SIM ejection pin, and a quick start guide.

Setup

1. **Insert SIM Card:**

   Locate the SIM card tray on the side of your device. Use the provided SIM ejection pin to open the tray. Insert your Nano-SIM card(s) into the tray with the gold contacts facing down. The Galaxy F16 5G supports Dual SIM functionality. Ensure the tray is securely closed.



Figure 2: Side view of the Samsung Galaxy F16 5G, illustrating the location of the SIM card tray and power/volume buttons.

2. **Charge the Battery:**

   Connect the USB Type-C data cable to the phone's charging port and the other end to a compatible 25W fast charger (sold separately). Allow the device to charge fully before initial use. The device has a 5000 mAh battery.

3. **Power On:**

   Press and hold the Power button (located on the side) until the Samsung logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account setup, and data transfer.



Figure 3: Front view of the Samsung Galaxy F16 5G, showcasing its sAMOLED display and front camera.

Operating Your Device

Display and Navigation

The Galaxy F16 5G features a 6.6-inch Full HD+ sAMOLED display with a 90Hz refresh rate for smooth visuals. Navigate using touch gestures, including swiping, tapping, and pinching. The device supports Always On Display for quick access to information.

Camera Features

Your device is equipped with a versatile camera system:

- **Rear Cameras:** 50MP Main, 5MP Ultra-wide, 2MP Depth.
- **Front Camera:** 13MP for selfies and video calls.

Open the Camera app to select various modes like Photo, Video, Portrait, and more. Tap the shutter button to capture images or start/stop video recording.



Figure 4: Back view of the Samsung Galaxy F16 5G in Glam Green, highlighting the triple camera module and Samsung branding.

Battery Management

The 5000 mAh battery provides extended usage. To optimize battery life:

- Adjust screen brightness.
- Close unused apps running in the background.
- Enable power-saving modes from Settings.

The device supports 25W fast charging. Use a compatible charger for quicker charging times.

Connectivity

The Galaxy F16 5G supports 5G cellular networks for high-speed data. It also includes Wi-Fi, Bluetooth, and USB Type-C for various connections. Ensure your SIM card is 5G compatible for 5G network access.

Security Features

Unlock your device using Face Recognition for convenient and secure access. Set up your preferred security method in the device settings.

Samsung Wallet

Utilize Samsung Wallet for contactless payments and storing digital cards. Set up your payment methods within the Samsung Wallet application.

Voice Focus

Activate Voice Focus during calls to minimize background noise and enhance voice clarity in noisy environments. This feature can be toggled during an active call.

Maintenance

Software Updates

Keep your device's software up-to-date to benefit from the latest features, security patches, and performance improvements. Samsung provides 6 generations of OS upgrades and 6 years of security updates for this model. Check for updates in *Settings > Software update*.

General Care

- Clean the screen and body with a soft, lint-free cloth.
- Avoid exposing the device to extreme temperatures or direct sunlight for prolonged periods.
- Protect your device from physical damage by using a protective case and screen protector.

Troubleshooting

If you encounter issues with your device, try the following common solutions:

- **Device not responding:** Press and hold the Power button for about 10 seconds to force restart the device.
- **Battery draining quickly:** Review battery usage in Settings to identify power-hungry apps. Reduce screen brightness and disable unnecessary features like GPS or Bluetooth when not in use.
- **Network connectivity issues:** Ensure your SIM card is properly inserted. Try toggling Airplane Mode on and off. Restart your device.
- **App crashes:** Clear the cache and data for the problematic app in *Settings > Apps*, or uninstall and reinstall the app.
- **Slow performance:** Close background applications. Clear unnecessary files and cache. Consider a factory reset as a last resort (back up your data first).

For more detailed troubleshooting, refer to the official Samsung support website or contact customer service.

Specifications

Samsung Galaxy F16 5G Key Specifications

Feature	Detail
Brand	Samsung
Model	Galaxy F16 5G
Operating System	Android 14
Processor	Mediatek Dimensity 6300 (2.4 GHz)
RAM	6 GB
Internal Storage	128 GB
Display	6.6-inch FHD+ sAMOLED (1080 x 2400 Pixels), 90Hz Refresh Rate
Rear Camera	50 MP (Main) + 5 MP (Ultra-wide) + 2 MP (Depth)
Front Camera	13 MP
Battery Capacity	5000 mAh
Charging	25W Fast Charging (USB Type C)
SIM Support	Dual SIM (Nano)
Cellular Technology	5G
Security	Face Recognition
Dimensions	12 x 8 x 4 Centimeters
Weight	230 Grams
Box Contents	Handset, Data Cable (C to C), Sim Ejection Pin, Quick Start Guide

Warranty Information

The Samsung Galaxy F16 5G comes with a **1-year manufacturer warranty** for the device from the date of purchase. In-box accessories are covered by a **6-month manufacturer warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in the box or visit the official Samsung website.

Support

For further assistance, technical support, or service requests, please contact Samsung Customer Service or visit the official Samsung support website:

- **Samsung Official Website:** www.samsung.com/in/support/
- Refer to the Quick Start Guide for initial contact information.

Manufacturer Contact Information: Dixon Technologies (India) Ltd., Plot No. 6, Sector-90, Noida, Gautam Buddha Nagar, U.P. India-201305

© 2026 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1W7YDKW

More documents and user manuals: **https://manuals.plus/**