

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BESNOOW](#) /
- › [BESNOOW I53 Wireless Earbuds Instruction Manual](#)

BESNOOW I53

BESNOOW I53 Wireless Earbuds

Instruction Manual

Model: I53 | Brand: BESNOOW

1. INTRODUCTION

Thank you for choosing the BESNOOW I53 Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features for convenience and durability. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: BESNOOW I53 Wireless Earbuds in Rose Gold, showcasing their sleek design.

2. PACKAGE CONTENTS

Ensure all items are present in your package:

- 2 x In-Ear Bluetooth Earbuds
- 1 x Fast Charging Case
- 3 x Pairs of Earplugs (S, M, L)
- 1 x USB-C Charging Cable
- 1 x Instruction Manual

Secure and comfortable fit



Image: All components included in the BESNOOW I53 Wireless Earbuds package: earbuds, charging case, ear tips, USB-C cable, and manual.

3. PRODUCT OVERVIEW

The BESNOOW I53 earbuds feature a compact design with an intuitive LED display on the charging case for battery status. Each earbud is equipped with touch controls for easy management of audio and calls.

Key Features:

- **Bluetooth 5.4:** For fast and stable connections.
- **ENC Noise Cancelling Mic:** Ensures clear call quality.
- **HiFi Stereo Sound:** Powered by 14.2mm dynamic drivers for immersive audio.
- **IP7 Waterproof:** Protection against sweat and rain.
- **Long Battery Life:** Up to 8 hours per charge, 48 hours with charging case.
- **LED Display:** Shows battery levels of earbuds and case.
- **Touch Control:** For easy operation.



Image: BESNOOW I53 Wireless Earbuds in different colors, emphasizing the ENC noise reduction feature.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and to a power source. The LED display will show the charging progress.

Package Contents

- Bluetooth Earphones*2
- Charging Case*1
- Instruction Manual*1
- Earplugs (S/M/L)
- USB-C Charging Cable*1



Image: The charging case of the BESNOOW I53 earbuds, displaying the battery percentage for the case and individual earbuds.

4.2 Bluetooth Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available devices and select "I53" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

Wide Compatibility



Image: A smartphone screen displaying Bluetooth settings with the 'I53' earbuds successfully connected.

4.3 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct size ear tips (S/M/L) and ensure a secure fit.

1. Select the ear tip size that best fits your ear canal.
2. Gently insert the earbud into your ear, aligning it correctly.
3. Twist slightly until it feels secure and comfortable.




Image: A diagram illustrating the correct method for wearing in-ear earbuds, including selecting the right ear tip size and adjusting for comfort.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The earbuds feature high-precision touch sensors for various functions:

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Volume Up	1S Press	
Volume Down		1S Press
Next Song		2S Press
Previous Song	2S Press	
Answer Call	Single Tap	Single Tap
Decline Call	2S Press	2S Press
Voice Assistant	Triple Tap	Triple Tap
Reset Earbuds	5S Press	5S Press

Intelligent Touch Control

Make your day easier



Image: Visual guide to the intelligent touch controls on the BESNOOW I53 earbuds.

5.2 ENC Noise Cancellation

The Environmental Noise Cancellation (ENC) technology effectively filters out ambient noise during calls, ensuring your voice is clear to the other party, even in noisy environments.



Image: A visual representation of how ENC noise reduction works to minimize background noise for clearer audio.

5.3 Battery Life & Charging

Enjoy up to 8 hours of music playback on a single charge. The charging case provides multiple additional charges, extending total battery life up to 48 hours. The case charges via USB-C.

Image: The BESNOOW I53 charging case with earbuds, highlighting the 48-hour total battery life and LED display.

5.4 IP7 Waterproof Rating

The earbuds are IP7 rated, making them resistant to sweat and rain. This makes them suitable for workouts, sports, and outdoor activities.



Image: BESNOOW I53 earbuds and their charging case shown with water droplets, illustrating their IP7 waterproof capability.

5.5 Wide Compatibility

These earbuds are compatible with most Bluetooth-enabled devices, including iOS and Android smartphones, tablets, computers, and laptops.



Image: Various devices like smartphones, tablets, and laptops, demonstrating the wide compatibility of the BESNOOW I53 earbuds.

6. MAINTENANCE

To ensure the longevity and optimal performance of your earbuds:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Remove ear tips and clean them with mild soap and water, ensuring they are completely dry before reattaching.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or corrosive liquids.

7. TROUBLESHOOTING

If you encounter any issues, try the following solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Reset earbuds (5S press on touch control).
No sound	Check volume levels on both earbuds and connected device. Ensure earbuds are properly paired.
Poor call quality	Ensure earbuds are fully charged. Check for obstructions around the microphone. Move closer to your connected device.
Earbuds falling out	Try different sized ear tips for a more secure fit. Ensure proper insertion as shown in Section 4.3.
Charging case not charging	Ensure USB-C cable is properly connected to both the case and power source. Try a different cable or power adapter.

8. SPECIFICATIONS

Feature	Detail
Model Name	I53
Connectivity Technology	Wireless (Bluetooth 5.4)
Bluetooth Range	15 Meters
Noise Control	Environmental Noise Cancellation (ENC)
Audio Driver Size	14.2 Millimeters
Battery Life (Earbuds)	Up to 8 Hours
Total Battery Life (with Case)	Up to 48 Hours
Charging Time	1.5 Hours (for case)
Water Resistance Level	IP7 Waterproof
Control Method	Touch
Item Weight (Earbuds)	3.7g each (approx.)
Compatible Devices	iOS, Android, and all Bluetooth-enabled devices

9. WARRANTY AND SUPPORT

Your BESNOOW I53 Wireless Earbuds come with a standard manufacturer's warranty. For detailed warranty information, product support, or technical assistance, please refer to the contact information provided on the product packaging or visit the official BESNOOW website.

10. SAFETY INFORMATION

Please read and follow these safety guidelines to prevent damage to your device or injury to yourself:

- Do not disassemble, repair, or modify the earbuds.
- Keep the earbuds away from children and pets.
- Avoid using the earbuds at high volume for extended periods to prevent hearing damage.
- Do not use the earbuds in situations where you need to hear your surroundings (e.g., driving, cycling, walking in traffic).
- Dispose of the earbuds and battery according to local regulations.

11. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product overview of the BESNOOW I53 Wireless Earbuds, demonstrating key features and design.