

Generic Lisa Official Light Stick User Manual

1. PRODUCT OVERVIEW

The Generic Lisa Official Light Stick is a battery-powered LED light device designed for various uses, including concerts and events. This manual will guide you through its proper use and care.

LISA OFFICIAL LIGHT STICK



Figure 1: Lisa Official Light Stick - Front View

DETAIL



Figure 2: Lisa Official Light Stick - Front and Back Detail

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Lisa Official Light Stick
- 1 x Strap
- 1 x Out Box (packaging)

Note: Batteries are not included and must be purchased separately.



Figure 3: Light Stick Handle and Packaging Box

3. SETUP INSTRUCTIONS

Follow these steps to prepare your light stick for use:




Figure 4: Light Stick Component Diagram

3.1 Battery Installation

1. Locate the **Battery Cap** at the bottom of the light stick handle (refer to Figure 4).
2. Twist or slide the battery cap to open the battery compartment.
3. Insert the required batteries (e.g., AAA batteries, quantity not specified in product data, typically 3) according to the polarity indicators (+/-) inside the compartment.
4. Securely close the battery cap.

3.2 Attaching the Strap

1. Locate the **Strap Hole** on the light stick handle (refer to Figure 4).
2. Thread the provided strap through the strap hole.
3. Secure the strap by looping it back through itself or using the provided fastener.

4. OPERATING INSTRUCTIONS

Once batteries are installed, you can begin using your light stick:

4.1 Power On/Off

- To turn on the light stick, press and hold the **Power Button** (refer to Figure 4) for approximately 2-3 seconds until the light illuminates.
- To turn off the light stick, press and hold the Power Button again for approximately 2-3 seconds until the light turns off.

4.2 Changing Light Modes/Colors

- While the light stick is on, short press the **Power Button** to cycle through different light modes or colors.
- Continue pressing until you reach your desired light setting.

5. MAINTENANCE

Proper maintenance ensures the longevity of your light stick:

- **Cleaning:** Wipe the light stick with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the light stick in a cool, dry place away from direct sunlight and high humidity. If storing for extended periods, remove the batteries to prevent leakage.
- **Battery Care:** Replace batteries when the light dims or fails to turn on. Dispose of used batteries responsibly.

6. TROUBLESHOOTING

If you encounter issues with your light stick, try the following:

- **Light Stick Does Not Turn On:**
 - Ensure batteries are correctly inserted with the correct polarity.
 - Replace with fresh batteries.
 - Check if the battery cap is securely closed.
- **Light Dims or Flickers:**
 - Batteries may be low. Replace them with new ones.
- **Light Modes Do Not Change:**
 - Ensure the light stick is fully powered on.
 - Try pressing the power button firmly and briefly.

7. PRODUCT SPECIFICATIONS

Detailed specifications for the Lisa Official Light Stick:

Feature	Specification
Brand	Generic
Model Name	LISA
Model Number	LISA_LIGHTSTICK
Manufacturer	Ktown4u
Material	Plastic (ABS/PC)
Power Source	Battery Powered
Light Source Type	Light Emitting Diode (LED)
Item Dimensions (L x W x H)	7.77"L x 1.39"W x 10.18"H (197.3 x 35.2 x 258.5 mm)
Weight	Approx. 215g

PRODUCT SPECIFICATION

NAME	LISA OFFICIAL LIGHT STICK
MANUFACTURE	ISYNAPSE
A/S	Ktown4u CS Center
MATERIALS	ABS / PC
WEIGHT	ABOUT 215g
SIZE	197.3 × 35.2 × 258.5 mm

SIZE INFO



구매 시 유의사항

1. 직사광선이 닿거나 고온다습한 곳을 피하고 상온에서 보관해 주세요.
2. 제품을 떨어뜨리거나 강한 충격이 가해질 경우 LED에 영향을 줄 수 있으니 주의해 주세요.
3. 영유아의 손이 닿지 않는 곳에 보관하시고, 부품을 삼키거나 입에 넣지 않도록 주의해 주세요.
4. 반드시 정품 배터리를 사용하시고, 장시간 미사용 시 배터리를 분리하여 보관해 주세요.
5. 소비자의 부주의 및 인위적인 제품 변경/조작, 과실로 인한 고장·파손에 대해서는 일절 책임을 지지 않습니다.
6. 본 제품은 무선 연동 장치로 운용 중 전파 혼신이 발생할 가능성이 있습니다.
7. 우천 시 사용은 고장의 원인이 됩니다.

Figure 5: Product Specifications and Size Information

8. WARRANTY INFORMATION

This product is covered by a warranty provided by Ktown4u. For specific details regarding warranty terms and conditions, please refer to the documentation provided with your purchase or contact Ktown4u directly.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries not covered in this manual, please contact your retailer or the manufacturer, Ktown4u. Ensure you have your product model number (LISA_LIGHTSTICK) and purchase details available when contacting support.