



Manuals.plus /

› BESNOOW /

› BESNOOW I53 Wireless Earbuds User Manual

BESNOOW I53

BESNOOW I53 Wireless Earbuds User Manual

Model: I53 | Brand: BESNOOW

INTRODUCTION

Thank you for choosing the BESNOOW I53 Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your new earbuds. Please read it thoroughly to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX



Image: BESNOOW I53 Wireless Earbuds in their charging case.

- in-Ear Bluetooth Earbuds (x1 pair)
- Fast Charging Case (x1)
- Pairs of Earplugs (S, M, L) (x1 set)
- USB-C Charging Cable (x1)
- Instruction Manual (x1)

SETUP

1. Initial Charging

All-Day Companionship Long Battery Life Of 40 Hours

Enjoy exceptional sound all day with up to 8 hours of continuous listening time and a total battery life of up to 40 hours when using the charging case

8 hrs
Playtime

40 hrs
Charging Case

1.5 hrs
Quickly Charged



Image: The charging case displaying battery levels for the case and individual earbuds.

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C charging cable to the charging port on the case and a compatible power source. The dual LED digital display on the case will show the battery level of the case and each earbud. A full charge takes approximately 1.5 hours.

2. Bluetooth Pairing



Image: A smartphone screen indicating successful Bluetooth connection to the I53 earbuds.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "I53" from the list of devices to connect.
5. Once paired, the earbuds will automatically connect to your device when taken out of the case, thanks to magnetic Hall effect technology.

OPERATING INSTRUCTIONS

Touch Controls



Image: A visual guide to the touch controls on the earbuds for various functions.

The I53 earbuds feature high-precision touch sensors for convenient control:

- **Play/Pause:** Tap once on either earbud.
- **Next Song:** Tap and hold the right earbud for 2 seconds.
- **Previous Song:** Tap and hold the left earbud for 2 seconds.
- **Volume Up:** Tap the right earbud once.
- **Volume Down:** Tap the left earbud once.
- **Answer/End Call:** Tap once on either earbud.
- **Decline Call:** Tap and hold either earbud for 2 seconds.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either earbud.

KEY FEATURES

Fast and Stable Bluetooth 5.4 Connection

Equipped with the latest Bluetooth 5.4 technology, these earbuds offer a 30% faster transmission speed and a more stable signal connection, minimizing delays. The connection distance can reach up to 15 meters, providing reliable audio whether you are in the gym, exercising, or commuting.

Clear Call Experience with ENC Noise Cancelling



Image: Illustration of how environmental noise reduction microphones work to filter out background noise during calls.

Advanced ENC (Environmental Noise Cancellation) technology effectively filters out over 80% of external noise, ensuring clear voice transmission during calls. Four high-performance microphones accurately capture your voice, making conversations clear even in noisy environments.

Immersive HiFi Stereo Sound

Premium HI-FI Stereo Sound Quality

Featuring a built-in 13mm PET diaphragm moving coil unit, this device delivers powerful resolution, creating a captivating musical ambiance and providing an immersive Hi-Fi sound experience.



Image: The earbuds in their charging case, surrounded by musical notes, symbolizing high-fidelity stereo sound.

The earbuds feature high-quality 14.2mm dynamic drivers, delivering deep low frequencies, balanced mid-range, and clear highs. Lossless CD-level audio transmission enhances every note and musical detail, providing an immersive listening experience.

48-Hour Battery Life & Dual LED Digital Display

Enjoy up to 8 hours of music playback on a single charge. The charging case extends the total battery life to 48 hours. The dual LED display clearly shows the battery levels of both the earbuds and the charging case, ensuring you are always aware of the remaining power.

Ergonomic Design and IP7 Waterproof



Image: A person wearing the BESNOOW I53 earbuds, demonstrating their comfortable and secure ergonomic fit.

IP7 Waterproof & Dustproof

Protects against dust and perspiration and meets the needs of many life situations



Light Rain



Accident Splashes



Sweat



Image: The earbuds and charging case are shown with water droplets, emphasizing their IP7 waterproof and dustproof capabilities.

The earbuds feature a curved design that fits snugly in the ear, complemented by soft silicone ear tips (S/M/L sizes included) for secure and comfortable wear during activities like running or exercising. Each earbud weighs only 3.7g, ensuring lightweight and burden-free long-term use. With an IP7-rated nano-coating, they are effectively sweat-proof and rain-proof.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth to remove dust and debris. Avoid using harsh chemicals or abrasive materials.
- **Charging:** To maintain battery health, fully charge the earbuds and case at least once every two months, even if not in regular use. If used daily for extended periods, charging the case nightly is recommended.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from damage and keep them charged.
- **Water Exposure:** While IP7 rated for sweat and rain, avoid submerging the earbuds in water or exposing them to high-pressure water jets. Ensure they are dry before placing them back in the charging case.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not pairing	Earbuds not in pairing mode or device Bluetooth off.	Ensure earbuds are out of the case and device Bluetooth is on. Re-select "I53" in Bluetooth settings.
No sound from one earbud	Earbud low battery or not properly connected.	Place both earbuds back in the case, close it, then reopen to reset connection. Check battery levels.
Charging case not charging	Faulty cable or power source.	Try a different USB-C cable and power adapter. Ensure connections are secure.
Intermittent connection	Distance from device or interference.	Stay within 15m of your device. Avoid strong electromagnetic interference.

SPECIFICATIONS

Feature	Detail
Model Name	I53
Connectivity Technology	Wireless, Bluetooth
Bluetooth Version	5.4
Bluetooth Range	15 Meters
Noise Control	Sound Isolation (ENC)
Audio Driver Type	Dynamic Driver
Audio Driver Size	14.2 Millimeters
Battery Life (Earbuds)	8 Hours
Total Battery Life (with Case)	48 Hours
Charging Time	1.5 Hours
Water Resistance Level	IP7 Waterproof
Item Weight	3.52 ounces (0.1 Kilograms)
Product Dimensions	1.57 x 1.97 x 1.18 inches
Control Method	Touch
Compatible Devices	iOS, Android, and all Bluetooth-enabled devices (smartphones, TVs, computers, laptops)

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the contact details provided in your product packaging or visit the official BESNOOW website. Keep your purchase receipt for any warranty claims.

