



[Manuals.plus](#) /

› [BESNOOW](#) /

› BESNOOW Wireless Earbuds I53 Instruction Manual

## BESNOOW I53

# BESNOOW Wireless Earbuds I53 Instruction Manual

Model: I53

## INTRODUCTION

---

This manual provides detailed instructions for the use and maintenance of your BESNOOW I53 Wireless Earbuds. Please read thoroughly before use to ensure optimal performance and longevity of your device.



Image: BESNOOW I53 Wireless Earbuds in their Azure charging case, displaying a 100% charge on the LED screen.

## PACKAGE CONTENTS

- in-Ear Bluetooth Earbuds (x1 pair)
- Fast Charging Case (x1)
- Pairs of Earplugs (S, M, L) (x1 set)
- USB-C Charging Cable (x1)
- Instruction Manual (x1)



Image: The complete package contents of the BESNOOW I53 Earbuds, neatly arranged, showing the earbuds, charging case, USB-C charging cable, and additional ear tip sizes.

## KEY FEATURES

- **Bluetooth 5.4 Connectivity:** Ensures faster transmission, stable signal, and extended connection range up to 15m.
- **ENC Noise Cancelling:** Advanced Environmental Noise Cancellation with 4 microphones for clear calls by filtering over 80% of external noise.
- **HiFi Stereo Sound:** Equipped with 14.2mm dynamic drivers for deep bass, balanced mid-range, and clear highs.
- **Extended Battery Life:** Up to 8 hours of playback on a single charge, with a total of 48 hours using the charging case.
- **LED Digital Display:** Clearly shows battery levels for both earbuds and the charging case.
- **IP7 Waterproof Rating:** Nano-coating technology provides effective sweat and rain protection.
- **Ergonomic Design:** Curved design with soft silicone ear tips (S/M/L) for a secure and comfortable fit.
- **Intuitive Touch Control:** High-precision touch sensors for managing volume, tracks, calls, and voice assistant.
- **Wide Compatibility:** Works with most Bluetooth-enabled devices, including iOS and Android smartphones, TVs, computers, and laptops.

# Quick & Reliable

Newly upgraded to Bluetooth 5.3, providing lower latency, reduced power consumption, and improved wireless interference resistance.



More Stable Connection



Longer Transmission Range



Lower Power Consumption



Lower Latency



Image: Visual representation of Bluetooth 5.4 technology, highlighting its benefits such as improved speed, stability, and lower power consumption.

# Incorporating An Integrated ENC Noise Reduction Chip



Image: An illustration demonstrating the Environmental Noise Cancelling (ENC) technology, showing a reduction of up to 40dB in ambient noise for clearer audio.

## SETUP AND PAIRING

- 1. Initial Charge:** Before first use, ensure the charging case and earbuds are fully charged. Connect the USB-C cable to the charging port on the case and a power source. The LED display will show charging progress.
- 2. Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
- 3. Pairing with Device:**
  - On your device (smartphone, tablet, laptop), go to Bluetooth settings.
  - Search for available devices.
  - Select "I53" from the list to connect.
  - Once connected, you will hear an audio prompt, and the LED indicator on the earbuds will change.
- 4. Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the charging case, thanks to magnetic Hall effect technology.



Image: A hand holding a smartphone showing the Bluetooth settings, with the "I53" earbuds listed as connected, demonstrating the pairing process.

## OPERATING INSTRUCTIONS (TOUCH CONTROLS)

The BESNOOW I53 earbuds feature intuitive touch controls on each earbud. Refer to the diagram below for specific functions:



Image: A detailed diagram outlining the intelligent touch controls for the BESNOOW I53 earbuds, showing various tap durations and their corresponding functions for music playback, calls, and voice assistant activation.

- **Play/Pause:** Single tap on either earbud.
- **Next Song:** Double tap on the Right earbud.
- **Previous Song:** Double tap on the Left earbud.
- **Volume Up:** Triple tap on the Right earbud.
- **Volume Down:** Triple tap on the Left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant (Siri/Google Assistant):** Press and hold either earbud for 3 seconds.

## CHARGING

The earbuds provide up to 8 hours of music playback on a single charge. The portable charging case extends this to a total of 48 hours.

- **Charging the Earbuds:** Place the earbuds into the charging case. They will automatically begin charging.
- **Charging the Case:** Connect the included USB-C charging cable to the port on the case and a 5V/1A power adapter (not included). A full charge takes approximately 1.5 hours.
- **LED Display:** The digital LED display on the charging case indicates the battery percentage of the case and individual charging status of each earbud (L/R).

## All-Day Companionship Long Battery Life Of 40 Hours

Enjoy exceptional sound all day with up to 8 hours of continuous listening time and a total battery life of up to 40 hours when using the charging case

**8 Hrs**  
Playtime

**40 Hrs**  
Charging Case

**1.5 Hrs**  
Quickly Charged



Image: The BESNOOW I53 earbuds and charging case, illustrating the impressive 48-hour total battery life, 8 hours of single-charge playtime, and quick 1.5-hour charging time.



Image: The dual LED display on the charging case, clearly showing the battery status of both the charging case and the individual left and right earbuds.

## WEARING THE EARBUDS

---

For optimal sound quality and comfort, choose the correct size silicone ear tips (S, M, L) and ensure a proper fit.

1. **Select Ear Tips:** Experiment with the included S, M, and L ear tips to find the size that provides the best seal and comfort for your ears.
2. **Insert Earbuds:** Gently insert the earbud into your ear canal.
3. **Adjust for Fit:** Twist the earbud slightly until it feels secure and comfortable. The ergonomic design is intended to fit snugly for various activities.

# Wear Them All Day Without Worries



Image: A woman comfortably wearing the BESNOOW I53 earbuds, accompanied by an inset diagram illustrating the ergonomic design for a perfect and secure fit within the ear.

## Wide Compatibility



Image: A step-by-step guide demonstrating the correct method for inserting and adjusting the earbuds, emphasizing the selection of appropriate ear tip sizes for a secure and comfortable listening experience.

**WATERPROOFING (IP7 RATED)**

The BESNOOW I53 earbuds feature IP7-rated nano-coating technology, making them resistant to sweat and rain. This makes them suitable for workouts, sports, and outdoor activities.

- **Protection:** Protected against immersion in water up to 1 meter for up to 30 minutes.
- **Usage:** Ideal for running, cycling, fitness, and travel.
- **Caution:** Not recommended for swimming or showering for extended periods. Ensure earbuds are dry before placing them back in the charging case to prevent damage.



Image: A visual explanation of the IP7 Waterproof and Dustproof capabilities of the earbuds, demonstrating their resilience against various moisture exposures like light rain, accidental splashes, and sweat.

## MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the silicone ear tips with water and mild soap if necessary. Ensure they are completely dry before reattaching.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or direct

sunlight for prolonged periods.

## TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget "I53" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back in the case, close it, then open it again. Ensure both are charged. If issue persists, reset the earbuds (refer to touch control diagram for reset function).
Poor sound quality	Ensure earbuds are fully inserted and ear tips provide a good seal. Clean any debris from the earbud nozzles. Check device volume and audio source quality.
Charging issues	Check USB-C cable and power adapter. Ensure charging contacts on earbuds and case are clean. Verify LED display indicates charging.

## SPECIFICATIONS

Feature	Detail
Model Name	I53
Bluetooth Version	5.4
Bluetooth Range	15 Meters
Noise Control	Sound Isolation (ENC)
Audio Driver Type	Dynamic Driver
Audio Driver Size	14.2 Millimeters
Battery Life (Earbuds)	8 Hours
Battery Life (with Case)	48 Hours
Charging Time	1.5 Hours
Water Resistance Level	IP7 Waterproof
Control Method	Touch
Item Weight	3.7g (each earbud)
Included Components	Earbuds, Charging Case, S/M/L Earplugs, USB-C Cable, Manual

## OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the BESNOOW I53 Wireless Earbuds, demonstrating their features and design.

## WARRANTY AND SUPPORT

---

While specific warranty details are not provided in the product information, the product is eligible for Amazon's return policy, which allows returns for up to 2026 days from purchase. For any product-related inquiries or technical support, please refer to the contact information provided in the included instruction manual or reach out to the seller directly through the platform of purchase.