



Manuals.plus /

› Coowisty /

› Coowisty 10000mAh Portable Charger CW1 Instruction Manual

Coowisty CW1

Coowisty 10000mAh Portable Charger CW1 Instruction Manual

Model: CW1

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Coowisty 10000mAh Portable Charger (Model CW1). Please read it thoroughly before operation.

PRODUCT FEATURES

- **Slim and Portable Design:** Measuring 5.7 x 2.7 x 0.73 inches and weighing 9.17 ounces, this power bank is designed for easy portability.
- **Built-in 4 Cables:** Includes USB-C, USB-A, Micro USB, and Lightning cables, eliminating the need for external cables.
- **Charge 5 Devices Simultaneously:** Features 5 output ports and 2 input ports, supporting pass-through charging.
- **LED Digital Display:** Shows real-time battery percentage for accurate power monitoring.
- **Micro USB Lanyard:** The Micro USB cable doubles as a convenient lanyard for carrying.
- **Universal Compatibility:** Compatible with a wide range of devices including iPhones, Android phones, tablets, and earbuds.
- **5-Layer Safety Protection:** Equipped with a smart chip for protection against overcharge, overvoltage, overcurrent, short circuits, and overheating.

PACKAGE CONTENTS

- 1x Coowisty 10000mAh Portable Charger (Model CW1)
- 1x User Manual

COMPONENT IDENTIFICATION

Familiarize yourself with the various parts of your portable charger.

4 Cables & 2 Ports




Image: The top side of the power bank, highlighting the four integrated cables (USB-C, USB-A, Micro USB, Lightning) and the two external ports (USB-C Port, USB-A Port) for versatile connectivity.

- **Built-in Cables:** USB-C, USB-A, Micro USB, Lightning
- **External Ports:** USB-C (bidirectional), USB-A (output)
- **Power Button:** Located on the side.
- **LED Digital Display:** Shows battery percentage.
- **Lanyard:** Integrated with the Micro USB cable for carrying.

SETUP

Initial Charge

Before first use, fully charge your Coowisty portable charger.

1. Connect the built-in USB-A cable to a wall charger's USB-A port, or use a USB-C cable with the USB-C input port.
2. The LED display will show the charging progress.
3. The device is fully charged when the LED display shows "100".




Image: This illustration shows two ways to recharge the power bank. One method shows connecting the built-in USB-A cable to a wall adapter. The second method shows connecting an external USB-C cable to the power bank's USB-C input port. Both methods are indicated to take approximately 5 hours.

OPERATING INSTRUCTIONS

Charging Your Devices

The Coowisty portable charger allows you to charge up to 5 devices simultaneously.

1. Identify the appropriate built-in cable for your device (USB-C, USB-A, Micro USB, or Lightning).
2. Gently pull out the required cable from its slot.
3. Connect the cable to your device's charging port.
4. If needed, press the power button on the side to initiate charging.
5. For devices requiring a standard USB-A connection, use the external USB-A output port.
6. For devices requiring a standard USB-C connection, use the external bidirectional USB-C port.



5 Devices At Once

Image: The portable charger connected to and charging five devices at once: a smartphone via Lightning cable, a tablet via USB-C cable, earbuds via Micro USB cable, another smartphone via USB-A cable, and a smart speaker via the external USB-A port. This demonstrates its multi-device charging capability.

Pass-Through Charging

The power bank supports pass-through charging, allowing you to charge the power bank and your connected devices simultaneously.

1. Connect your devices to the power bank using the built-in cables or external ports.
2. Connect the power bank to a power source using its built-in USB-A cable or the USB-C input port.
3. Both the power bank and your connected devices will charge.

MAINTENANCE

- Keep the power bank dry and away from moisture.
- Avoid extreme temperatures.
- Do not disassemble or attempt to repair the device.
- Clean the exterior with a soft, dry cloth.
- Store in a cool, dry place when not in use.

TROUBLESHOOTING

Device Not Charging

- Ensure the power bank is sufficiently charged (check LED display).
- Verify that the cables are securely connected to both the power bank and your device.
- Press the power button to activate charging if the display is off.
- Try a different cable or port.

Power Bank Not Recharging

- Ensure the charging cable is properly connected to a functional power adapter and outlet.
- Try a different power adapter or outlet.
- Use the built-in USB-A cable or a compatible USB-C cable for recharging.

SPECIFICATIONS

Feature	Detail
Brand	Coowisty
Model Number	CW1
Battery Capacity	10000 Milliamp Hours
Product Dimensions	5.7 x 2.57 x 0.72 inches
Item Weight	9.9 ounces
Connector Type	Micro USB/USB A, USB Type C
Special Features	Built In Cable, Digital Display, Lightweight, Short Circuit Protection, Slim
Manufacturer	Shenzhen weipai Technology Co., Ltd.
Date First Available	February 27, 2025

WARRANTY AND SUPPORT

The product includes a user manual and 24/7 friendly customer support. For any questions or issues, please contact Coowisty customer service.

PRODUCT VIDEOS

Watch this official video for a visual guide on using your Coowisty portable charger.
Your browser does not support the video tag.

Video: Slim 10000mAh Portable Charger with Built-in Cables. This video demonstrates the compact design and integrated cables of the Coowisty power bank.