MOUNTUP MU0047-L-OD

MOUNTUP Outdoor TV Mount MU0047-L-OD Instruction Manual

Weatherproof Full Motion TV Wall Mount for 42-75 Inch TVs

1. PRODUCT OVERVIEW

This instruction manual provides detailed information for the MOUNTUP Outdoor TV Mount, model MU0047-L-OD. This weatherproof full-motion wall mount is designed for most 42-75 inch TVs, supporting weights up to 99 lbs. It is ideal for outdoor and semi-enclosed environments such as gazebos, patios, backyards, and balconies, offering robust construction and flexible viewing options.



Image: The MOUNTUP Outdoor TV Mount MU0047-L-OD, a full-motion wall mount designed for outdoor use.

2. KEY FEATURES

• Outdoor Durability: Specifically designed for outdoor use, featuring anti-rust materials, outdoor powder coating, galvanised layers, and stainless steel hardware to withstand temperature fluctuations, moisture, and sunlight.



Image: Diagram showing the multi-layer construction of the mount, including outdoor powder coating, galvanised layer, and steel, designed for weather resistance.

• Wide Compatibility: Fits most 42-75 inch TVs with VESA patterns ranging from 150x100mm to 600x400mm, supporting TVs up to 99 lbs.




Image: Illustration detailing compatible VESA patterns (horizontal x vertical) from 150x100mm to 600x400mm, and how to measure them on a TV.

• Full Motion Flexibility:

• Long Arm Extension: Extends up to 37.9 inches from the wall and retracts to just 3 inches, providing extensive reach for optimal viewing angles.




Image: Visual representation of the mount extending 37.9 inches and retracting to 3 inches from the wall.

• **Tilt Functionality:** Offers an impressive tilt range of +5° to -10° to reduce glare and optimize viewing comfort, especially in outdoor lighting conditions.



Image: Depiction of the mount's tilt range ($\pm 5^{\circ}$ to $\pm 10^{\circ}$) and the $\pm 3^{\circ}$ leveling adjustment feature.

• **Swiveling the TV:** Pivot the TV left or right along the arm to achieve a swivel angle of up to +/-90°. This allows for optimal viewing from various positions in your outdoor area.



Image: An outdoor patio scene showing a TV mounted with the ability to swivel ±90 degrees for flexible viewing.


- **Level Adjustment:** Features a ±3° leveling adjustment to ensure the TV is perfectly horizontal after installation.
- Diverse Wall Compatibility: Can be installed on concrete walls, brick walls, and single wood studs. NOTE: Do not install into drywall alone.

Diverse Wall Compatibility



Do Not Mount on Drywall Alone!





Concrete/Brick Wall

Single Wood Stud

Image: Visual guide showing the mount's compatibility with concrete/brick walls and single wood studs, with a warning against drywall-only installation.

• Corner Mounting: The single stud design and flexible arm folding make it suitable for corner installations.



Image: A close-up view of the mount installed on a single stud, demonstrating its suitability for corner placement.

3. SETUP AND INSTALLATION

The MOUNTUP Outdoor TV Mount is designed for straightforward installation. A detailed installation manual in PDF format is available for download. Please refer to the official installation manual for comprehensive step-by-step instructions, safety warnings, and a complete list of included hardware.

Key Installation Steps (Summary):

- 1. Mount Brackets: Attach the TV brackets to the back of your television. Ensure VESA compatibility.
- 2. **Install Wall Plate:** Secure the wall plate to your chosen wall type (concrete, brick, or single wood stud). Use the provided drilling template and level tool for accuracy. **Do not install into drywall alone.**
- 3. Hang TV onto Wall Plate: Carefully lift and hang the TV (with attached brackets) onto the installed wall plate.



Image: A visual guide illustrating the three main steps for installation: mounting brackets to the TV, installing the wall plate, and hanging the TV onto the wall plate.

For detailed instructions, please download the Installation Manual (PDF).

4. OPERATING THE MOUNT

Once installed, the MOUNTUP Outdoor TV Mount offers various adjustments to achieve your desired viewing experience:

- Extending and Retracting: Gently pull the TV away from the wall to extend the arm, or push it back towards the wall to retract. The mount extends up to 37.9 inches and retracts to 3 inches.
- **Tilting the Screen:** Adjust the tilt angle by loosening the tilt adjustment screws (if applicable, refer to manual) and manually tilting the screen up or down. The mount supports a tilt range of +5° to -10°. Re-tighten screws after adjustment.
- Swiveling the TV: Pivot the TV left or right along the arm to achieve a swivel angle of up to +/-90°. This allows for optimal viewing from various positions in your outdoor area.
- Leveling Adjustment: If your TV appears slightly unlevel after installation, use the built-in ±3° leveling mechanism to adjust it by +/-3°. Refer to the manual for specific screw adjustments.

Your browser does not support the video tag.

Video: An official MOUNTUP video demonstrating the full motion capabilities of the outdoor TV mount, including extension, retraction, tilt, and swivel functions.

5. MAINTENANCE

To ensure the longevity and optimal performance of your MOUNTUP Outdoor TV Mount, especially given its exposure to outdoor elements, follow these maintenance guidelines:

- **Regular Cleaning:** Periodically wipe down the mount with a soft, damp cloth to remove dust, dirt, and debris. Avoid abrasive cleaners or solvents that could damage the protective coatings.
- Inspect for Wear: Annually inspect all moving parts, bolts, and connections for any signs of wear, corrosion, or loosening.

 Tighten any loose bolts as necessary.
- Lubrication: While the mount is designed for smooth operation, if you notice any stiffness in the articulating arms or swivel points, a small amount of silicone-based lubricant can be applied to the joints.
- Weather Protection: Although weatherproof, consider covering your TV and mount during extreme weather conditions (e.g., heavy storms, prolonged freezing temperatures) to further extend their lifespan.

6. TROUBLESHOOTING

If you encounter any issues with your MOUNTUP Outdoor TV Mount, please review the following common concerns:

- TV Not Level: Use the built-in ±3° leveling adjustment feature. Refer to the installation manual for specific instructions on how to adjust the level screws.
- **Difficulty Moving Mount:** Ensure all installation bolts are securely tightened but not over-tightened, which can restrict movement. If movement is stiff, a small amount of silicone lubricant on the joints may help.
- Mount Appears Loose: Re-check all wall mounting bolts and TV attachment screws. Ensure the mount is installed on a compatible and sturdy wall structure (concrete, brick, or single wood stud) and not drywall alone.
- TV Ports Blocked: The mount is designed to avoid blocking ports. If ports are blocked, ensure the TV brackets are correctly positioned according to your TV's VESA pattern and the mount's design.

For further assistance, please contact MOUNTUP customer service.

7. Specifications

Attribute	Value
Brand	MOUNTUP
Model	MU0047-L-OD
Item Weight	14.61 pounds
Package Dimensions	17.52 x 12.8 x 2.8 inches
Color	Black
Mounting Type	Wall Mount
Movement Type	Articulating, Tilt, Swivel, Level, Extend, Full Motion
Material	Alloy Steel
Maximum Compatible TV Size	75 Inches
Minimum Compatible TV Size	42 Inches
Max VESA Pattern	600x400mm
Min VESA Pattern	150x100mm
Weight Capacity	Up to 99 lbs
Extension from Wall	3 to 37.9 inches
Maximum Tilt Angle	10 Degrees

8. WARRANTY AND SUPPORT

MOUNTUP is dedicated to providing quality products and excellent customer service. For any inquiries or assistance, please reach out to our support team.

- Customer Service: If you have questions regarding suitability for your TV, installation concerns, need additional hardware (screws, spacers, washers, etc.), or require any other help, MOUNTUP experts are available to provide comprehensive solutions.
- **Protection Plans:** Extended protection plans may be available for purchase to cover your product beyond the standard warranty. Please check with your retailer for details on 2-year or 3-year protection plans.

• **Returns:** This product typically comes with a 30-day return policy for refund or replacement. Please verify the exact return policy with your purchase point.

For direct support, please visit the official MOUNTUP store or contact their customer service as indicated on your product packaging or purchase receipt.

© 2025 MOUNTUP. All rights reserved.

This manual is for informational purposes only. MOUNTUP is not responsible for any damage or injury caused by incorrect installation or use of this product.