

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [truke](#) /
- › [truke Crystal Dyno True Wireless Earbuds User Manual](#)

truke Crystal Dyno F221

truke Crystal Dyno True Wireless Earbuds User Manual

Model: Crystal Dyno F221

1. INTRODUCTION

Thank you for choosing the truke Crystal Dyno True Wireless Earbuds. These earbuds are designed to provide an immersive audio experience with advanced features such as Spatial Audio, long battery life, and clear call quality. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: truke Crystal Dyno True Wireless Earbuds in Oak Brown with their charging case.

2. WHAT'S IN THE BOX

Upon unboxing your truke Crystal Dyno Earbuds, please ensure all the following items are present:

- truke Crystal Dyno True Wireless Earbuds
- Wireless Charging Case
- USB Charging Cable
- Eartips (various sizes)
- User Manual (this document)

360° Spatial Sound

CRYSTAL
Dyno




Image: The true Crystal Dyno Earbuds, charging case, and accessories included in the package.

3. SETUP AND FIRST USE

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB charging cable to the charging port on the case and a power source. The LED indicator on the case will show charging status. Once fully charged, the indicator will change or turn off.




Image: The truke Crystal Dyno Earbuds in their charging case, illustrating the 70 hours of playtime and rapid charge feature.

3.2 Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by flashing LED lights on the earbuds.
2. On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "truke Crystal Dyno" from the list.
4. Once connected, the LED indicators on the earbuds will stop flashing, and you will hear a confirmation tone.

The earbuds will automatically reconnect to the last paired device when taken out of the case, provided Bluetooth is enabled on your device.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The truke Crystal Dyno Earbuds feature intuitive touch controls on each earbud. Refer to the table below for common functions:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Right)	Volume Up
Triple Tap (Left)	Volume Down
Long Press (2s) (Left/Right)	Activate Voice Assistant, Reject Call
Quad Tap (Left/Right)	Toggle Gaming Mode (40ms Ultra Low Latency)

4.2 Spatial Audio

The earbuds feature 360° Spatial Audio for an immersive listening experience. This feature is automatically enabled

when supported content is played. Ensure your device's audio settings are configured to utilize spatial audio if available.



Image: A person enjoying music with the truke Crystal Dyno Earbuds, illustrating the 360° Spatial Sound feature.

5. MAINTENANCE

To ensure the longevity and optimal performance of your truke Crystal Dyno Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Remove eartips periodically and clean them with water and mild soap. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Water Resistance:** The earbuds are IPX5 water resistant, meaning they can withstand splashes and sweat. Do not submerge them in water or expose them to heavy rain.

6. TROUBLESHOOTING

If you encounter any issues with your truke Crystal Dyno Earbuds, please refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair.
Only one earbud working	Place both earbuds back in the case, close it, then open again. Ensure both earbuds are charged.
No sound or low volume	Check device volume and earbud volume. Ensure earbuds are properly seated in your ears. Clean any debris from the earbud grilles.

Problem	Solution
Charging issues	Ensure charging cable is securely connected. Try a different USB port or power adapter. Clean charging contacts on earbuds and case.
Poor call quality	Ensure microphones are not obstructed. Move to an area with less background noise.

If the issue persists, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	truke Crystal Dyno
Model Number	F221
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Audio Driver Type	13mm Titanium Dynamic Driver
Battery Life	Up to 70 Hours (with charging case)
Rapid Charge	10 minutes charge = 150 minutes playback
Low Latency	40ms Ultra Low Latency
Microphones	Quad-mic PureVoice ENC (Environmental Noise Cancellation)
Special Features	Spatial Audio, IPX5 Water Resistance
Control Method	Remote (Touch Controls)
Ear Placement	In Ear
Material	Plastic (with Leather Finish case)
Item Weight	41.1 g
Product Dimensions	5 x 5 x 2.6 cm

8. WARRANTY AND SUPPORT

Your truke Crystal Dyno Earbuds come with a 12-month warranty from the date of purchase, ensuring peace of mind and reliable service support. For any warranty claims, technical assistance, or product-related inquiries, please contact truke customer service.

For further information and support, you may also visit the official truke website or refer to your purchase platform's

support section.




Image: truke Crystal Dyno Earbuds highlighting 1 year service and 400+ service points.