Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Basike AN6

Basike AN6 Bluetooth Headphones User Manual

Model: AN6 (FON198-AN6)

1. Introduction

Thank you for choosing the Basike AN6 Bluetooth Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones to ensure a high-quality audio experience. Please read this manual thoroughly before use.



Image 1.1: Basike AN6 Bluetooth Headphones, black color, showcasing the over-ear design and control buttons on the right earcup.

2. Product Overview

2.1 Key Features

- **Active Noise Cancellation (ANC):** Immerse yourself in audio by reducing external distractions.
- **Bluetooth 5.4 Connectivity:** Ensures a strong, stable, and efficient wireless connection.

- **Dual Device Connection:** Connect to two Bluetooth devices simultaneously and switch seamlessly.
- **Long Battery Life:** Up to 50 hours of playback (without ANC) on a single charge.
- **Foldable and Retractable Design:** For enhanced portability and easy storage.
- **Comfortable Ear Cushions:** Made from high-quality synthetic leather for extended wear.

2.2 Package Contents

- Basike AN6 Bluetooth Headphones
- USB Type-C Charging Cable
- 3.5mm AUX Audio Cable
- User Manual



Image 2.1: Illustration of the Basike AN6 headphones, showing approximate dimensions (205mm height, 170mm width, 50mm earcup diameter) and the included accessories: USB Type-C cable and 3.5mm AUX cable.

3. Setup

3.1 Charging the Headphones

Before first use, fully charge your headphones.

1. Connect the USB Type-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status (e.g., red for charging, blue/off for fully charged).

Charging time is approximately 2 hours. A full charge provides up to 50 hours of playback without ANC or 30 hours with ANC enabled.

3.2 Bluetooth Pairing

To connect your headphones to a device:

1. Ensure the headphones are turned off.
2. Press and hold the Power button until the indicator light flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Ba-FON198" or "Basike AN6" from the list of devices.
5. Once connected, the indicator light will turn solid blue or flash blue slowly.

Your headphones support Bluetooth 5.4 for a stable connection up to 10 meters.



Image 3.1: A user wearing the Basike AN6 headphones, highlighting the Bluetooth 5.4 technology and 400mAh battery capacity for extended use.

3.3 Dual Device Connection

The Basike AN6 headphones can connect to two Bluetooth devices simultaneously.

1. Pair the headphones with the first device (e.g., smartphone) as described above.
2. Disable Bluetooth on the first device.
3. Put the headphones back into pairing mode and pair with the second device (e.g., laptop).
4. Re-enable Bluetooth on the first device. The headphones should automatically reconnect to both devices.

You can now switch audio sources between the two connected devices without re-pairing.



Image 3.2: Basike AN6 headphones connected to both a laptop and a smartphone, illustrating the convenience of dual device connectivity for multitasking.

4. Operating Instructions

4.1 Controls Overview



Image 4.1: Detailed view of the control buttons on the right earcup of the Basike AN6 headphones, indicating functions for volume, power, call management, music playback, USB-C charging, AUX connection, and ANC switch.

- **Power Button:** Press and hold to power on/off. Click to answer/end calls, play/pause music.
- **Volume + Button:** Press to increase volume. Click for the next track.
- **Volume - Button:** Press to decrease volume. Click for the previous track.
- **ANC Switch:** Toggle to activate/deactivate Active Noise Cancellation.
- **USB-C Port:** For charging the headphones.
- **AUX Port:** For wired audio connection using the 3.5mm cable.

4.2 Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the indicator light turns on.
- **Power Off:** Press and hold the Power button for approximately 3 seconds until the indicator light turns off.

4.3 Music Playback

- **Play/Pause:** Click the Power button.
- **Next Track:** Click the Volume + button.
- **Previous Track:** Click the Volume - button.
- **Volume Up:** Press and hold the Volume + button.
- **Volume Down:** Press and hold the Volume - button.

4.4 Call Management

- **Answer Call:** Click the Power button.
- **End Call:** Click the Power button during a call.
- **Reject Call:** Press and hold the Power button for 2 seconds during an incoming call.

4.5 Active Noise Cancellation (ANC)

To activate or deactivate ANC, use the dedicated ANC switch on the headphones. When ANC is active, the headphones will reduce ambient noise, providing a more immersive listening experience.



Image 4.2: A user wearing the Basike AN6 headphones, with visual representation of sound waves being cancelled, illustrating the active noise cancellation feature.

4.6 Wired Connection (AUX Mode)

To use the headphones with a wired connection:

1. Connect one end of the 3.5mm AUX cable to the AUX port on the headphones.
2. Connect the other end to the 3.5mm audio jack of your device.

In AUX mode, Bluetooth functionality is disabled, and the headphones operate passively. ANC may still be used if the headphones have battery power.

5. Maintenance

5.1 Cleaning

- Wipe the headphones with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Clean the ear cushions gently with a damp cloth if necessary, and allow them to air dry completely.

5.2 Storage

- Store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures.
- Utilize the foldable design for compact storage and transport.



Image 5.1: Basike AN6 headphones in a folded configuration, demonstrating their portability and ease of storage.

5.3 General Care

- Avoid dropping or subjecting the headphones to strong impacts.
- Do not expose to water or moisture.
- Do not attempt to disassemble or modify the headphones.



Image 5.2: Close-up of the Basike AN6 headphones, highlighting ergonomic features such as 90-degree earcup rotation, soft synthetic leather, and a retractable headband for comfortable and durable use.

6. Troubleshooting

6.1 No Power

- Ensure the headphones are fully charged. Connect to a power source using the USB Type-C cable.

6.2 Cannot Pair with Device

- Ensure the headphones are in pairing mode (indicator light flashing blue and red).
- Make sure Bluetooth is enabled on your device and it is within 10 meters of the headphones.
- Forget the device from your phone's Bluetooth list and try pairing again.
- Restart both the headphones and your device.

6.3 No Sound or Low Volume

- Check the volume levels on both the headphones and your connected device.
- Ensure the headphones are properly connected via Bluetooth or the 3.5mm AUX cable.
- If using AUX cable, ensure it is fully inserted into both ports.

6.4 ANC Not Working Effectively

- Ensure the ANC switch is in the 'ON' position.
- ANC is most effective against low-frequency, constant noise. It may not completely eliminate all sounds.

6.5 AUX Cable Not Functioning

- Ensure the AUX cable is securely connected to both the headphones and the audio source.
- Test with a different 3.5mm AUX cable if available to rule out a faulty cable.
- Verify the audio source is playing sound.

7. Specifications

Feature	Specification
Model Name	AN6 (FON198-AN6)
Speaker Size	40 mm
Impedance	32 ohms
Frequency Response	20 Hz - 20 kHz
Sensitivity	110dB ± 3dB
Battery Capacity	Lithium 3.7V / 400mAh
Noise Reduction	21 ± 2dB (Active Noise Cancellation)
Charging Time	Approx. 2 hours
Bluetooth Version	5.4
Wireless Range	Up to 10 meters
Playback Time (ANC Off)	Approx. 50 hours
Playback Time (ANC On)	Approx. 30 hours
Weight	210 Grams
Material	ABS/SBC
Connectivity	Bluetooth, 3.5mm AUX
Certification	ANATEL: 15081-21-14103

8. Warranty and Support

8.1 Limited Warranty

Basike is not responsible for damages caused by improper use of the product or by use with an incompatible electrical device. Please refer to your purchase documentation for specific warranty terms and conditions.

8.2 Customer Support

For further assistance or inquiries, please contact Basike customer support through the retailer where the product was purchased or visit the official Basike website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question