

[manuals.plus](#) /

› [Paladone](#) /

› [Paladone Bluey Icon Light Instruction Manual Model 14355](#)

Paladone 14355

Paladone Bluey Icon Light Instruction Manual

Model: 14355

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Paladone Bluey Icon Light, Model 14355. This battery-powered LED night light is designed to provide a soft, warm glow, featuring the beloved character Bluey.



Image: The Paladone Bluey Icon Light in its off state, showcasing the character design.

SETUP

1. Unpacking

Carefully remove the Bluey Icon Light from its packaging. Inspect the product for any damage. Retain the packaging for future reference or disposal. The packaging also features a colour-in design for creative activity.

PALADONE®

ICONS

BluEY

#001



ICON LIGHT

~Lampe · Licht · Lámpara · Luce~

Image: The Paladone Bluey Icon Light in its retail packaging, highlighting the colour-in feature.

2. Battery Installation

1. Locate the battery compartment cover on the base of the light.
2. Using a small screwdriver (not included), unscrew the cover and remove it.
3. Insert 2x AAA batteries (not included) into the compartment, ensuring the correct polarity (+/-) as indicated inside.
4. Replace the battery compartment cover and secure it with the screw.

3. Placement

Place the Bluey Icon Light on a stable, flat surface. Ensure it is away from direct sunlight, heat sources, and moisture.

OPERATING INSTRUCTIONS

Turning On/Off

The Bluey Icon Light features a push-button switch. To turn the light on, press the button located on the base of the unit. To turn it off, press the button again.



Image: The Paladone Bluey Icon Light illuminated, providing a soft, warm glow.

MAINTENANCE

Cleaning

To clean the light, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the unit in water.

Battery Replacement

When the light appears dim or stops working, it is time to replace the batteries. Follow the "Battery Installation" steps in the Setup section to replace the 2x AAA batteries. Always dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Batteries are incorrectly installed or depleted.	Check battery polarity. Replace with fresh AAA batteries.
Light is dim.	Batteries are low.	Replace with fresh AAA batteries.
Light flickers.	Loose battery connection or low batteries.	Ensure batteries are securely seated. Replace with fresh AAA batteries.

SPECIFICATIONS

Feature	Detail
Model Number	14355
Product Dimensions	3.54"D x 4.13"W x 5.31"H (approx. 9cm D x 10.5cm W x 13.5cm H)
Item Weight	0.08 Kilograms (approx. 2.82 ounces)
Light Source Type	LED
Light Color	Warm
Power Source	Battery Powered (2x AAA, not included)
Battery Life	Approximately 8 Hours
Switch Type	Push Button
Material	Plastic
Indoor/Outdoor Usage	Indoor
Manufacturer	Paladone




Image: Diagram showing the approximate dimensions of the Bluey Icon Light: 11cm (4.3") tall and 7.7cm (3") wide at the base.

WARRANTY AND SUPPORT

Warranty Information

Specific warranty details for this product may vary by region and retailer. Please refer to your purchase receipt or contact the retailer where the product was purchased for information regarding warranty coverage.

Customer Support

For further assistance, technical support, or inquiries regarding your Paladone Bluey Icon Light, please contact the manufacturer, Paladone, through their official website or customer service channels. Contact information can typically be found on the product packaging or the manufacturer's website.