

[Manuals.plus](#) /

› [Scentsationals](#) /

› Scentsationals White Owl Wax Melt Warmer User Manual

Scentsationals White Owl Wax Melt Warmer

Scentsationals White Owl Wax Melt Warmer User Manual

Model: White Owl Wax Melt Warmer

INTRODUCTION

This manual provides instructions for the safe and effective use of your Scentsationals White Owl Wax Melt Warmer. Please read all instructions carefully before operation and retain this manual for future reference.

PRODUCT COMPONENTS

- Ceramic Owl Warmer Base
- Removable Wax Dish
- Heating Bulb (pre-installed or included separately)
- Power Cord with On/Off Switch



Image: Front view of the Scentsationals White Owl Wax Melt Warmer, showing the ceramic owl base and the removable dish on top.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Placement:** Place the warmer on a flat, stable, heat-resistant surface, away from flammable materials, drafts, and out of reach of children and pets.
3. **Bulb Installation:** Ensure the heating bulb is securely screwed into the socket inside the warmer base. (If not pre-installed, gently screw it in).
4. **Dish Placement:** Place the removable wax dish securely on top of the ceramic owl warmer base.
5. **Power Connection:** Plug the power cord into a standard electrical outlet.



Image: The White Owl Wax Melt Warmer placed on a wooden surface in a room, demonstrating typical placement.

OPERATING INSTRUCTIONS

1. **Add Wax Melts:** Place one or two wax melt cubes into the removable dish on top of the warmer. Do not overfill.
2. **Activate:** Locate the on/off switch on the power cord and switch it to the "ON" position. The internal bulb will illuminate and begin to heat the dish.
3. **Fragrance Release:** The heating element will gently melt the wax, releasing fragrance into your space. This process is flameless, producing no smoke or soot.
4. **Deactivate:** To turn off the warmer, switch the on/off switch on the power cord to the "OFF" position.
5. **Cool Down:** Allow the warmer and wax to cool completely before handling or moving.

For optimal fragrance experience, use Scentsationals brand wax melts. The warmer is designed to quickly melt wax and release scent effectively.



Image: Scentsationals wax melt cubes in various colors, illustrating the type of product used with the warmer.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your wax warmer.

1. **Changing Wax:**
- **Method 1 (Cold Wax):** Allow the wax to cool and solidify completely. Gently apply pressure to one edge of the solidified wax to pop it out of the dish.

◦ **Method 2 (Warm Wax):** Turn on the warmer for a few minutes to slightly warm the wax, making it easier to slide out in a single piece. Alternatively, place cotton balls into the melted wax to absorb it, then wipe the dish clean.
2. **Cleaning the Dish:** After removing the wax, wipe the dish with a soft cloth or paper towel. For stubborn residue, a mild, non-abrasive cleaner can be used, ensuring the dish is completely dry before reuse.
3. **Cleaning the Warmer Base:** Wipe the exterior of the ceramic owl base with a soft, dry cloth. Do not immerse the base in water or use abrasive cleaners.
4. **Bulb Replacement:** If the light or heating function ceases, the bulb may need replacement. Ensure the warmer is unplugged and cool before replacing the bulb. Use a bulb of the same wattage and type as the original.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Warmer does not turn on or heat.	Not plugged in; power switch off; faulty bulb; power outage.	Ensure power cord is securely plugged in. Check that the on/off switch is in the "ON" position. Replace the heating bulb if necessary. Verify power to the outlet.
Wax is not melting or scent is weak.	Insufficient heating; old wax; too much wax; poor air circulation.	Ensure the warmer is on and the bulb is heating. Replace old wax with fresh cubes. Do not overfill the dish. Place the warmer in an area with good air circulation.
Warmer appears damaged or cracked.	Accidental impact; manufacturing defect.	Discontinue use immediately. Ceramic can be fragile; handle with care. Contact customer support if damage occurred upon arrival.

SPECIFICATIONS

- **Brand:** Scentsationals
- **Model:** White Owl Wax Melt Warmer
- **Material:** Ceramic
- **Power Source:** Electric
- **Package Dimensions:** 8.46 x 7.17 x 7.09 inches
- **Item Weight:** 1.94 pounds
- **Manufacturer:** Rimports, LLC
- **ASIN:** B0F1Z69CZL
- **UPC:** 843283167127

WARRANTY AND SUPPORT

Specific warranty information for the Scentsationals White Owl Wax Melt Warmer is not provided in this manual. For

warranty details, product support, or to inquire about replacement parts, please contact the manufacturer, Rimports, LLC, or the seller directly.

Manufacturer: Rimports, LLC

Seller: ScentSationals® (via Amazon)

Please refer to your purchase documentation or the Scentsationals official website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question