Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Honda CR-V

Honda CR-V 2016 Owner's Manual

Essential Information for Your Vehicle

Introduction

Welcome to the comprehensive guide for your 2016 Honda CR-V. This manual is designed to provide you with essential information regarding the safe operation, proper maintenance, and optimal care of your vehicle. Please read through this document thoroughly to familiarize yourself with all features and functions.



Image showing the front cover of the official 2016 Honda CR-V Owner's Manual, typically featuring the Honda logo and vehicle model.

Getting Started

This section covers initial setup procedures and basic controls to help you begin using your Honda CR-V.

Dashboard Overview

Familiarize yourself with the instrument panel. Key indicators include the speedometer, tachometer, fuel gauge, and various warning lights. Consult the full manual for detailed explanations of each indicator.

Seat and Steering Wheel Adjustment

Adjust your seat for optimal driving posture, ensuring comfort and clear visibility of the road and controls. The steering wheel can also be adjusted for tilt and telescope to further enhance your driving position.

Operating Your Vehicle

Learn the correct procedures for starting, driving, and safely operating your 2016 Honda CR-V.

Starting the Engine

To start the engine, ensure the transmission is in Park (P) or Neutral (N). Insert the key into the ignition and turn it to the START (III) position, or press the ENGINE START/STOP button while pressing the brake pedal.

Transmission Operation

Your CR-V is equipped with an automatic transmission. Understand the different drive modes:**P** (Park), **R** (Reverse), **N** (Neutral), **D** (Drive), and **S** (Sport mode, if equipped). Always apply the brake pedal when shifting from Park.

Infotainment System

Instructions for using the audio system, Bluetooth connectivity for hands-free calling and audio streaming, and the available navigation system (if equipped) are detailed in the full owner's manual. Refer to it for pairing devices and system settings.

Maintenance Schedule

Regular maintenance is crucial for the longevity, safety, and performance of your Honda CR-V. Adhere to the maintenance minder system displayed on your dashboard for service intervals.

Fluid Checks

- **Engine Oil:** Check level regularly and change as indicated by the maintenance minder.
- **Coolant:** Ensure coolant level is between MIN and MAX marks when the engine is cool.
- **Brake Fluid:** Verify fluid level is within the specified range.
- **Washer Fluid:** Keep the windshield washer reservoir filled for clear visibility.

Tire Care

Check tire pressure monthly, including the spare. Inspect tires for wear, damage, and proper tread depth. Rotate tires according to the recommended schedule to ensure even wear and extend tire life.

Battery Maintenance

Keep battery terminals clean and free of corrosion. Ensure the battery is securely mounted. If your vehicle is stored for extended periods, consider using a battery tender.

Troubleshooting Common Issues

This section provides guidance for addressing minor problems you might encounter with your vehicle.

Warning Lights

If a warning light illuminates on your dashboard, consult the full owner's manual immediately to understand its meaning and the recommended course of action. Some lights may indicate a serious issue requiring professional service.

Engine Not Starting

If the engine does not start, check the following: ensure the transmission is in Park (P) or Neutral (N), verify the fuel level, check battery connections for tightness and corrosion, and listen for any clicking sounds from the starter motor.

Flat Tire

In the event of a flat tire, safely pull over to a level area away from traffic. Refer to the full manual for detailed instructions on how to safely change a flat tire using the spare tire and tools provided in your vehicle.

Vehicle Specifications

Key technical details for the 2016 Honda CR-V are summarized below. For comprehensive specifications, refer to your official owner's manual.

Category	Detail
Engine Type	2.4L i-VTEC 4-Cylinder
Fuel Tank Capacity	Approximately 15.3 US gallons
Transmission	Continuously Variable Transmission (CVT)
Dimensions (L x W x H)	Refer to full manual for detailed measurements
Curb Weight	Varies by trim and drivetrain (FWD/AWD)

Note: For complete and precise specifications, including towing capacity, tire sizes, and fluid capacities, always refer to the detailed sections within your physical owner's manual.

Warranty Information

Your 2016 Honda CR-V is covered by a limited warranty provided by Honda. Details regarding coverage periods, terms, and conditions can be found in the separate Warranty Booklet supplied with your vehicle at the time of purchase. Typical coverage includes:

- New Vehicle Limited Warranty
- Powertrain Limited Warranty
- Corrosion Limited Warranty

For specific warranty claims, service, or questions, please contact an authorized Honda dealership. Keep your warranty booklet and service records in a safe place.

Customer Support

For further assistance, technical support, or service inquiries regarding your 2016 Honda CR-V, please contact your authorized Honda dealer. They are equipped with the knowledge and tools to provide expert service.
Useful Resources:

- Honda Owners Website: Access owner resources, service schedules, and more.
- Find a Honda Dealer: Locate your nearest authorized Honda service center.

Always use genuine Honda parts for replacements and repairs to ensure compatibility and maintain vehicle performance and warranty.

© 2016 Honda Motor Co., Ltd. All rights reserved. This document is a summary and does not replace the official owner's manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1ZCSYK7

More documents and user manuals: **https://manuals.plus/**