

[Manuals.plus](#) /

› [SEUNKWANG](#) /

› EWEADN V97 Tri-Mode Wireless Gaming Keyboard User Manual

SEUNKWANG EWEADN-V97

SEUNKWANG EWEADN V97 Tri-Mode Wireless Gaming Keyboard

USER MANUAL

Model: EWEADN-V97

Introduction

The SEUNKWANG EWEADN V97 is a versatile tri-mode wireless gaming keyboard designed for a seamless user experience across various platforms. It features Bluetooth 5.0, 2.4GHz wireless, and wired connectivity options, a 97-key compact layout, vibrant RGB backlighting with multiple effects, and a convenient 2-in-1 knob for volume and lighting control. Its ergonomic curved body and durable PBT keycaps ensure comfortable and reliable performance for work, gaming, and study.



Image: The EWEADN V97 keyboard showcasing its compact layout and RGB backlighting.

V97 Wireless Bluetooth & 2.4G keyboard



97 key layout
compact



2.4G & Bluetooth
more convenient



High elastic silicone
sensitive triggering



Ergonomics
easy typing



multimedia knob
fast & convenient



Low noise typing
not disturbing

Image: An overview of the V97 keyboard highlighting its 97-key compact layout, 2.4G & Bluetooth connectivity, high elastic silicone sensitive triggering, ergonomics, multimedia knob, and low noise typing.

Setup

Follow these steps to set up your EWEADN V97 keyboard for the first time.

1. Unboxing and Initial Charge

Carefully remove the keyboard and the included USB Type-C cable from the packaging. It is recommended to fully charge the keyboard before first use. Connect the Type-C cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, wall adapter). The power indicator light will show charging status.

2. Connectivity Modes

The V97 keyboard supports three connection modes: 2.4GHz wireless, Bluetooth 5.0, and wired (USB-C).

2.1. 2.4GHz Wireless Mode

1. Locate the 2.4G USB dongle, typically stored magnetically within the keyboard's chassis.
2. Plug the USB dongle into an available USB port on your computer or device.
3. On the keyboard, switch to 2.4G mode by pressing **Fn + 4**. The keyboard will automatically connect to the dongle.



Image: The EWEADN V97 keyboard showing its 97% layout, 7-degree tilt angle, and the magnetic 2.4G dongle socket.

2.2. Bluetooth 5.0 Mode

The keyboard can connect to up to three Bluetooth devices simultaneously.

1. On the keyboard, press **Fn + 1**, **Fn + 2**, or **Fn + 3** to select a Bluetooth channel. The corresponding indicator light will flash rapidly, indicating pairing mode.
2. On your device (PC, laptop, tablet, smartphone), enable Bluetooth and search for new devices.
3. Select "EWEADN V97" (or similar name) from the list of available devices to pair.
4. Once paired, the indicator light will stop flashing and remain solid.
5. To switch between connected Bluetooth devices, simply press **Fn + 1/2/3** for the desired channel.




Image: Diagram illustrating the two modes of connection (2.4GHz and Bluetooth) and compatibility with various devices like PC, Laptop, Tablet, Switch, Xbox, and PlayStation.

16.8 Million RGB Backlit



Image: Visual guide on switching between Bluetooth modes (Fn+1, Fn+2, Fn+3) and 2.4G mode (Fn+4).

2.3. Wired Mode

Connect the keyboard directly to your device using the provided USB Type-C cable. The keyboard will automatically switch to wired mode and begin charging.

3. System Compatibility Switching

The keyboard is compatible with both Windows and Mac operating systems.

- To enter Windows system mode: Press and hold **Fn + A**.
- To enter Mac system mode: Press and hold **Fn + S**.

Compatible with Multiple Systems

BT5.0 & 2.4GHz




Image: The EWEADN V97 keyboard connected to various devices, demonstrating compatibility with BT5.0 & 2.4GHz, and the ability to connect to three devices simultaneously.

Operating Instructions

1. RGB Backlighting Control

The V97 keyboard features vibrant RGB backlighting with 11 pre-set lighting effects and adjustable brightness and speed.

- **Switch Lighting Effect:** Press **Fn + INS** to cycle through the 11 pre-set lighting effects.
- **Adjust Brightness:** Press **Fn + PgUp** to increase brightness, and **Fn + PgDn** to decrease brightness (9 levels).
- **Adjust Speed:** Press **Fn + -_** to decrease lighting speed, and **Fn + =+** to increase lighting speed.
- **Turn Backlight On/Off:** Use the dedicated knob (see below) or specific key combination if available (not explicitly stated, but usually part of knob function).



Image: Visual guide for controlling RGB backlight effects, brightness, and speed using Fn key combinations.

2. Volume & Light 2-in-1 Knob

The multi-functional knob allows for quick adjustments of both volume and lighting settings.

- **Switch Modes:** Press the knob for approximately 5 seconds to switch between Volume Mode and RGB Mode.
- **In Volume Mode:**
 - Rotate the knob clockwise to increase volume.
 - Rotate the knob counter-clockwise to decrease volume.
 - Press the knob briefly to mute/unmute audio.
- **In RGB Mode:**
 - Rotate the knob clockwise to increase backlight brightness.
 - Rotate the knob counter-clockwise to decrease backlight brightness.
 - Press the knob briefly to cycle through lighting effects.

Volume & Lighting Adjust 2-in-1 Knob



Press change lighting effect



brightness -



brightness +

Press for 3S
enter volume mode



Press mute



volume -



volume +




Image: Close-up of the 2-in-1 knob, illustrating its functions for changing lighting effects, adjusting brightness, muting, and controlling volume.



Image: Detailed explanation of the knob's functions in Multimedia Mode (mute/unmute, volume +/-) and RGB Mode (switch effect, brightness +/-).

3. Power Display Light

The keyboard features a power display light to indicate battery status:

- **Low Battery:** Indicator light flashes.
- **Charging:** Indicator light is always on.
- **Fully Charged:** Indicator light turns off.

4. Ergonomic Design

The keyboard's unique curved body and 7-degree tilt angle, combined with the ergonomic stepped keycap layout, are designed to fit the natural arc of your fingers and wrists, reducing fatigue during extended use.

6-STEP KEYCAP LAYOUT ERGONOMIC BODY DESIGN

TYPING MORE COMFORTABLE
NO FATIGUE




Image: Illustration of the keyboard's 6-step keycap layout and ergonomic body design, emphasizing comfortable typing.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your keyboard.

1. Cleaning the Keyboard

The V97 keyboard features durable PBT keycaps, which are resistant to wear and fading.

- **General Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution to wipe down the keycaps and keyboard body.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keycaps.
- **Deep Cleaning (Keycaps):** For thorough cleaning, keycaps can be carefully removed using a keycap puller (not included) and washed with mild soap and water. Ensure keycaps are completely dry before reattaching.



Image: Close-up of the keyboard's high-quality PBT keycaps with MDA profile, highlighting their fine matte texture and wear-resistant characters.



Image: Detail of the PBT Retro Ball Caps, emphasizing their smooth surface and lack of light transmission.

2. Battery Care

The keyboard is equipped with a built-in 2000mAh rechargeable battery.

- Avoid completely draining the battery frequently.
- Charge the keyboard when the low battery indicator flashes.
- If storing the keyboard for an extended period, charge it to about 50% to prevent battery degradation.
- Use only the provided USB Type-C cable or a certified equivalent for charging.




Image: Information on the 2000mAh rechargeable battery, showing approximate battery life: Backlit OFF ~200 hours, Backlit ON ~30 hours.

Troubleshooting

If you encounter issues with your EWEADN V97 keyboard, refer to the following common problems and solutions.

1. Keyboard Not Connecting/Responding

- **Check Power:** Ensure the keyboard is turned on and has sufficient battery charge.
- **Mode Selection:** Verify that the correct connection mode (2.4GHz, Bluetooth, or Wired) is selected on the keyboard.

and matches your device.

- **2.4GHz:** Ensure the USB dongle is securely plugged into a working USB port. Try a different USB port.
- **Bluetooth:** Ensure Bluetooth is enabled on your device. Forget the device in your device's Bluetooth settings and attempt to re-pair. Try a different Bluetooth channel (Fn+1/2/3).
- **Wired:** Ensure the USB-C cable is securely connected to both the keyboard and your device. Try a different USB-C cable or port.
- **Restart:** Restart your computer/device and the keyboard.

2. Backlight Not Working or Incorrect

- **Brightness Level:** Increase brightness using **Fn + PgUp** or the knob in RGB mode.
- **Effect Cycle:** Cycle through lighting effects using **Fn + INS** or the knob in RGB mode.
- **Power Saving:** The backlight may turn off automatically after a period of inactivity to save battery. Press any key to reactivate.

3. Battery Not Holding Charge

- **Charging Cable:** Ensure you are using the original USB Type-C cable or a high-quality replacement.
- **Power Source:** Try charging from a different USB port or wall adapter.
- **Charging Time:** Allow sufficient time for a full charge (until the indicator light turns off).
- **Usage:** High backlight brightness and continuous wireless use will consume battery faster. Adjust settings for longer battery life.

4. Keyboard Color Discrepancy

Please note that while the product may be described as 'white', the actual color is a creamy off-white. This is an intentional design choice and not a defect.

Specifications

Feature	Detail
Model Number	EWEADN-V97
Connectivity	2.4G Wireless, Bluetooth 5.0, Wired (USB Type-C)
Layout	97-key (90% Compact)
Keycaps	Durable PBT, MDA Profile
Backlighting	RGB, 11 Pre-set Effects, 9 Brightness Levels
Battery Capacity	2000mAh Rechargeable
Estimated Battery Life	Backlight OFF: ~200 hours; Backlight ON: ~30 hours
Ergonomics	Curved Body, 7° Tilt Angle, Stepped Keycap Layout
Special Features	Volume & Light 2-in-1 Knob, Power Display Light
Compatibility	Windows, macOS, Gaming Consoles, Laptops, PCs, Tablets, Smartphones

Feature	Detail
Dimensions (L x W x H)	16 x 5.7 x 1.85 inches (407 x 146 x 47 mm)
Weight	2.2 lbs (1003g)
Color	Cream White
Included in Box	EWEADN V97 Keyboard, USB Type-C Cable



Image: Detailed dimensions of the 97% layout keyboard, including length, width, height, and weight.

Warranty and Support

The EWEADN V97 keyboard comes with 24-month brand support. If you encounter any issues or have questions regarding your product, please contact our customer support team. Our expert team is dedicated to assisting you. For assistance, please refer to the contact information provided with your purchase or visit the official SEUNKWANG website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F1ZXJWLX>

More documents and user manuals: <https://manuals.plus/>