

Eonini Y70

Eonini Y70 Open-Ear Bluetooth Earbuds User Manual

Model: Y70

INTRODUCTION

Thank you for choosing the Eonini Y70 Open-Ear Bluetooth Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. These earbuds are designed for comfort, environmental awareness, and high-quality audio, making them suitable for various activities including workouts, running, and daily commutes.

SAFETY INFORMATION

- Do not disassemble or modify the earbuds or charging case.
- Keep the device away from extreme temperatures, humidity, and corrosive substances.
- Avoid dropping or subjecting the device to strong impacts.
- Clean the earbuds with a soft, dry cloth. Do not use harsh chemicals.
- Dispose of batteries according to local regulations. Do not expose to fire.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a safe level.

PACKAGE CONTENTS

Please check the package for the following items:

- Eonini Y70 Open-Ear Bluetooth Earbuds (1 pair)
- Wireless Charging Case (1)

- USB Charging Cable (1)
- User Manual (1)

PRODUCT OVERVIEW

The Eonini Y70 earbuds feature an open-ear design for comfort and situational awareness, along with advanced audio technology for an immersive listening experience.



The advertisement features a black background with a subtle starry pattern. Two Eonini Y70 earbuds are prominently displayed, one in the foreground and one in the background, both showing the 'EONINI' logo. The text 'EONINI' is at the top left, followed by 'Next-Gen' in large blue letters and 'OWS Pro Earbuds' in white. Below this, the text 'Open-Ear Hi-Fi Sound' is written in blue. At the bottom, there are three grey boxes, each with a red 'X' over a different type of earbud: wired earbuds, standard earbuds in a case, and over-ear headphones. Each box has a title and a description of its drawback.

EONINI
Next-Gen
OWS Pro Earbuds

Open-Ear
Hi-Fi Sound

Tangled cords
Limited mobility

Uncomfortable
Falls out

Poor sound
Pressure discomfort

Image: Eonini Y70 Open-Ear Bluetooth Earbuds with their charging case, emphasizing the 'Next-Gen OWS Pro Earbuds' and 'Open-Ear Hi-Fi Sound' features.



Your All-Day Audio Companion

Listen Anywhere, Talk Clearly

Perfect for Music, Video Calls, Conferencing, Workouts, and Gaming

EONINI

Image: Four individuals using Eonini Y70 earbuds during different activities such as running, using a smartphone, working on a laptop, and at the gym, showcasing their versatility as an 'All-Day Audio Companion'.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and to a power source.
3. The LED indicator on the case will show the charging status. A full charge takes approximately 1.5 hours.

Long-lasting Battery Life

10 Hours per Charge, 40 Hours with Charging Case



Quick Charge

5 minutes = 1 hour playtime!

EONINI

Image: The Eonini Y70 charging case with earbuds inside, connected to a USB cable, displaying the 'Long-lasting Battery Life' of 40 hours total and a 'Quick Charge' feature providing 1 hour playtime from 5 minutes of charging.

2. Pairing with a Device

The earbuds use Bluetooth 5.3 for stable and fast connectivity.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "Y70" from the list.
4. Once connected, you will hear an audible confirmation.

Ultra-Fast Pairing

Quickly Connect to All Your Bluetooth Devices




10M/33FT



Low Latency



Stable Signal



EONINI

Image: The Eonini Y70 charging case and an iPhone displaying its Bluetooth settings, showing 'Y70' as a connected device, illustrating 'Ultra-Fast Pairing'.

3. Wearing the Earbuds

The ergonomic open-ear design with adjustable ear hooks ensures a secure and comfortable fit.

1. Identify the left (L) and right (R) earbuds.
2. Gently place the ear hook over your ear, positioning the earbud speaker near your ear canal without inserting it directly.
3. Adjust the ear hook for a snug and comfortable fit.

EONINI

Ergonomic Open Ear Design

Immerse in Music, Stay Aware of Your World



Ultra Light
For All-Day Comfort



Soft Silicone
Flexible Memory Metal



Ergonomic Ear Hook
For Secure Fit



IPX5 Waterproof
Resists Sweat & Rain

Image: A woman wearing an Eonini Y70 open-ear earbud, showcasing the 'Ergonomic Open Ear Design' and features like ultra-light, soft silicone, ergonomic ear hook, and IPX5 waterproof rating.

OPERATING

1. Power On/Off

- **Power On:** Open the charging case, or press and hold the touch control area on both earbuds for 2 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or press and hold the touch control area on both earbuds for 5 seconds.

2. Music Playback

- **Play/Pause:** Single tap the touch control area on either earbud.
- **Next Track:** Double tap the touch control area on the right earbud.

- **Previous Track:** Double tap the touch control area on the left earbud.
- **Volume Up:** Triple tap the touch control area on the right earbud.
- **Volume Down:** Triple tap the touch control area on the left earbud.

3. Call Management

- **Answer/End Call:** Single tap the touch control area on either earbud.
- **Reject Call:** Press and hold the touch control area on either earbud for 2 seconds.



Crystal Clear Calls
Just Like Face-to-Face Conversations

Easy Touch Controls
with Voice Assistant Activation

EONINI

High-Performance MEMS Microphone with ENC Noise-Cancelling for Clear Calls

The image features a man in profile wearing a black Eonini Y70 earbud. A large, detailed inset of the earbud is shown on the right, highlighting the touch control area with a blue fingerprint icon. Below the earbud, a blue waveform graphic represents sound waves. The background shows a man working at a desk with a computer monitor displaying technical drawings.

Image: A man wearing an Eonini Y70 earbud while on a call, illustrating 'Crystal Clear Calls' with high-performance MEMS microphone and ENC Noise-Cancelling, alongside 'Easy Touch Controls' and Voice Assistant Activation.

4. Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on either earbud for 2 seconds (when not on a call).

MAINTENANCE

1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive materials, solvents, or chemical cleaners.
- Ensure charging contacts are free of dust and debris.

2. Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.

3. Water Resistance (IPX5)

The Eonini Y70 earbuds are IPX5 water-resistant, meaning they can withstand sweat and light rain. They are not designed for swimming or submersion in water. Ensure the earbuds are dry before placing them back in the charging case to prevent damage.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are charged and in pairing mode. Turn off and on your device's Bluetooth. Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise place in case, close, then reopen).
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Poor sound quality:** Ensure there are no obstructions between your device and the earbuds. Move closer to your device. Check for interference from other wireless devices.
- **Earbuds not charging:** Ensure the charging cable is securely connected and the power source is working. Clean the charging contacts on both the earbuds and the case.
- **Microphone not working:** Ensure the earbuds are properly connected and selected as the audio input device on your phone during calls.

SPECIFICATIONS

Experience True **HIFI** Sound

Feel Every Beat, Just Like Being There



Image: An exploded view diagram of an Eonini Y70 earbud, detailing internal components such as the 14.2mm Studio Driver, Bluetooth 5.3 chip, and features like Immersive Bass+, 92% Anti-Leakage, and 0.2ms Ultra Sync, illustrating 'Experience True HiFi Sound'.

Feature	Detail
Model Number	Y70
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	33 Feet (10 meters)
Audio Driver Size	14.2 mm Dynamic Driver
Frequency Range	20 Hz - 20,000 Hz
Impedance	16 Ohms
Sensitivity	133 dB

Noise Control	Environmental Noise Cancellation (ENC)
Battery Life (Earbuds)	Up to 10 hours per charge
Total Playtime (with Case)	Up to 40 hours
Charging Time	Approx. 1.5 hours
Water Resistance	IPX5 (Sweat and splash resistant)
Control Type	Touch Control
Compatible Devices	Smartphones, Laptops, Tablets, Desktop Computers
Material	Silicone (internal)

WARRANTY INFORMATION

Eonini products are designed and manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Eonini website for detailed warranty terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

SUPPORT

If you encounter any issues or have questions regarding your Eonini Y70 Open-Ear Bluetooth Earbuds, please contact our customer support team.

- **Email:** [Insert Customer Support Email Here]
- **Website:** [Insert Official Website URL Here]
- **Phone:** [Insert Customer Support Phone Number Here]

Please have your model number (Y70) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question