Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE A75C560

XINFUTE Replacement AC Remote Control User Manual

Models: A75C560, A75C442, A75C399, A75C264

Introduction

This manual provides comprehensive instructions for the XINFUTE replacement remote control, designed for various National Panasonic Air Conditioner models including A75C560, A75C442, A75C399, and A75C264. This remote functions as a direct replacement for your original unit, ensuring seamless operation of your air conditioning system.



Figure 1: Front view of the XINFUTE replacement AC remote control. The display shows current settings, and buttons for Mode, Temp, Fan Speed, Swing, and Manual are visible.

Setup and Battery Installation

Before using your new remote control, you must install the batteries. This remote requires two AAA batteries (not included).

1. **Locate the Battery Compartment:** Turn the remote control over to find the battery compartment cover on the back.
2. **Open the Cover:** Gently slide the battery compartment cover downwards or in the direction indicated by an arrow, if present, to open it.

3. **Insert Batteries:** Insert two new AAA batteries into the compartment. Ensure the positive (+) and negative (-) ends of the batteries align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. **Close the Cover:** Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use. No programming is typically required as this is a direct replacement unit.



Figure 2: Back view of the remote control, highlighting the battery compartment.

Operating Instructions

This section details the functions of the buttons on your XINFUTE replacement remote control.



Figure 3: Overview of the remote control's buttons.

- **OFF/ON Button:** Press to turn the air conditioner unit on or off.
- **SLEEP Button:** Activates or deactivates the sleep mode, which typically adjusts temperature gradually for comfortable sleep and energy saving.
- **MODE Button:** Cycles through available operating modes such as Cool, Heat, Fan, Dry, and Auto. The active mode is usually displayed on the remote's screen.
- **TEMP Buttons (Up/Down Arrows):** Adjusts the desired temperature setting. Press the up arrow to increase temperature and the down arrow to decrease it.
- **FAN SPEED Button:** Changes the fan speed settings (e.g., Low, Medium, High, Auto).
- **SWING / AIR SWING Button:** Controls the vertical oscillation of the air conditioner's louvers to distribute air evenly. Pressing it typically cycles through different swing patterns or stops the swing.
- **MANUAL Button:** This button may offer additional functions depending on the specific AC unit, such as manual operation override or specific settings. Refer to your AC unit's manual for details on this button's function.

Ensure the remote control is pointed directly at the air conditioner's receiver when pressing buttons for optimal response.

Maintenance and Care

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's range decreases or the display becomes dim. Always replace both batteries at the same time with new ones of the same type (AAA). Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical shocks and drops, which can damage internal circuitry.

Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly inserted batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit.
Display is dim or blank	Low battery power.	Replace batteries.
AC unit not responding to specific commands	Remote button malfunction. AC unit specific issue.	Ensure button is pressed firmly. Test other functions. Consult your AC unit's manual for specific error codes or behaviors.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Product Type	Replacement Air Conditioner Remote Control
Brand	XINFUTE
Compatible Models	National Panasonic AC A75C560, A75C442, A75C399, A75C264
Material	ABS Material
Color	As Shown (Typically White)
Power Source	2 x AAA Batteries (not included)

Feature	Detail
Product Dimensions	4 x 3 x 1 inches
Item Weight	2.4 ounces
Model Name	A75C560
ASIN	B0F2158VT3

Warranty Information

XINFUTE provides a one-year warranty on all purchases of this product. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

For warranty claims or issues, please retain your proof of purchase and contact customer support within the warranty period.

Customer Support

If you have any questions, require assistance, or are not satisfied with your purchase, please contact us. All goods are inspected before shipment. If you are not satisfied with the purchase, you can contact us within 24 hours of the receipt of your purchase.

For further support, you may visit the official XINFUTE store on Amazon:XINFUTE Store.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2158VT3

More documents and user manuals: **https://manuals.plus/**