ANCTOR B0F21FM2YB

ANCTOR 6-Drawer Dresser Instruction Manual

Model: B0F21FM2YB | Brand: ANCTOR

1. Introduction

Welcome to your new ANCTOR 6-Drawer Dresser. This manual provides essential information for the assembly, safe use, and maintenance of your furniture. Please read it thoroughly before beginning assembly and retain it for future reference.

2. Important Safety Information

To prevent serious injury or death, always follow these safety precautions:

- This furniture must be securely anchored to the wall using the provided anti-tipping devices. Failure to do so can result in severe injury or death from furniture tip-over.
- Never allow children to climb on drawers, doors, or shelves.
- Do not place heavy objects in top drawers.
- Always open only one drawer at a time.
- Keep small parts away from children during assembly.



This image illustrates the proper installation of the anti-tipping device, securing the dresser to the wall to prevent accidental tip-over. The left panel shows correct installation, while the right panel shows the dresser tipping without the device.

3. Package Contents


Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- All wooden panels (top, sides, back, drawer fronts, drawer sides, drawer bottoms)
- Hardware pack (screws, dowels, cam locks, drawer slides, handles, anti-tipping kit)
- 3 Hooks
- Assembly Instructions Manual

4. Assembly Instructions (Setup)

Assembly typically requires two adults. Please follow the steps carefully.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts using the provided diagrams (refer to the separate parts list and diagrams).
3. Attach drawer slides to side panels and drawer boxes according to the instructions.
4. Assemble the main frame of the dresser.
5. Assemble each drawer box.
6. Insert assembled drawers into the dresser frame.
7. Attach the 3 hooks to the designated side panel.
8. Secure the anti-tipping device to the dresser and the wall as shown in the safety section.



This image displays the fully assembled ANCTOR 6-Drawer Dresser, showcasing its six drawers and overall design.




This image provides a side perspective of the dresser, emphasizing the three functional hooks located on the right side panel.

5. Operating Instructions

Your ANCTOR dresser is designed for efficient storage and display.

- **Drawers:** The six smooth-gliding drawers are designed for easy access. Pull gently to open and push firmly to close. Avoid forcing drawers.
- **Elevated Top:** The elevated tabletop provides a secure surface for decorative items, lamps, or a television up to 65 inches. The raised edge helps prevent items from falling.
- **Side Hooks:** The three integrated hooks are ideal for hanging lightweight items such as keys, headphones, or small bags.



Hidden Handle Drawers

Store all your essentials,
drawer slides pull out smoothly and quietly

Grooved Panel Design

Enhances texture and sense of space,
highlighting simple elegance





Sturdy Durable base

Provide strong support for
the entire dresser

This image shows the dresser with multiple drawers partially open, demonstrating its storage capacity for various items like clothing and accessories.



This image illustrates the dresser being used as a TV stand, with a television and other decor placed on its elevated top, highlighting its multi-functional design.



This image provides a detailed view of the three hooks on the side of the dresser, designed for hanging small items.

6. Maintenance and Care

To ensure the longevity and appearance of your ANCTOR dresser, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of the wood.
- **Hardware:** Periodically check and tighten all hardware to ensure stability.


7. Troubleshooting

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **Drawers not closing smoothly:**
  - Check if drawers are overloaded.
  - Ensure drawer slides are properly aligned and free of obstructions.
  - Verify all screws on drawer slides are tightened.
- **Dresser feels wobbly:**
  - Confirm all assembly hardware is securely tightened.
  - Ensure the dresser is placed on a level surface.
  - Verify the anti-tipping device is correctly installed and secured to the wall.
- **Missing or damaged parts:**
  - Do not attempt to assemble with missing or damaged parts. Contact ANCTOR customer support for replacements.

8. Product Specifications

Feature	Detail
Brand	ANCTOR
Model	B0F21FM2YB
Dimensions (W x D x H)	150.01 cm x 40.01 cm x 91.49 cm (59" W x 15.75" D x 36" H)
Material	Engineered Wood
Number of Drawers	6
Color	White
Special Features	3 Hooks, Elevated Top, Curved Profile Design, Anti-tipping devices
Assembly Required	Yes
Max TV Size	Up to 65 inches



This diagram provides precise measurements of the dresser, including its overall width (59 inches), depth (15.7 inches), and height (36.2 inches), along with individual drawer dimensions.

9. Warranty and Customer Support

ANCTOR stands behind the quality of its products. For warranty information, replacement parts, or technical assistance, please contact ANCTOR customer support.

Please have your model number (B0F21FM2YB) and purchase date available when contacting support.

- **Website:** ANCTOR Official Website (Placeholder)
- **Email:** support@anctor.com (Placeholder)
- **Phone:** +1-XXX-XXX-XXXX (Placeholder)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question