

WLIVE PTS501HXDE

WLIVE Mobile TV Stand (Model PTS501HXDE)

Instruction Manual

Brand: WLIVE | Model: PTS501HXDE

INTRODUCTION

Thank you for choosing the WLIVE Mobile TV Stand. This manual provides detailed instructions for assembly, safe operation, and maintenance of your new TV console. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product.

SAFETY INFORMATION

WARNING:

- Do not place more than 50 kg (110 lbs) on the top surface of the TV stand. Exceeding this weight limit may cause instability and potential injury.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not allow children to climb on or play with the TV stand.
- Place the TV stand on a flat, stable, and level surface to prevent tipping.
- Keep small parts out of reach of children during assembly.




Image: Product dimensions and weight limits. The top surface supports up to 110 lbs (50 kg), and each internal shelf supports up to 22 lbs (10 kg).

PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Top Panel (1)
- Bottom Panel (1)
- Side Panels (2)
- Adjustable Shelves (3)
- Metal Frame Components (4)
- X-shaped Support Brackets (2)
- Adjustable Feet (4)
- Hardware Pack (screws, dowels, Allen wrench)


- Instruction Manual (this document)

ASSEMBLY INSTRUCTIONS

Assembly is required. All components are clearly labeled with numbers, and necessary tools are included. Follow the steps below for a smooth assembly process.

1. **Unpack and Identify Parts:** Carefully unpack all contents and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided labels and the parts list.
2. **Assemble the Metal Frame:** Attach the metal frame components to the side panels using the provided screws. Ensure all connections are firm.
3. **Install X-shaped Support Brackets:** Secure the X-shaped support brackets to the rear of the side sections. These brackets enhance stability.
4. **Attach Top and Bottom Panels:** Connect the top and bottom panels to the assembled frame. Ensure proper alignment before tightening screws.
5. **Insert Adjustable Shelves:** Place the adjustable shelves into the central compartments. The shelves can be positioned at different heights to accommodate various items.
6. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the stand. Adjust them as needed to ensure the stand is level on uneven floors or carpets.
7. **Final Check:** Verify that all screws are tightened and the stand is stable.


HERVORRAGENDE KONSTRUKTION



Leicht zu reinigende Holzböden



X-förmiges Design an der Rückseite für bessere Stabilität



Extrem hohe Kapazität für größere Gegenstände

Image: Construction details highlighting the X-shaped design for enhanced stability and adjustable feet for leveling.

OPERATING INSTRUCTIONS

- **Placement:** Position the TV stand in your desired location, ensuring it is on a stable and level surface.
- **TV Placement:** The top surface is designed to hold TVs up to 65 inches and a maximum weight of 50 kg (110 lbs). Carefully place your television on the center of the top panel.
- **Storage:** Utilize the open shelves for storing media devices, gaming consoles, books, or decorative items. The side compartments are taller, suitable for audio equipment or speakers.
- **Cable Management:** Use the pre-drilled holes at the back of the central compartment to route cables, keeping them organized and out of sight.



Image: Features such as cable management, adjustable shelves, and adjustable feet for optimal use.

MAINTENANCE

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Spills:** The particle board panels are waterproof. In case of spills, wipe them immediately to prevent water damage.
- **Scratch Resistance:** The material is designed to be scratch-resistant, but avoid sharp objects that could cause deep marks.
- **Regular Checks:** Periodically inspect all connections and tighten any loose screws to maintain stability.



Image: Close-up of the high-quality particle board, illustrating its waterproof and scratch-resistant characteristics.

TROUBLESHOOTING

- **Stand is Wobbly:**
 - Ensure all screws are fully tightened.
 - Adjust the leveling feet at the bottom of the stand to compensate for uneven floor surfaces.
- **Parts Missing or Damaged:**
 - Review the "Package Contents" section. If parts are missing or damaged upon arrival, contact WLIVE customer support for assistance.
- **Difficulty Assembling:**
 - Double-check the assembly instructions and diagrams. Ensure components are oriented correctly.
 - Do not overtighten screws until all parts are loosely fitted, then tighten them fully.

PRODUCT SPECIFICATIONS

Brand	WLIVE
Model Number	PTS501HXDE
Color	Grey
Style	Industrial
Material	Particle Board, Metal Frame
Product Dimensions (L x W x H)	140 x 40 x 51 cm (55.1 x 15.7 x 20.1 inches)
Product Weight	18 kg (39.7 lbs)
Top Surface Weight Capacity	50 kg (110 lbs)
Shelf Weight Capacity	10 kg (22 lbs) per shelf
Max TV Size Supported	Up to 65 inches
Assembly Required	Yes

WARRANTY INFORMATION

WLIVE products are designed for quality and durability. Specific warranty details may vary. Please retain your proof of purchase for any warranty claims. For detailed warranty terms and conditions, please refer to the documentation included with your purchase or visit the official WLIVE website.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact WLIVE customer support.

- **Online Support:** Visit the official WLIVE store on Amazon:[WLIVE Amazon Store](#)
- **Email:** Refer to your product packaging or the WLIVE Amazon store page for direct contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question