Onsekin CS08

Onsekin Dehumidifier Model CS08 User Manual

Efficient Humidity Control with Aromatherapy and Ambient Lighting

1. Introduction

Thank you for choosing the Onsekin Dehumidifier Model CS08. This device is designed to effectively remove excess moisture from your indoor environment, covering areas up to 1000 square feet. It features semiconductor condensation technology, an integrated aromatherapy diffuser, 7-color LED ambient lighting, and ultra-quiet operation modes. Please read this manual thoroughly before use to ensure proper operation and maintenance.

Your browser does not support the video tag.

Video Description: An overview of the Onsekin Dehumidifier, showcasing its compact design and various features in a home setting.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not operate the dehumidifier with a damaged cord or plug.
- Ensure the power outlet voltage matches the appliance's requirements.
- Keep the appliance away from heat sources, direct sunlight, and flammable materials.
- Do not immerse the unit, cord, or plug in water or other liquids.
- Always unplug the dehumidifier before cleaning or performing any maintenance.
- This appliance is for indoor use only.
- Do not block the air inlets or outlets.

3. Product Overview

The Onsekin Dehumidifier Model CS08 is a compact and efficient unit designed to improve air quality by reducing humidity. It features a sleek design with intuitive controls.

Components

- **Control Panel:** Power button, Mode button (moon icon for sleep mode), Light button (bulb icon for LED).
- **Water Tank:** Removable tank located at the bottom rear of the unit. Features a visible water level indicator on the front.
- **Air Inlet/Outlet:** Vents for air circulation.
- **Aromatherapy Slot:** Located on the top of the unit for essential oils.
- **Drain Port:** For continuous drainage using the included hose.
- **Integrated Handle:** For easy portability.



Image Description: Front view of the Onsekin Dehumidifier Model CS08, showcasing its minimalist design and control panel.



Image Description: Side view of the dehumidifier, highlighting the air vents and compact structure.

4. Setup

1. **Unpack the Dehumidifier:** Carefully remove the unit and all accessories from the packaging.
2. **Remove Water Tank and Accessories:** Pull out the water tank from the rear of the unit. Inside, you will find the drain hose, an extra cap, and an aromatherapy pad. Remove these items.
3. **Replace Water Tank:** Ensure the water tank is securely re-inserted into the unit.
4. **Placement:** Place the dehumidifier on a flat, stable surface in the desired area. Ensure there is at least 8 inches (20 cm) of space around the air inlets and outlets for optimal airflow.
5. **Power Connection:** Plug the power cord into a suitable electrical outlet.

Your browser does not support the video tag.

Video Description: A detailed review and demonstration of the dehumidifier's features, including unpacking, water tank removal, and aromatherapy function.

5. Operating Instructions

Power On/Off

- Press the **Power Button** ( ) once to turn the unit on. The default mode is High Speed.
- Press the **Power Button** ( ) again to turn the unit off.

Mode Selection

The dehumidifier offers two operating modes:

- **High Speed (Day Mode):** Provides powerful dehumidification.

- **Sleep Mode (Night Mode):** Operates at a lower fan speed for ultra-quiet performance (below 45dB) and turns off the LED light for an undisturbed sleep environment.

Press the **Mode Button** ( ) to switch between High Speed and Sleep Mode.



Image Description: Illustration comparing the noise levels and light status of Day Mode and Night Mode.

7-Color LED Ambient Lighting

The unit features a 7-color LED light that can be customized:

- Press the **Light Button** ( ) to cycle through the 7 colors.
- Press the button again to lock a specific color.
- Press and hold the button to turn off the LED light completely.



Image Description: Visual representation of the 7-color ambient lighting options available on the dehumidifier.

Your browser does not support the video tag.

Video Description: A short demonstration of the dehumidifier's 7-color LED light feature cycling through different colors.

Aromatherapy Function

To add a pleasant scent to your environment:

1. Locate the aromatherapy slot on the top of the unit.
2. Open the small cap and place a few drops of your preferred essential oil onto the aromatherapy pad inside.
3. Close the cap. The scent will diffuse as the dehumidifier operates.



Image Description: A hand adding essential oil drops to the aromatherapy pad on top of the dehumidifier.

6. Maintenance

Emptying the Water Tank

The dehumidifier will automatically shut off and illuminate a red light when the water tank is full. To empty:

1. Gently pull out the water tank from the rear of the unit.
2. Carefully pour out the collected water.
3. Slide the empty tank back into the unit until it clicks into place. The dehumidifier will resume operation.



Image Description: Visual representation of the dehumidifier's auto shut-off feature when the water tank is full, indicated by a red light.

Continuous Drainage

For continuous operation without needing to empty the tank manually:

1. Remove the water tank.
2. Locate the drain port at the bottom of the tank and remove the soft plug. Store the plug safely.
3. Insert one end of the provided drain hose into the drain port.
4. Ensure the other end of the hose is placed in a suitable drainage area (e.g., sink, large bucket) where water can flow continuously by gravity.
5. Re-insert the water tank into the unit.



Image Description: Step-by-step guide on how to install the drain hose for continuous water drainage.

Cleaning

- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Water Tank:** Clean the water tank regularly with mild soap and water to prevent mold and mildew buildup. Rinse thoroughly.
- **Air Filter:** The air filter should be cleaned every two weeks or as needed. Gently remove the filter, clean it with a soft brush or vacuum, and rinse with water. Ensure it is completely dry before re-inserting.

7. Troubleshooting

Problem	Possible Cause	Solution
Dehumidifier does not turn on	No power; Water tank full or incorrectly placed	Check power connection; Empty and correctly re-insert water tank.
No water collected	Room humidity too low; Temperature too low; Air inlets/outlets blocked	Ensure room conditions are suitable for dehumidification; Clear any obstructions.
Unit is noisy	Unit not on a flat surface; Air filter clogged	Place on a stable, flat surface; Clean the air filter.
Red light is on	Water tank is full or misplaced	Empty and correctly re-insert water tank.

8. Specifications

Feature	Specification
Brand	Onsekin
Model Name	CS08
Floor Area Coverage	1000 Square Feet

Feature	Specification
Dehumidification Capacity	1.1 Liters per Day
Tank Volume	2.5 Liters (85 oz)
Product Dimensions	9.4"D x 7.3"W x 15.2"H
Item Weight	2.71 Kilograms (5.96 pounds)
Number of Speeds	2 (High Speed, Sleep Mode)
Special Features	Anti-Spill, Automatic Shutoff, Portable, Sleep Mode, 7-Color LED Light, Aromatherapy Diffuser
Material	Metal, Plastic

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Onsekin customer service directly. Keep your purchase receipt as proof of purchase.

© 2025 Onsekin. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where is the air filter located on the Onsekin CS08 dehumidifier, and why is the unit leaking water?

For the Onsekin Dehumidifier Model CS08, the air filter is typically located behind the air inlet vents. According to the maintenance instructions, you should gently remove the filter to clean it every two weeks.Regarding...

Read full answer