

[Manuals.plus](#) /

> [Vinsetto](#) /

> Vinsetto High Back Massage Office Chair (Model 921-275V80GY) Instruction Manual

Vinsetto 921-275V80GY

Vinsetto High Back Massage Office Chair Instruction Manual

Model: 921-275V80GY

Brand: Vinsetto

PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your Vinsetto High Back Massage Office Chair, Model 921-275V80GY. This ergonomic chair features a six-point vibration massage system, adjustable recline, a retractable footrest, and adjustable height for enhanced comfort during extended use.






Image: The Vinsetto High Back Massage Office Chair in Grey, positioned in a modern office setting.

SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Do not exceed the maximum weight capacity of 264 lbs (120 kg) to ensure stability and prevent injury.
- Keep all packaging materials away from children.
- Ensure all screws and bolts are securely tightened before use and periodically check for looseness.
- Use the chair on a flat, stable surface.
- Avoid placing the chair near heat sources or in direct sunlight for prolonged periods to prevent material damage.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.



Image: A brown cardboard box labeled "Vinsetto" indicating 1x package.

SETUP AND ASSEMBLY

Assembly is required. It is recommended to have a clear, open space for assembly. An Allen wrench is typically included for tightening screws.

1. **Base Assembly:** Attach the five castor arms to the support base using the provided screws. Ensure they are securely fastened.
2. **Caster Installation:** Insert the casters into the holes at the end of each arm of the chair base.
3. **Gas Lift Installation:** Place the gas lift cylinder into the center hole of the assembled base.
4. **Seat and Backrest Assembly:** Attach the seat and backrest components according to the diagrams in the included assembly guide. Ensure all bolts are tightened.
5. **Armrest Attachment:** Secure the armrests to the seat and backrest.
6. **Footrest Assembly:** Attach the retractable footrest mechanism to the underside of the seat.
7. **Connect Power:** Plug in the power cord for the massage and heating functions.

Note: Refer to the detailed diagrams in your product's physical assembly manual for precise steps and component identification.

OPERATING INSTRUCTIONS

Height Adjustment

To adjust the chair's height, locate the lever under the seat. Lift the lever to raise the seat, or sit on the chair and lift the lever to lower it. Release the lever to lock the height.

RECLINING FUNCTION



Working



Watching



Relaxing



Image: Diagram showing the height adjustment lever and its function.

Reclining Function

The chair features a 130° recline function. Use the recline lever, typically located on the side of the chair, to adjust the backrest angle. Lean back to your desired position and release the lever to lock it. The chair also includes a retractable footrest for added comfort when reclining.

FLEXIBLE AND CONVENIENT

For multi-tasking convenience



360° swivel

Image: Diagram illustrating the 130° reclining function and the retractable footrest.

Vibration Massage and Heat Functions

The chair is equipped with a six-point vibration massage system (4 back points, 2 seat points) and a heating function, controlled by a remote. Ensure the chair is plugged into a power source.

VIBRATION MASSAGE

4 Back Points & 2 Seat Points



Image: Diagram showing the 6 vibration points in the chair and the remote control for massage and heat functions.

- **Power On/Off:** Press the power button on the remote to activate or deactivate the massage and heat functions.
- **Massage Modes:** Select from five massage modes (M1-M5) for different vibration patterns. You can target specific areas: thigh, lumbar, and back.
- **Heat Function:** Activate the heating function. Adjust heat intensity if available (low, medium, high).
- **Timer:** Set a timer for 15, 30, or 60 minutes for the massage and heat functions.

MAINTENANCE

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the faux leather.
- **Inspection:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary.
- **Moving the Chair:** When moving the chair, lift it rather than dragging it to prevent damage to the base or floor.
- **Storage:** Store the remote control in the designated side pocket when not in use.

TROUBLESHOOTING

- **Chair is unstable:** Ensure all assembly bolts are securely tightened. Check that the casters are properly inserted into the base. Ensure the chair is on a flat surface.
- **Massage/Heat not working:** Verify that the power cord is securely plugged into both the chair and a working electrical outlet. Check the remote control for battery issues if applicable (this model is wired, so check connections).
- **Difficulty adjusting height:** Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Squeaking noises:** Apply a small amount of lubricant to moving parts or pivot points, avoiding contact with upholstery. Check for loose connections and tighten if necessary.

SPECIFICATIONS

Brand	Vinsetto
Model Number	921-275V80GY
Color	Grey
Material	Faux Leather, Foam, Alloy Steel
Product Dimensions (D x W x H)	29.5"D x 26"W x 48"H (75cm D x 66cm W x 122cm H)
Adjustable Height Range	44" - 48" (112cm - 122cm)
Seat Height	22 Inches (56cm)
Seat Depth	22.25 inches (56.5cm)
Maximum Weight Capacity	264 lbs (120 kg)
Reclining Angle	Up to 130°
Massage Points	6 (4 back, 2 seat)
Included Components	Remote Control, Lumbar Pillow



Image: Detailed diagram showing the dimensions of the Vinsetto High Back Massage Office Chair.

WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms, conditions, and duration. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For any questions, missing parts, or technical assistance, please contact Vinsetto customer support. Contact details can typically be found on the product packaging or the official Vinsetto website.

Online Support: Visit the [Vinsetto Store on Amazon](#) for more information and support resources.



