CAB55 B-01

CAB55 Rolling Craft Bag User Manual

Model: B-01

Introduction

Thank you for choosing the CAB55 Rolling Craft Bag. This versatile bag is designed for convenient transport and organization of various items, including craft supplies, teaching materials, and office essentials. Its robust construction and thoughtful design ensure durability and ease of use. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to help you maximize your product's potential.

Setup Instructions

Follow these steps to assemble the removable folding hand truck and attach the craft bag.

1. **Unfold the Hand Truck:** Extend the handle of the hand truck upwards. Press the button to release and pull out the base. Ensure all parts click into place securely.
2. **Attach the Bag:** Place the craft bag onto the unfolded hand truck. The bag features a fabric strip on the back designed to slide over the hand truck's handle.
3. **Secure the Bag:** Locate the Velcro straps on the bottom of the bag. Secure these straps around the base of the hand truck to prevent movement. Additionally, thread the bungee cord (if included) through the bag and attach its hooks to the crossbar of the hand truck for extra stability.



Figure 1: Step-by-step guide for attaching the bag to the hand truck.

Your browser does not support the video tag.

Video 1: Demonstration of hand truck assembly and bag attachment for the CAB55 Rolling Craft Bag.

Operating Instructions

The CAB55 Rolling Craft Bag offers extensive storage and organization features:

- **Main Compartment:** The spacious main compartment (17 x 12 x 12 inches) is ideal for larger items such as scrapbooks, photo albums, and art canvases. It includes a removable hard base for added sturdiness and protection.
- **Internal Pockets:** Inside the main flap, there are mesh pockets and zippered pockets for smaller items like pens, rulers, and

gadgets.

- **Front Pockets:** The front of the bag features large zippered pockets for sharp tools and smaller pockets for brushes and other accessories.
- **Side Mesh Pockets:** Four side mesh bags provide quick access storage for frequently used items like water bottles or additional tools.



Figure 2: The main compartment of the bag, showcasing its capacity for various craft supplies.



Figure 3: Close-up of the front pocket and internal mesh pockets, designed for organizing smaller tools and accessories.

Storage and Portability

The CAB55 Rolling Craft Bag is designed for both easy transport and compact storage.

- **Rolling Function:** Utilize the durable two-wheel hand truck for smooth and effortless transportation of your bag. The handle is adjustable for comfortable pulling.
- **Hand Carry:** For stairs or uneven surfaces, detach the bag from the hand truck and use the reinforced top handles for individual carrying.
- **Compact Storage:** The hand truck folds flat for convenient storage when not in use. The bag itself can also be folded for minimal space occupation.



Figure 4: The bag in use, demonstrating its rolling capability with the extended handle.

Maintenance

To ensure the longevity and optimal performance of your CAB55 Rolling Craft Bag, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior fabric with a damp cloth and mild soap. Do not machine wash. Allow to air dry completely before storage.
- **Wheel Care:** Periodically check the wheels for debris and clean as needed. Ensure they rotate freely.
- **Zipper Maintenance:** Keep zippers clean and free of obstructions. Lubricate with a zipper lubricant if they become stiff.
- **Storage:** Store the bag in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

If you encounter any issues with your CAB55 Rolling Craft Bag, refer to the following common solutions:

- **Bag Tipping:** Ensure the bag is properly secured to the hand truck using all available straps and the bungee cord. Distribute

the weight of contents evenly within the bag to maintain balance.

- **Stiff Handle:** If the telescopic handle is difficult to extend or retract, check for any obstructions. Apply a small amount of silicone spray to the telescoping mechanism if necessary.
- **Wheels Not Rolling Smoothly:** Inspect the wheels for tangled hair, lint, or other debris. Clean the wheel axles thoroughly.

Specifications

Feature	Detail
Product Dimensions	17 x 12 x 12 inches
Item Weight	6.69 pounds
Model Number	B-01
Material	Heavy-duty nylon with sponge filling
Wheels	2-wheel hand truck (removable)

Warranty and Support

CAB55 offers a **1-year quality warranty** on every rolling case purchased. If you are not satisfied with your rolling craft bag or encounter any issues, please contact our customer service team for assistance. Our enthusiastic customer service team is eager to help with any questions or problems about our bag series.
For support, please visit our official website or contact us via the details provided on your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question