

Angel Sar B0F2215N92

Angel Sar Modern White Shoe Cabinet User Manual

Model: B0F2215N92

1. PRODUCT OVERVIEW

The Angel Sar Modern White Shoe Cabinet is designed to provide a sleek and functional storage solution for your entryway or hallway. This minimalist cabinet features three flip drawers with adjustable shelves, capable of storing 16-24 pairs of shoes. Its compact design makes it ideal for small spaces, while the durable MDF construction ensures longevity and easy maintenance. The top surface offers additional space for decorative items.



Image 1.1: The Angel Sar Modern White Shoe Cabinet, showcasing its design and capacity for shoe storage in an entryway setting.

Key Features:

- **Modern Minimalist Design:** Clean lines and a contemporary white finish seamlessly integrate into various home decors.
- **Versatile and Practical Storage:** Three flip drawers with adjustable shelves accommodate different shoe heights, storing 16-24 pairs.
- **Space-Saving and Compact:** With a depth of only 9.45 inches, it's perfect for narrow entryways and small spaces.
- **Easy to Maintain and Built to Last:** Constructed from high-quality MDF with a laminated finish for durability and easy cleaning.
- **Quick Assembly:** Simple setup with clear instructions and all necessary hardware included.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the unit on a soft, clean surface to prevent scratches.

- Do not overtighten screws, as this may damage the material.
- For safety, it is recommended to secure the cabinet to a wall using anti-tip hardware (if included) to prevent tipping, especially in homes with children or pets.
- Do not exceed the weight capacity of the shelves or the top surface.
- Keep small parts away from children during assembly to avoid choking hazards.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Top, Bottom, Sides, Back)
- Flip Drawers (x3)
- Adjustable Shelves (for inside drawers)
- Legs (x4)
- Hardware Pack (Screws, Dowels, Cam Locks, Hinges, Handles, Anti-tip Kit)
- Assembly Instructions Manual

4. SETUP AND ASSEMBLY

Assembly is required for this shoe cabinet. Please follow these steps carefully. It is recommended to have two people for assembly.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the cabinet parts and your floor.
2. **Attach Legs:** Securely attach the four black legs to the bottom panel of the cabinet using the provided screws. Ensure they are firmly tightened.
3. **Assemble Cabinet Frame:** Connect the side panels to the bottom panel, then attach the top panel. Use dowels and cam locks as indicated in the detailed assembly diagram. Ensure all connections are snug.



Image 4.1 : Rear view of the cabinet, illustrating the back panel and support beams for structural integrity.

4. **Install Back Panel:** Slide or screw the back panel into place. This adds stability and completes the main frame.
5. **Assemble Flip Drawers:** For each of the three flip drawers, assemble the drawer box and attach the front panel. Install the internal adjustable shelves within each drawer.



Image 4.2: The cabinet with all three flip drawers open, showing the internal structure and adjustable shelves ready for shoe placement.

6. **Attach Drawers to Cabinet:** Mount the assembled flip drawers to the cabinet frame using the provided hinges. Ensure they open and close smoothly.
7. **Install Handles:** Attach the handles to the front of each flip drawer.
8. **Secure to Wall (Recommended):** For enhanced stability and safety, especially in households with children or pets, use the included anti-tip kit to secure the cabinet to a wall. Follow the specific instructions provided with the anti-tip hardware.

5. OPERATING INSTRUCTIONS

Using your Angel Sar Shoe Cabinet is straightforward:

- **Opening Drawers:** Gently pull the handle of each flip drawer outwards. The drawer will tilt forward, revealing the shoe compartments.
- **Storing Shoes:** Place shoes onto the adjustable shelves within each drawer. The shelves can be adjusted to accommodate different shoe sizes and types, such as flats, sneakers, or boots.



Image 5.1: The shoe cabinet with various types of shoes organized within its three open flip drawers.

- **Closing Drawers:** Push the drawer back into the cabinet until it clicks securely into place.
- **Top Surface Use:** The top surface can be used to display decorative items, keys, or other small belongings. Do not place excessively heavy items on the top.

6. MAINTENANCE

To keep your Angel Sar Shoe Cabinet in excellent condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner can be used. Dry immediately with a clean cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or polishes that may damage the finish.
- **Spills:** Clean up spills immediately to prevent moisture damage to the MDF.
- **Regular Checks:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.

7. TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Drawers do not close properly.	Shoes are obstructing the mechanism; hinges are loose or misaligned.	Ensure shoes are fully inside the drawer. Check and tighten hinge screws. Realign hinges if necessary.
Cabinet feels wobbly.	Screws are loose; cabinet is not on a level surface; anti-tip kit not installed.	Tighten all assembly screws. Move cabinet to a level surface. Install the anti-tip kit to secure it to the wall.
Scratches on surface.	Rough handling; abrasive cleaning materials.	Use a soft cloth for cleaning. Avoid dragging sharp objects across the surface. Minor scratches may be touched up with furniture repair pens.
Missing parts during assembly.	Packaging error.	Contact Angel Sar customer support with your purchase details and the list of missing parts.

8. SPECIFICATIONS

Detailed specifications for the Angel Sar Modern White Shoe Cabinet:



Image 8.1: Dimensional drawing of the shoe cabinet, indicating its height, width, and depth.

Attribute	Detail
-----------	--------

Attribute	Detail
Brand	Angel Sar
Model	B0F2215N92
Color	White (with Black Legs)
Product Dimensions (Assembled)	31.50" L x 9.65" W x 47.24" H (9.65"D x 31.5"W x 47.24"H)
Material	MDF (Medium-Density Fiberboard)
Item Weight	63.8 Pounds
Mounting Type	Floor Mount
Assembly Required	Yes
Shoe Capacity	16-24 pairs (approx.)

9. WARRANTY AND SUPPORT

Return Policy: This product is eligible for a 30-day return policy, allowing for a refund or replacement within 30 days of purchase. Please refer to the retailer's specific return policy for detailed terms and conditions.

Manufacturer Support: For any questions regarding assembly, missing parts, or product defects, please contact Angel Sar customer support.

Seller Information: Sold by Angel Sar Furniture.

For further assistance, please visit the Angel Sar store on Amazon or contact their customer service directly.