

VECELO TV Stand with Mount

VECELO 63" TV Stand with Swivel Mount and Power Outlets Instruction Manual

Model: TV Stand with Mount | Brand: VECELO

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VECELO 63" TV Stand with Swivel Mount and Power Outlets. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.

Safety Information

- Do not exceed the weight limit of **160 lb** on the top surface and **60 lb** on the lower shelves.
- Always assemble the TV stand according to the instructions provided to ensure stability and prevent tip-over risks.
- Ensure all parts and screws are tightened securely before using the TV stand.
- Keep small parts away from children during assembly.

2. SETUP AND ASSEMBLY

The VECELO TV Stand is designed for straightforward assembly. All necessary tools and instructions are included in the package. Please follow the steps below and refer to the assembly video for visual guidance.

Assembly Steps Overview

1. Unpack all components and verify against the parts list provided in your package.
2. Assemble the main frame structure using the provided screws and tools.
3. Attach the wooden shelves to the frame.
4. Install the TV swivel mount to the designated area on the stand.

5. Secure the power strip into its slot.
6. Attach the adjustable feet to the bottom of the stand.
7. Ensure all connections are tight and the stand is stable before placing any items on it.

Assembly Video Guide

Your browser does not support the video tag.

Video: This video demonstrates the step-by-step assembly process for the VECELO TV Stand. It covers attaching the frame, shelves, and mount, providing a visual guide to complement the written instructions.

Product Dimensions




Image: This diagram illustrates the overall dimensions of the TV stand: 63"L x 15.7"W x 24"H, with a total height of 61.4" including the mount. It also shows the spacing of the open shelves and the mount's width of 26.2" and height of 16.9".

3. OPERATING INSTRUCTIONS

TV Mount Usage

The integrated swivel mount is designed to accommodate most 40-75 inch TVs. It allows for a rotation of $\pm 45^\circ$ to optimize your viewing angle. Ensure your TV's VESA mounting pattern (horizontal and vertical hole distances) falls within the supported range of 6.7-24.6 inches horizontally and 5.5-15.3 inches vertically.

Fits TV Size Most 40~75 inch



Available Mounting Holes

Horizontal Support : 6.7-24.6 inch

Vertical Support: 5.5-15.3 inch



Image: This image displays the TV size compatibility, indicating the stand fits most 40-75 inch televisions. It also details the available mounting holes, specifying horizontal support from 6.7 to 24.6 inches and vertical support from 5.5 to 15.3 inches.

Your browser does not support the video tag.

Video: This video showcases the VECELO Swivel TV Stand, highlighting its adjustable mount and the ability to rotate the TV for optimal viewing angles. It demonstrates the stand's functionality with larger televisions.

Power Outlets and USB Ports

The TV stand includes a built-in power strip with four 125V/12A outlets and two 5V/2A USB ports. This allows for convenient powering and charging of your television, gaming consoles, media players, and other electronic devices directly from the stand, reducing cable clutter.

Built Power Outlet



125V/12A



5V/2A



Image: This image provides a clear view of the built-in power outlet, featuring four standard electrical outlets (125V/12A) and two USB charging ports (5V/2A) for convenient device connectivity.

Adjustable Feet

The TV stand is equipped with adjustable feet that can be rotated 360°. These feet help stabilize the stand on uneven floors and protect your flooring from scratches.

Adjustable Feet



Adjustable Mount



Sturdy Metal Shelf



Image: This image highlights two key features: the adjustable feet at the base of the stand, which can be rotated 360 degrees for stability on uneven surfaces, and the adjustable height mechanism of the TV mount.

4. MAINTENANCE

To maintain the appearance and longevity of your VECELO TV Stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Dusting:** Regularly dust the stand with a soft, dry cloth.
- **Spills:** Clean up spills immediately to prevent staining, especially on the wooden surfaces.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.

5. TROUBLESHOOTING

If you encounter any issues with your VECELO TV Stand, please refer to the following common solutions:

- **Stand is wobbly:** Ensure all assembly screws are fully tightened. Adjust the leveling feet on the bottom of the stand to compensate for uneven flooring.
- **TV mount not holding position:** Verify that the TV is within the specified weight and size limits. Check that all mounting hardware is securely fastened to both the TV and the stand.
- **Power outlets not working:** Ensure the power cord for the stand is securely plugged into a functional wall outlet. Check if the power strip has a reset button or circuit breaker that may have tripped.
- **Missing parts:** If you find any parts missing during assembly, please contact VECELO customer support for assistance.

For issues not covered here, or if troubleshooting steps do not resolve the problem, please contact VECELO customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	VECELO
Model Number	TV Stand with Mount
Color	Black
Material Type	Engineered Wood (MDF), Metal
Item Dimensions (L x W x H)	63 x 15.7 x 61.4 inches (overall with mount)
Stand Dimensions (L x W x H)	63 x 15.7 x 24 inches (without mount)
Item Weight	58 Pounds
Tabletop Weight Capacity	160 lbs
Open Shelves Weight Capacity	60 lbs
TV Mount Compatibility	Most 40-75 inch TVs
Mount Horizontal Support	6.7 - 24.6 inches
Mount Vertical Support	5.5 - 15.3 inches
Mount Rotatable Angle	±45°
Power Outlets	4 x 125V/12A
USB Ports	2 x 5V/2A
Assembly Required	Yes
Included Components	1 x TV Stand with Mount, 1 x Tool Kit, 1 x Instructions

7. WARRANTY AND SUPPORT

Warranty Information

VECELO provides a **24-month warranty** for this product, covering manufacturing defects and material flaws under normal use. Please retain your proof of purchase for warranty claims.

Return Policy

A **30-day free return service** is available from the date of purchase. Please refer to the retailer's return policy for specific conditions.

Customer Support

If you have any questions, require assistance with assembly, or need replacement parts, please do not hesitate to contact VECELO customer support. Our team is available to help you.

Contact information can typically be found on the VECELO official website or through your purchase platform.