

Midland T71PNK

Midland T71PNK X-TALKER FRS Walkie Talkies User Manual

Model: T71PNK

INTRODUCTION

Thank you for choosing the Midland T71PNK X-TALKER FRS Walkie Talkies. This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your two-way radios. Please read this manual thoroughly before use to ensure optimal performance and safety.



Image: Two Midland T71PNK X-TALKER FRS Walkie Talkies.

Key Features

- 36 FRS (Family Radio Service) Channels for communication.
- 121 CTCSS Privacy Codes for enhanced communication options.
- NOAA Weather Scan + Alert for severe weather updates.
- eVOX (Easy Voice and Sound Activated Transmission) for hands-free operation.
- Channel Scan feature to monitor active channels.
- Micro USB charging capability.

What's in the Box

Your Midland T71PNK X-TALKER package includes the following items:

- 2 x Midland T71PNK X-TALKER FRS Walkie Talkies

- 2 x Belt Clips
- 2 x 1000mAh Rechargeable Battery Packs
- 1 x Micro USB Charging Cable

IN THE BOX BUILT FOR EVERY ADVENTURE



Image: Contents of the Midland T71PNK X-TALKER package.

SETUP

Battery Installation

1. Locate the battery compartment cover on the back of the radio.
2. Press down on the tab and slide the cover off.
3. Insert the 1000mAh rechargeable battery pack, ensuring the contacts align correctly.
4. Replace the battery compartment cover, sliding it until it clicks into place.

Charging the Batteries

Before first use, fully charge the battery packs. The radios feature a battery meter on the display.

1. Connect the micro USB charging cable to the micro-USB charging port located on the side of the radio.

2. Connect the other end of the USB cable to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The battery indicator on the display will show charging status. A full charge typically takes several hours.
4. Disconnect the charging cable once charging is complete.



Image: Midland T71PNK radio highlighting rapid charge feature.

Attaching the Belt Clip

1. Align the belt clip with the grooves on the back of the radio.
2. Slide the belt clip downwards until it locks into place.
3. To remove, lift the tab on the belt clip and slide it upwards.

OPERATING INSTRUCTIONS



Image: Diagram of Midland T71PNK controls and features.

Power On/Off

- To power on, press and hold the **POWER/MENU** button until the display illuminates.
- To power off, press and hold the **POWER/MENU** button until the display turns off.

Adjusting Volume

- Use the **UP** and **DOWN** arrow buttons to adjust the listening volume.

Channel Selection

Your radio has 36 FRS channels.

1. Press the **MENU** button once. The channel number will flash.
2. Use the **UP** or **DOWN** arrow buttons to select your desired channel.
3. Press the **MENU** button again or wait 5 seconds to confirm the selection.

Privacy Codes (CTCSS)

Privacy codes help reduce interference from other users on the same channel by filtering out transmissions that do not use the same code.

1. Select a channel first (as described above).
2. Press the **MENU** button twice. The privacy code number will flash.
3. Use the **UP** or **DOWN** arrow buttons to select your desired privacy code (0-121).
4. Press the **MENU** button again or wait 5 seconds to confirm.

Transmitting and Receiving

- To transmit, press and hold the **PUSH-TO-TALK (PTT)** button and speak clearly into the microphone.
- Release the **PTT** button to receive.



Image: Person using a Midland T71PNK radio for communication.

NOAA Weather Scan + Alert

The NOAA Weather Scan feature automatically scans through 10 available weather (WX) band channels and locks onto the strongest weather channel to alert you of severe weather updates.

- To activate Weather Scan, press the **WX** button. The radio will begin scanning.
- To exit Weather Scan, press the **WX** button again.

eVOX (Hands-Free Operation)

eVOX allows for hands-free transmission without pressing the PTT button. An optional headset may be required for optimal performance.

1. Press the **MENU** button until the eVOX icon flashes.
2. Use the **UP** or **DOWN** arrow buttons to select the eVOX sensitivity level (1-3, with 3 being most sensitive).
3. Press the **MENU** button again or wait 5 seconds to confirm.

Channel Scan

The Channel Scan feature allows you to monitor all channels for activity.

- To activate Channel Scan, press the **MON/SCAN** button. The radio will begin scanning through channels.
- When activity is detected, the scan will pause on that channel.
- To exit Channel Scan, press the **MON/SCAN** button again.

MAINTENANCE

Battery Care

- Always use the specified rechargeable battery packs.
- Avoid overcharging or completely draining the batteries to prolong their lifespan.
- If storing the radios for an extended period, remove the battery packs.




Image: Midland T71PNK radio highlighting long-lasting battery life.

Cleaning

- Clean the radio with a soft, damp cloth.
- Do not use harsh chemicals or abrasive cleaners.

Storage

- Store the radios in a cool, dry place when not in use.
- Keep away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No power	Ensure batteries are correctly installed and fully charged.
Cannot transmit or receive	Verify both radios are on the same channel and privacy code. Check battery level. Ensure PTT button is fully pressed.
Poor audio quality	Adjust volume. Move closer to the other radio. Check for obstructions. Ensure microphone is not covered.
Weather Alert not working	Ensure you are in an area with NOAA weather radio coverage.

SPECIFICATIONS

Feature	Detail
Model Number	T71PNK
Channels	36 FRS Channels
Privacy Codes	121 CTCSS Codes
Frequency Range	450-470 MHz
Talking Range Maximum	Up to 30 Miles (unobstructed environments)
Power Source	1000mAh Rechargeable Battery Pack (included)
Special Features	Voice Operated Transmission (eVOX), Weather Alert
Water Resistance Level	Water Resistant
Product Dimensions	1.4 x 2.6 x 6.1 inches
Item Weight	7.2 ounces

LEGAL DISCLAIMER

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device does not cause harmful interference, and (2) this radio must accept any interference that may cause undesired operation. To maintain compliance with the FCC's RF exposure guidelines, for body-worn operation, this radio has been tested and meets the FCC RF exposure guidelines when used with Midland Radio Corp. accessories supplied or designed for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

WARRANTY AND SUPPORT






Warranty Information

Midland products are designed for reliability. For specific warranty details regarding your T71PNK X-TALKER FRS Walkie Talkies, please refer to the warranty card included in your product packaging or visit the official Midland website.

Customer Support

For technical assistance, troubleshooting, or general inquiries, please contact Midland customer support. You can find contact information and additional resources on the official Midland website: [Midland Radio Store](#).

Related Documents - T71PNK

	<p>Midland X-Talker T60 Series Two-Way Radios User Manual</p> <p>User manual for Midland X-Talker T60 Series two-way radios, covering features, operation, battery installation, charging, troubleshooting, specifications, and warranty.</p>
	<p>Midland T60 Series X-TALKER Two-Way Radios User Manual and Specifications</p> <p>Official user manual for the Midland T60 Series X-TALKER Two-Way Radios. Learn about features, operation, charging, troubleshooting, specifications, privacy codes, NOAA weather alerts, and warranty.</p>
	<p>Midland X-TALKER T10 & T30 Series Two-Way Radios User Manual</p> <p>Comprehensive user manual for Midland X-TALKER T10 and T30 series two-way radios. Learn about features, operation, charging, troubleshooting, and specifications.</p>
	<p>Midland X-Talker T70 Series Two-Way Radios User Manual and Specifications</p> <p>Comprehensive user manual for the Midland X-Talker T70 Series two-way radios, covering features, operation, installation, charging, troubleshooting, specifications, and accessories. Includes FCC and Industry Canada compliance information.</p>
	<p>Midland X-TALKER T70 Series Two-Way Radios User Manual</p> <p>Comprehensive user manual for the Midland X-TALKER T70 Series (T71 & T75) two-way radios, covering features, operation, FCC compliance, troubleshooting, specifications, and warranty information.</p>



[Midland T10 Two-Way Radio User Manual and Features](#)

Comprehensive guide to the Midland T10 two-way radio, covering its features, operation, specifications, and compliance information. Learn how to use channels, privacy codes, VOX, NOAA weather alerts, and more.