

HOLAPAW WSQ-A001

HOLAPAW Automatic 5-Meal Wet Food Pet Feeder (Model WSQ-A001) Instruction Manual

Model: WSQ-A001

INTRODUCTION

Thank you for choosing the HOLAPAW Automatic 5-Meal Wet Food Pet Feeder. This device is designed to provide up to five scheduled meals for your pet, ensuring fresh food delivery even when you are away. It features a cordless design, voice recording capability, and includes ice packs to keep wet food fresh. Please read this manual thoroughly before use to ensure proper operation and maintenance.

- **5-Meal Capacity:** Dispenses up to 5 customized meals daily (260ml per slot) for wet food, dry food, or treats.
- **Freshness Preservation:** Includes 2 ice crystal boxes to keep food refrigerated for up to 6 hours and wet food fresh for up to 12 hours.
- **Cordless & Battery Operated:** Powered by 4 C batteries (not included) for the feeder, offering up to 180 days of battery life. The UV component requires 3 AAA batteries (not included).
- **10-Second Voice Recording:** Record a personalized message to call your pet for meals.
- **Easy to Clean:** Made from food-grade, BPA-free ABS material. The feeder tray is removable for cleaning.

SAFETY INFORMATION

Please read and follow all safety instructions to prevent injury or damage to the product.

- Always read the user manual carefully before initial use.
- Keep the feeder away from direct sunlight and heat sources.
- Do not immerse the main unit in water. The feeder tray is removable for cleaning.
- Ensure batteries are inserted with correct polarity. Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the feeder will not be used for an extended period.
- This product is intended for indoor use only.
- Keep out of reach of children.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your HOLAPAW Automatic Pet Feeder.



Figure 1: Exploded View of Feeder Components

An exploded diagram of the HOLAPAW Automatic Pet Feeder details its individual parts. These include the Top Cover, the multi-compartment Feeder Tray, the Ice Crystal Box (shown in blue), and the main Base unit. A note indicates that batteries are not included.

1. Top Cover
2. Feeder Tray (5 compartments)
3. Ice Crystal Box (2 units)
4. Base Unit (with control panel and battery compartment)

SETUP

1. Install Batteries:

- Open the battery compartment on the underside of the Base Unit.
- Insert 4 C batteries (not included) into the main feeder compartment, ensuring correct polarity.
- If using the UV sterilization feature, insert 3 AAA batteries (not included) into its dedicated

compartment.

- o Close the battery compartments securely.



Figure 2: Feeder Dimensions and C Battery Installation

This image shows the HOLAPAW Automatic Pet Feeder in white, positioned on a wooden floor next to a cat. The feeder's dimensions are indicated as 12.6 inches in width and 5.6 inches in height. An inset graphic highlights the requirement for 4 C batteries, which are not included.



Figure 3: UV Sterilization and AAA Battery Installation

The image displays the HOLAPAW Automatic Pet Feeder on a wooden floor with a cat nearby. A purple glow emanates from the base, indicating UV sterilization. Insets show 'Ultraviolet Lamps' and the need for '3 x AAA Batteries (not included)' for the UV component.

2. **Prepare Ice Packs:** Place the two included ice crystal boxes in a freezer for at least 6-8 hours until completely frozen.
3. **Assemble Feeder:**
 - Once frozen, place the ice crystal boxes into the designated slots in the Base Unit.
 - Place the Feeder Tray onto the Base Unit, aligning it properly.
 - Secure the Top Cover onto the Feeder Tray.

OPERATING INSTRUCTIONS

1. Setting the Clock and Meal Schedule

The control panel on the feeder allows you to set the current time and program up to 5 meal times.

1. Press the 'SET' button to enter programming mode.
2. Use the 'UP' and 'DOWN' buttons to adjust the hour and minute for the current time. Press 'SET' to confirm each setting.
3. Continue pressing 'SET' to cycle through the 5 meal time settings (M1 to M5). For each meal, use 'UP' and

'DOWN' to set the desired dispensing time.

4. If you do not wish to use all 5 meal slots, simply set the unused meal times to 'OFF' or a time outside your pet's feeding window.
5. After setting all desired meal times, press 'SET' until the display returns to the current time.



Figure 4: Programmed Meal Schedule Example

A cat is shown eating from the HOLAPAW Automatic Pet Feeder on a wooden floor. A graphic overlay illustrates a programmed feeding schedule with five meal times: 06:00, 10:00, 14:00, 18:00, and 22:00, emphasizing the 'Feed On Time' feature.

2. Recording a Voice Message

You can record a 10-second voice message to play at each meal time, calling your pet to eat.

1. Locate the 'REC' (Record) button on the control panel.
2. Press and hold the 'REC' button. Speak clearly into the microphone for up to 10 seconds.
3. Release the 'REC' button to save your message.
4. To test the message, press the 'PLAY' button. The message will play before each scheduled meal.



Figure 5: Voice Recording Feature

The image features a cat sitting near the HOLAPAW Automatic Pet Feeder. A speech bubble graphic with a speaker icon and the text 'It's time to eat' highlights the feeder's 10-second voice recording capability, designed to call pets for meals.

3. Filling Food Compartments

The feeder tray has 5 compartments, each with a capacity of 260ml.

1. Remove the Top Cover.
2. Fill each compartment with your pet's desired wet food, dry kibble, or treats. Do not overfill.
3. Replace the Top Cover securely.

Scientific Feeding & Balanced Nutrition

Support Wet Food, Various Sized Dry Food & Snacks



Figure 6: Feeder Tray with Various Food Types

This image provides an overhead view of the HOLAPAW Automatic Pet Feeder's internal tray, divided into five compartments. Each compartment is shown filled with different types of pet food, including snacks, freeze-dried food, dry food, fresh food, and canned food. The capacity of each slot is labeled as 260 ml.

4. Using Ice Packs for Freshness

The frozen ice packs help maintain food freshness, especially for wet food.

1. Ensure the ice crystal boxes are fully frozen before placing them into the feeder.
2. Place the frozen ice packs into the designated slots in the Base Unit before placing the Feeder Tray.
3. The ice packs can keep food refrigerated for up to 6 hours and wet food fresh for up to 12 hours, depending on ambient temperature.

Keep Frozen for 6 Hours Fresh within 12 Hours



Twin Ice Packs

Greater Cooling
And Preservation Of Food

Figure 7: Ice Pack Cooling Duration

This diagram visually explains the cooling performance of the HOLAPAW Automatic Pet Feeder's ice packs. It shows a circular graphic indicating that food can be kept frozen for 6 hours and fresh for up to 12 hours, emphasizing the extended preservation capabilities.

MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the life of your feeder.

- **Feeder Tray:** The feeder tray is removable for easy cleaning. It is recommended to hand wash the feeder tray with mild soap and water. Rinse thoroughly and dry completely before reassembling.
- **Base Unit and Top Cover:** Wipe the exterior of the Base Unit and Top Cover with a damp cloth. Do not immerse the Base Unit in water, as it contains electronic components.
- **Ice Crystal Boxes:** After each use, wash the ice crystal boxes with soap and water, then refreeze for future use.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display, or if the feeder's functions become erratic.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Feeder does not turn on or display is blank.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with fresh C batteries.
Food is not dispensed at scheduled times.	Meal times are not set correctly or batteries are low.	Review the 'Setting the Clock and Meal Schedule' section. Replace batteries if needed.
Voice message is not playing.	Message not recorded or AAA batteries for UV component are low/dead.	Ensure a message has been recorded. Replace AAA batteries for the UV/voice component.
Food does not stay fresh for expected duration.	Ice packs not fully frozen or high ambient temperature.	Ensure ice packs are completely frozen for at least 6-8 hours. Place feeder in a cooler area if possible.
Feeder tray rotation is stuck.	Food obstruction or tray not properly seated.	Remove the top cover and tray, clear any obstructions, and reassemble ensuring the tray is correctly aligned.

SPECIFICATIONS

- **Model Number:** WSQ-A001
- **Product Dimensions:** 32.26 x 32.26 x 14.22 cm (12.7 x 12.7 x 5.6 inches)
- **Item Weight:** 1.6 kg (3.53 lbs)
- **Material:** Acrylonitrile Butadiene Styrene (ABS), Polypropylene
- **Target Species:** Cat
- **Food Capacity:** 5 compartments, 260ml per slot
- **Power Source:**
 - Feeder: 4 x C batteries (not included)
 - UV Component: 3 x AAA batteries (not included)
- **Special Features:** Automatic feeding schedule, programmable timer, 10s voice recording, UV sterilization, ice pack cooling.
- **Care Instructions:** Food tray hand wash only.

WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your HOLAPAW Automatic Pet Feeder, please refer to the manufacturer's official website or contact their customer service department. Contact details are typically provided on the product packaging or the manufacturer's website.