

Lenox 897580

Lenox 897580 Chef Snoopy Mugs, Set Of 4 User Manual

Your Guide to Care and Use

1. INTRODUCTION

Thank you for choosing the Lenox Chef Snoopy Mugs. This set of four mugs features beloved Peanuts characters Snoopy and Woodstock in charming chef-themed illustrations. Crafted from durable everyday porcelain, these mugs are designed for daily use and convenience. Please read this manual carefully to ensure proper care and enjoyment of your new mugs.



Image 1.1: The Lenox Chef Snoopy Mugs, Set of 4, showcasing individual designs.

2. PRODUCT COMPONENTS

Your purchase includes:

- Four (4) Lenox Chef Snoopy Mugs, each with a 16-ounce capacity.



Image 2.1: The four Lenox Chef Snoopy Mugs, stacked for display.

3. SETUP AND FIRST USE

Upon receiving your Lenox Chef Snoopy Mugs, please follow these steps:

1. **Unpack:** Carefully remove all mugs from their packaging. Inspect each mug for any signs of damage.
2. **Initial Cleaning:** Before first use, wash the mugs thoroughly with warm, soapy water, or place them in a dishwasher. Rinse well and dry.

4. OPERATING AND USAGE

These mugs are designed for serving hot or cold beverages. Their durable porcelain construction makes them

suitable for everyday use.

- **Beverage Compatibility:** Suitable for coffee, tea, hot chocolate, water, juice, and other beverages.
- **Microwave Safe:** The mugs are safe for use in microwave ovens for reheating beverages. Exercise caution as mugs may become hot.

5. MAINTENANCE AND CARE

To maintain the quality and appearance of your Lenox Chef Snoopy Mugs, please adhere to the following care instructions:

- **Dishwasher Safe:** These mugs are safe for cleaning in a dishwasher. Place them securely to prevent movement during the wash cycle.
- **Hand Washing:** If hand washing, use a soft sponge or cloth with mild dish soap. Avoid abrasive scrubbers that could scratch the surface or artwork.
- **Microwave Use:** While microwave safe, avoid extreme temperature changes, such as moving directly from a freezer to a hot oven, as this can cause thermal shock and damage.
- **Storage:** Store mugs in a manner that prevents chipping or breakage.

6. TROUBLESHOOTING

Most issues with ceramic mugs relate to improper handling or care. Follow the maintenance guidelines to prevent common problems.

- **Stains:** For stubborn coffee or tea stains, a paste of baking soda and water can be gently applied and left for a few minutes before washing.
- **Chipping/Breakage:** Ceramic items can chip or break if dropped or subjected to hard impacts. Handle with care.
- **Fading Artwork:** The artwork is designed to be durable. Ensure proper cleaning methods are used; avoid harsh chemicals or extremely abrasive cleaning tools.

7. SPECIFICATIONS





Feature	Detail
Brand	Lenox
Model Number	897580
Collection	Chef Snoopy
Material	Durable Everyday Porcelain
Quantity	Set of 4 Mugs
Capacity (Each)	16 ounces
Dimensions (Each)	4.43" H x 3.43" Diameter
Color	Multicolor (featuring Snoopy & Woodstock designs)
Dishwasher Safe	Yes
Microwave Safe	Yes

Item Weight	3.94 pounds (for the set)
UPC	194372037372

8. WARRANTY AND SUPPORT

Lenox products are crafted with quality and care. For specific warranty information or customer support regarding your Chef Snoopy Mugs, please refer to the official Lenox website or contact their customer service directly. You can visit the official Lenox store online for more information: [Lenox Official Store](#)

Related Documents - 897580

	<p>Lenox BCD120 Bluetooth Turntable CD Recorder Music System: Instruction Manual</p> <p>Explore the features of the Lenox BCD120 Bluetooth Turntable CD Recorder Music System with this official instruction manual. Learn setup, operation, recording, and troubleshooting for vinyl, CD, cassette, USB, and Bluetooth.</p>
	<p>Lenox 14830TS12 Manual Tight Space Tubing Cutter, 1/2 in - Product Overview</p> <p>Detailed information on the Lenox 14830TS12 Manual Tight Space Tubing Cutter, 1/2 in. Features include optimized blade geometry, compact design for tight spots, and stainless steel rollers. Suitable for cutting copper and soft tubing.</p>
	<p>LENEX MF550 40cm Misting Pedestal Fan User Manual</p> <p>Comprehensive user manual for the LENOX MF550 40cm Misting Pedestal Fan. Includes assembly instructions, operation guide, safety precautions, cleaning, maintenance, and troubleshooting tips for optimal household use.</p>
	<p>LENEX M Pedicure Spa Chair: Luxury and Comfort</p> <p>Discover the LENOX M Pedicure Spa Chair by J&A Inc., offering a refined experience with luxurious design, advanced Shiatsu massage, and exceptional comfort for the most elegant salons.</p>



[LENOX SNAP-BACK™ Quick Change Hole Saw Arbors & Pilot Drills | Product Guide](#)

Explore the LENOX SNAP-BACK™ system for quick and easy hole saw changes. Features tool-free bit change, anti-jam collar, and universal compatibility for arbors and pilot drills. Includes product specifications and cross-reference information.



[Porodo LENOX SMART WATCH PD-SWGTSL-BK User Manual](#)

User manual for the Porodo LENOX SMART WATCH PD-SWGTSL-BK, detailing features, operation, charging, connection, notifications, firmware upgrades, and main functions like Bluetooth calls, phonebook, activity tracking, and more.