Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KEXIN B0F23H814R

KEXIN External SSD 1TB User Manual

Model: B0F23H814R

Introduction

This manual provides detailed instructions for the KEXIN 1TB External Solid State Drive. Please read this guide thoroughly to ensure proper setup, operation, and maintenance of your device. This external SSD is designed for fast data transfer and broad compatibility across various devices.



Image: KEXIN External SSD with included cables and adapter.

Package Contents

Verify that all items are present in your package:

- 1 x KEXIN 1TB External SSD
- 1 x Silicone shell
- 1 x USB-C to USB-A cable
- 1 x USB-A to USB-C adapter
- 1 x Pouch
- 1 x User Manual (this document)



Image: All components included with the KEXIN External SSD.

Product Features

- **Fast Data Transfer:** Utilizes USB 3.1 standard for read/write speeds up to 500MB/s, enhancing performance for various tasks.
- **Wide Compatibility:** Connects to USB-C laptops, Macs, Xbox, PS4, tablets, Android phones, game consoles, and USB-A devices using the included cables and adapter.
- **Premium Quality:** Features an aluminum housing for shock and dust resistance, ensuring data safety and durability. Each unit undergoes rigorous testing for reliable performance.
- **Compact and Portable:** Designed with dimensions of 85.9x41x10mm (3.38x1.61x0.39 inches) and a weight of 52g (1.83oz), making it easy to carry in a pocket or bag.




Image: Internal components of the KEXIN External SSD, highlighting the memory chip.

Setup Instructions

1. **Connect the SSD:**
   a. Identify the appropriate port on your device (USB-C or USB-A).
   b. Use the provided USB-C to USB-A cable. Connect the USB-C end to the KEXIN SSD.
   c. If your device has a USB-A port, connect the USB-A end of the cable directly to your device.
   d. If your device has a USB-C port, attach the USB-A to USB-C adapter to the USB-A end of the cable, then connect the adapter to your device's USB-C port.
2. **Initial Recognition:** Your operating system should automatically detect the KEXIN SSD. A new drive letter or icon may appear.
3. **Formatting (if necessary):** For optimal performance and compatibility, especially if using with a new operating system or for specific applications, you may need to format the drive. Refer to your operating system's disk management tools for formatting options (e.g., exFAT for broad compatibility, NTFS for Windows, APFS/HFS+ for Mac). Formatting will erase all data on the drive, so ensure it is empty or backed up if it contains data.



Image: KEXIN External SSD connected to a laptop, illustrating typical setup.

Operating Instructions

1. **Data Transfer:** Once connected and recognized, you can drag and drop files to and from the KEXIN SSD just like any other external storage device.
2. **Compatibility:** The KEXIN SSD is compatible with a wide range of devices, including:
    - PC (Windows)
    - Mac (macOS)
    - Android devices
    - Game Consoles (Xbox, PS4)
    - Laptops and Tablets

    Note on Game Consoles: While compatible with game consoles like Xbox and PS4 for storing games and media, specific console features (e.g., playing next-generation games directly from external storage) may require specialized external NVMe SSDs or internal upgrades. The KEXIN External SSD functions as a high-speed external storage device for general

use.

3. **Safe Removal:** Always safely eject the SSD from your operating system before physically disconnecting it to prevent data corruption.



Image: Visual representation of the KEXIN SSD's universal compatibility with various devices.

Maintenance

- **Physical Care:** The aluminum housing provides protection, but avoid dropping the device or exposing it to excessive force.
- **Environmental Conditions:** Keep the SSD away from extreme temperatures, direct sunlight, and moisture.
- **Cleaning:** Use a soft, dry cloth to clean the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the SSD in its protective pouch to prevent scratches and dust accumulation.



Image: The compact KEXIN External SSD being stored in a bag.

Troubleshooting

- **SSD Not Recognized:**
  a. Ensure the cable is securely connected to both the SSD and your device.
  b. Try connecting to a different USB port on your device.
  c. Test with a different USB cable if available.
  d. Restart your computer or device.
  e. Check your operating system's disk management utility to see if the drive is detected but unformatted or offline.
- **Slow Data Transfer Speeds:**
  a. Ensure you are connected to a USB 3.0/3.1 port on your device. Older USB 2.0 ports will result in significantly slower speeds.
  b. Close any unnecessary applications running in the background that might be consuming system resources.
  c. Ensure your device's drivers are up to date.
- **SSD Gets Warm During Use:**

It is normal for the SSD to become slightly warm during extended use, especially during large data transfers. The aluminum housing helps dissipate heat. If it becomes excessively hot, disconnect it and allow it to cool before resuming use.

- **Data Corruption:**
  Always safely eject the SSD before disconnecting it. Unexpected disconnections can lead to data loss or corruption. If data corruption occurs, you may need to reformat the drive (which will erase all data).

SPECIFICATIONS

Brand	KEXIN
Series	KEXIN External SSD
Model Number	B0F23H814R
Digital Storage Capacity	1 TB
Hard Disk Interface	USB 3.0 (compatible with USB 3.1)
Connectivity Technology	USB
Hard Disk Description	Solid State Drive
Read/Write Speed	Up to 500MB/s
Item Weight	1.83 ounces (52g)
Product Dimensions (LxWxH)	3.38 x 1.61 x 0.39 inches (85.9 x 41 x 10 mm)
Color	Black
Compatible Devices	Camera, Gaming Console, Laptop, Smartphone, Tablet



Image: Detailed dimensions of the KEXIN External SSD and its accompanying cable and adapter.

Warranty and Support

KEXIN products are designed for reliability and performance. For any questions, technical assistance, or warranty inquiries regarding your KEXIN External SSD, please contact KEXIN customer service. Refer to the product packaging or the official KEXIN website for the most current contact information.
Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F23H814R

More documents and user manuals: **https://manuals.plus/**