

**Dekala SAC001**

# Dekala Arches Sunrise Alarm Clock User Manual

Model: SAC001

## 1. PRODUCT OVERVIEW

The Dekala Arches Sunrise Alarm Clock is a multifunctional device designed to enhance your sleep and wake-up experience. It combines a gradual sunrise simulation, various soothing sounds, ambient lighting, Bluetooth speaker functionality, wireless charging, and weather display. Control is intuitive via a smart app, voice commands, or physical buttons.



Figure 1: Dekala Arches Sunrise Alarm Clock with integrated wireless charging.

## 2. SETUP

### 2.1 Unboxing and Initial Placement

Carefully remove all components from the packaging. Place the Dekala Arches on a stable, flat surface such as a bedside table. Ensure it is within reach of a power outlet.

### 2.2 Power Connection

Connect the provided power adapter to the DC input port on the back of the alarm clock. Plug the adapter into a standard electrical outlet. The display will illuminate, indicating the device is powered on.

### 2.3 App Download and Wi-Fi Connection

For full functionality, download the dedicated smart app (refer to the quick start guide for QR code or app store search). Ensure your mobile device is connected to a 2.4G WiFi network, as the alarm clock only supports 2.4G

WiFi (not 5G WiFi). Follow the in-app instructions to connect your Dekala Arches to your home Wi-Fi network. This will enable automatic time synchronization and weather display.




Figure 2: The Dekala Arches offers multiple control methods including app and voice control.

### 3. OPERATING INSTRUCTIONS

#### 3.1 Setting Alarms

The alarm clock features dual programmable alarms. You can set alarms via the physical buttons on the device or through the smart app. Choose from 8 different nature sound settings for your alarm tone. The alarm can be set for specific days of the week (e.g., weekdays only, weekends, or every day).

#### 3.2 Sunrise Simulation

The gradual sunrise simulation feature brightens the light over a set period (e.g., 30 minutes) before your alarm time, mimicking a natural sunrise to gently wake you up. This feature can be synchronized with your local sunrise time via the app.




Figure 3: Gradual sunrise simulation for a gentle wake-up.

### 3.3 Sunset and Soothing Sounds

Utilize the sunset feature to gradually dim the light as you prepare for sleep. The device offers 8 different white noise and soothing sounds (e.g., white noise, brown noise, fan, waves, frog, lullaby, light music) to help you fall asleep and create a disturbance-free environment. These can be set with a sleep timer.



Figure 4: A selection of soothing sounds for improved sleep.

### 3.4 Ambient Lighting

The Dekala Arches features 9 different dynamic lighting effects and 16 million colors, allowing you to customize the ambiance of your room. Adjust brightness and color via the app or device controls.

# Many Previewable Light Options



Figure 5: Control ambient lighting and scenes through the mobile application.

## 3.5 Wireless Charging

Place your Qi-compatible smartphone on the designated wireless charging pad located on the device. The clock supports 15W Qi wireless fast-charging and also includes a 5V USB charge port to charge two devices simultaneously.

## 15W Qi Wireless Fast-Charging and 5V USB Charge

Charge 2 devices at the same time



Figure 6: Integrated wireless and USB charging capabilities.

### 3.6 Voice Control Integration

The Dekala Arches is compatible with Alexa and Google Home Assistant, allowing for convenient voice control of various functions.




Figure 7: Seamless integration with smart home voice assistants.

### 3.7 Button Operations

The device features physical buttons with voice prompts for easy operation without the app. A touch-sensitive area on top allows for quick snooze activation.

## 4. MAINTENANCE

To ensure the longevity and optimal performance of your Dekala Arches, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the alarm clock. Avoid abrasive cleaners or solvents that may damage the finish.
- **Placement:** Keep the device away from direct sunlight, excessive heat, or moisture.
- **Handling:** Handle the device with care to prevent drops or impacts that could damage internal components.

## 5. TROUBLESHOOTING

If you encounter any issues with your Dekala Arches, please refer to the following common troubleshooting steps:

- **Device Not Powering On:** Ensure the power adapter is securely connected to both the device and a working electrical outlet.
- **Wi-Fi Connection Issues:** Verify your router is broadcasting a 2.4G WiFi signal. Restart your router and the alarm clock. Ensure your mobile device is also on the 2.4G network during setup.
- **Alarm Not Sounding:** Check that the alarm is enabled and the volume is not set to zero. Confirm the correct time and days are selected for the alarm.
- **Light Not Functioning Correctly:** Adjust the brightness settings via the app or device buttons. If using auto mode, ensure ambient light conditions are appropriate.
- **Wireless Charging Not Working:** Ensure your device is Qi-compatible and properly centered on the charging pad. Remove any thick phone cases that might interfere with charging.

For further assistance, please contact Dekala customer support.

## 6. SPECIFICATIONS

Feature	Detail
Brand	Dekala
Model Number	SAC001
Color	White
Display Type	Digital

Special Feature	Adjustable Brightness, Wireless Charging, Smart Control
Product Dimensions	6.5"W x 6.5"H
Power Source	Corded Electric
Frame Material	Acrylonitrile Butadiene Styrene
Item Weight	16 ounces (1 pound)
Connectivity	2.4G WiFi, Bluetooth
Voice Assistant Compatibility	Alexa, Google Home Assistant
Country of Origin	China

### 7. WARRANTY AND SUPPORT

Dekala stands by the quality of its products and offers a **365-day warranty** for the Arches Sunrise Alarm Clock. In case of any manufacturing defects or issues covered under warranty, Dekala prioritizes replacement over repair to ensure customer satisfaction.

For warranty claims, technical support, or any inquiries, please contact Dekala customer service through their official channels. Refer to the product packaging or the quick start guide for contact information.