



[Manuals.plus](#) /

> [Amenitlif](#) /

> Amenitlif 3.2 Cu.Ft Mini Fridge with Freezer Model Z12L-PHO\_105XE8VYj7f User Manual

## Amenitlif Z12L-PHO\_105XE8VYj7f

# Amenitlif 3.2 Cu.Ft Mini Fridge with Freezer User Manual

MODEL: Z12L-PHO\_105XE8VYJ7F

## 1. Important Safety Information

---

Please read all instructions carefully before using your new Amenitlif mini fridge. Retain this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury.

- Ensure the appliance is properly grounded.
- Do not operate the appliance with a damaged power cord or plug.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the refrigerator before cleaning or performing maintenance.

## 2. Setup and Installation

---

### 2.1 Unpacking

Carefully remove all packaging materials, including foam and adhesive tape. Inspect the refrigerator for any damage. Keep packaging materials out of reach of children.

### 2.2 Placement

Place the refrigerator on a firm, level surface. Ensure there is adequate space around the unit for proper ventilation (at least 4 inches on the sides and back, and 8 inches at the top). Avoid direct sunlight or heat sources. This appliance is designed for freestanding installation only.



Image: The Amenitlif 3.2 Cu.Ft Mini Fridge with Freezer, featuring its compact design and organized interior with food and beverages.

### 2.3 Leveling

The refrigerator has adjustable leveling feet. Turn the feet clockwise to raise the unit or counter-clockwise to lower it. Ensure the refrigerator is level to prevent vibrations and ensure proper door sealing.

# PRODUCT DETAILS

More Thoughtful Details  
& More Simplified Design



Image: A detailed view of the refrigerator's features, including its dimensions, crisper drawer, removable glass partition, and adjustable leveling feet.

## 2.4 Power Connection

Plug the refrigerator into a dedicated, grounded 110V AC outlet. Do not use extension cords or adapter plugs.

## 3. Operating Instructions

### 3.1 Temperature Control

The refrigerator features a 5-level adjustable thermostat located inside the fresh food compartment. Turn the knob to select the desired cooling level. Setting '1' is the warmest, and '5' is the coldest. A setting of '3' is generally suitable for daily use.

# 5-Stage Temperature Control

Average: 42° F



Temperature Knob



LED Interior Light



Refrigerator Compartment: 32° F to 50° F



Freezer Compartment: 5° F to -4° F

Image: Illustration of the 5-stage temperature control knob and the LED interior light within the refrigerator.



Image: A close-up view of the temperature control knob, showing the numerical settings.

### 3.2 Compartment Usage

This unit includes a separate freezer compartment and a fresh food refrigerator compartment.

- **Freezer Compartment:** Ideal for storing frozen foods, ice cream, and making ice. The temperature range is approximately 5°F to -4°F (-15°C to -20°C).
- **Refrigerator Compartment:** Suitable for fresh produce, dairy, beverages, and other refrigerated items. The temperature range is approximately 32°F to 50°F (0°C to 10°C).

# Dual-zone For Freezer & Fridge

The best capacity and temperature for storing your fresh food



Image: A visual representation of the refrigerator's dual-zone design, highlighting the separate capacities and temperature ranges for the freezer and refrigeration areas.

### 3.3 Removable Shelves and Crisper Drawer

The refrigerator is equipped with removable shelves and a crisper drawer for flexible storage. To adjust or remove shelves, gently lift and pull them out. The crisper drawer can be pulled out for easy access and cleaning.



Image: A close-up view of the interior showing the removable glass shelves, designed for customizable storage.



Image: A close-up view of the transparent crisper drawer, located at the bottom of the fresh food compartment.

### **3.4 LED Interior Light**

The refrigerator compartment includes an energy-efficient LED light that illuminates when the door is opened, providing clear visibility of contents.

## **4. Maintenance**

---

### **4.1 Cleaning**

Always unplug the refrigerator before cleaning. Use a soft cloth with a mild detergent and warm water to clean the interior and exterior surfaces. Do not use abrasive cleaners, harsh chemicals, or sharp objects. The detachable door seal can be removed for thorough cleaning and then reinstalled.

### **4.2 Defrosting**

This refrigerator features an automatic defrost system for the fresh food compartment. The freezer compartment may require manual defrosting if ice buildup becomes excessive. To defrost the freezer, turn off the unit, remove all contents, and allow the ice to melt naturally. Place towels to absorb water. Do not use sharp objects to remove ice.

### 4.3 Energy Saving Tips

- Ensure the refrigerator is placed in a cool, well-ventilated area, away from direct sunlight and heat sources.
- Avoid opening the doors frequently or for extended periods.
- Allow hot foods to cool to room temperature before placing them in the refrigerator.
- Keep the door seals clean and ensure they are sealing properly.

## 5. Troubleshooting

---

If you experience issues with your refrigerator, please consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Refrigerator does not operate	Not plugged in; circuit breaker tripped; temperature control set to 'OFF' or '0'.	Check power plug; reset circuit breaker; adjust temperature control.
Temperature is not cold enough	Temperature control set too warm; door opened too frequently; warm food placed inside; poor ventilation.	Adjust temperature control to a colder setting; minimize door openings; allow food to cool before storing; ensure adequate clearance around unit.
Excessive noise	Refrigerator not level; objects touching the back or sides; normal compressor operation.	Adjust leveling feet; move objects away from the unit; some operating noise is normal.
Water on floor	Drain pan overflowing; door not sealing properly.	Check and empty drain pan; ensure door seal is clean and intact.

## 6. Specifications

---

Feature	Specification
Brand	Amenitlif
Model Number	Z12L-PHO_105XE8VYj7f
Total Capacity	3.2 Cubic Feet (90 Liters)
Refrigerator Fresh Food Capacity	2.9 Cubic Feet
Freezer Capacity	0.3 Cubic Feet
Product Dimensions (D x W x H)	22.64 x 21.85 x 37.2 inches
Item Weight	57 pounds
Voltage	110V
Installation Type	Freestanding
Defrost System	Automatic (Refrigerator), Manual (Freezer)
Number of Doors	2

Feature	Specification
Special Features	Adjustable Shelves, LED Light, Crisper Drawer

## 7. Warranty and Support

---

This Amenitlif product comes with a standard manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included with your purchase or contact Amenitlif customer service through the retailer where the product was purchased.

Please have your model number (Z12L-PHO\_105XE8VYj7f) and purchase date available when contacting support.