

Bruder 01056

Bruder MAN TGA Garbage Truck 01056 Instruction Manual

50 Years Special Limited Edition, 1:16 Scale

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bruder MAN TGA Garbage Truck, model 01056. This 1:16 scale replica offers realistic features for an engaging play experience. Please read this manual thoroughly before use to ensure proper handling and to maximize the product's lifespan.

2. SAFETY INFORMATION

WARNING: Not suitable for children under 36 months. Choking hazard due to small parts.

Always supervise children during play. Ensure all parts are securely attached before use. Keep packaging materials away from children to prevent suffocation hazards.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1x Bruder MAN TGA Garbage Truck
- 2x Wheelie Bins (assorted colors)

4. SETUP

Your Bruder MAN TGA Garbage Truck comes largely pre-assembled. Follow these steps for initial setup:

4.1 Attaching Wheelie Bins

The two included wheelie bins can be attached to the rear loader mechanism. Gently slide the bin's handle onto the designated hooks on the rear loader. Ensure they are securely seated before operating the lifting mechanism.



Figure 1: Overview of the Bruder MAN TGA Garbage Truck with attached wheelie bins.



Figure 2: Side view illustrating the placement of the wheelie bins on the truck's rear.

5. OPERATING INSTRUCTIONS

The Bruder MAN TGA Garbage Truck features several functional components designed for realistic play.

5.1 Tilting Cab

The driver's cab can be tilted forward to reveal a detailed replica of the engine block. Gently pull the cab upwards from the front until it pivots forward. To close, push the cab back down until it clicks into place.

5.2 Rubbish Collection (Rear Loader)

The rear loader mechanism is designed to simulate waste collection. Attach a wheelie bin as described in Section

4.1. Use the rotary wheel mechanism located on the side of the truck to lift and empty the bin. The contents will be transported into the press room housing via two internal spindles.



Figure 3: The rear loader mechanism in action, lifting a wheelie bin.

5.3 Emptying Cargo Compartment

To empty the collected rubbish from the truck's cargo compartment, locate the lock on the tailgate at the rear of the truck. Unlock and open the tailgate. The entire cargo compartment can then be tilted upwards to discharge its contents. After emptying, lower the compartment and securely close and lock the tailgate.



Figure 4: The cargo compartment tilted for emptying, with the tailgate open.

6. MAINTENANCE

To ensure the longevity of your Bruder MAN TGA Garbage Truck, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the truck with a damp cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the truck in a clean, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check for any loose or damaged parts. If any part is broken, discontinue use and contact customer support.

7. TROUBLESHOOTING

If you encounter any issues with your Bruder MAN TGA Garbage Truck, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Wheelie bin does not attach securely.	Bin handle not aligned correctly with hooks.	Ensure the bin handle is fully seated on the rear loader hooks.
Rear loader mechanism is stiff.	Accumulated dirt or debris.	Clean the mechanism thoroughly. Ensure no foreign objects are obstructing movement.

Problem	Possible Cause	Solution
Tailgate does not close properly.	Obstruction or misaligned lock.	Check for any debris preventing closure. Ensure the lock mechanism is free and aligned.

8. SPECIFICATIONS

- **Model Number:** 01056
- **Scale:** 1:16
- **Product Dimensions:** 20.28 x 6.89 x 9.45 inches (51.5 x 17.5 x 24 cm)
- **Item Weight:** 3.24 pounds (1.47 kg)
- **Material:** High-quality plastics (e.g., ABS)
- **Manufacturer Recommended Age:** 3 years and up
- **ASIN:** B0F246RWQ1
- **UPC:** 4001702010638

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the official Bruder website or contact your retailer. Keep your proof of purchase for any warranty claims.
Bruder Official Website: www.bruder.de

© 2025 Bruder Spielwaren. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question