#### Vormooi Q1

# Vormooi 64GB Digital Voice Recorder User Manual

Model: Q1

## 1. Introduction

Thank you for choosing the Vormooi 64GB Digital Voice Recorder. This compact and powerful device is designed to capture high-quality audio for various purposes, including lectures, interviews, meetings, and personal notes. Its intuitive design and robust features ensure reliable performance.



Figure 1.1: Vormooi 64GB Digital Voice Recorder, showcasing its compact size.

## 2. What's in the Box

- Voice Recorder x 1
- User Manual x 1
- Type-C Cable x 1
- Lanyard x 1
- Other accessories (earbuds, control keypad, USB-A to USB-C cable)



Figure 2.1: All items included with your Vormooi Digital Voice Recorder.

#### 3. Product Overview

The Vormooi Digital Voice Recorder features a durable zinc alloy metal body. Its minimalist design includes essential controls for ease of use.

#### 3.1. Components and Controls

- ON/OFF Switch: Located on the top edge, used to start and stop recording, and save files.
- Type-C Port: For charging, data transfer, and connecting the control keypad/earbuds.
- Indicator Light: Provides status feedback (e.g., recording, charging).
- Built-in Microphone: Captures audio with 1536KBPS superior sound quality.
- Control Keypad: External accessory for playback control (volume, skip tracks).



Figure 3.1: Key controls and ports on the Vormooi Digital Voice Recorder.



Figure 3.2: Detailed view of the recorder's dimensions and interfaces.

## 4. Setup

## 4.1. Charging the Device

Connect the provided Type-C cable to the recorder's Type-C port and the other end to a USB power adapter or computer. A full charge takes approximately 1.5 hours, providing about 35-40 hours of continuous recording time.

## 4.2. Attaching the Lanyard

Thread the included lanyard through the designated lanyard hole on the device. This allows for convenient carrying and helps prevent loss.



Figure 4.1: The recorder's compact size allows for easy portability and attachment to a lanyard.

#### 5. Operating Instructions

## 5.1. Recording Audio

To begin recording, simply slide the ON/OFF switch to the **ON** position. The indicator light will confirm recording has started. To stop recording and save the file, slide the switch to the **OFF** position. Files are automatically named with the date and time of recording.




Figure 5.1: One-key recording and saving for simplicity.

#### 5.2. Voice Activated Recording (VOR)

The device supports Voice Activated Recording, which saves memory and time by intelligently skipping silent periods. When enabled, the recorder will only record when sound is detected and pause when silence occurs. The sensitivity of VOR can be adjusted from 1 to 7 (0 disables VOR). Refer to the user manual for detailed instructions on adjusting this setting.



Figure 5.2: Visual representation of the Voice Activated Recording feature.

#### 5.3. Playing Back Recordings

To listen to recordings directly from the device, connect the included earbuds via the control keypad to the Type-C port. Upon connection, the device will automatically enter playback mode, starting with the most recent recording. Use the control keypad to adjust volume, skip forward, or skip backward through your recordings.

#### 5.4. Transferring Files to a Computer

Connect the recorder to your computer using either the USB-A or USB-C cable. The device will appear as a removable drive. Navigate to the "RECORD" folder to access your recorded files. You can copy, move, or delete files as needed. The device supports direct connection to Android phones, Windows, and macOS for file transfer (Note: OTG connection with iPhone is not supported).

## 5.5. Using as an MP3 Player

The recorder can also function as an MP3 player. Transfer MP3 audio files from your computer to the "RECORD" folder on the device. You can then play these files using the earbuds and control keypad.

#### 6. Maintenance

• Keep the device clean and dry. Avoid exposure to extreme temperatures or humidity.

- Do not format the recorder directly on your computer, as this may corrupt the device's internal system.
- To clear memory, delete individual recording files via your computer.
- Ensure the control keypad is not lost, as it is essential for direct playback via earbuds.

## 7. Troubleshooting

- **Device not turning on:** Ensure the battery is charged. Connect to a power source and allow it to charge for at least 15 minutes before attempting to power on.
- **No recording:** Check that the ON/OFF switch is fully in the ON position. Ensure there is sufficient memory space.
- No sound during playback: Verify that the earbuds and control keypad are securely connected to the Type-C port. Check the volume level on the control keypad.
- Files not appearing on computer: Ensure the USB cable is properly connected. Try a different USB port or cable.
- **General issues:** If you encounter any persistent issues, please contact the Vormooi support team for assistance.

## 8. Specifications

Feature	Detail
Brand	Vormooi
Model Number	Q1
Memory Storage Capacity	64 GB (approx. 900 hours of recording)
Sound Quality	1536KBPS (WAV format)
Battery Life (Recording)	35-40 hours
Full Charge Time	1.5 hours
Product Dimensions	0.25 x 1.3 x 2.2 inches
Item Weight	0.8 ounces
Hardware Interface	USB Type C
Microphone Form Factor	Built-In
Compatible Devices	Personal Computer
Country of Origin	China

## 9. Warranty and Support

Vormooi is committed to providing excellent customer service. Your product comes with:

- · Lifetime Technical Support
- 2 Years Replacement Service

• 24 Hours Hapid Hesponse (on weekdays)
If you encounter any issues or have questions, please do not hesitate to contact the Vormooi support team. We are dedicated to ensuring your satisfaction.
© 2025 Vormooi. All rights reserved.