

## Outsunny 84H-179V00LG

# Outsunny Wooden Garden Storage Cabinet User Manual

Model: 84H-179V00LG

## 1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Outsunny Wooden Garden Storage Cabinet. This cabinet is designed to offer practical storage solutions for garden tools and accessories in outdoor spaces.

The cabinet features upper and lower compartments with two removable shelves, allowing for organized and flexible storage. Its double doors are equipped with locks to ensure the security of your stored items and provide convenient access.

## 2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Ensure all components are present and undamaged before beginning assembly.
- Assembly is recommended for 1-2 persons to ensure safety and ease.
- Do not exceed the maximum recommended load of **25 kg per shelf**. Overloading can cause structural damage or injury.
- Place the cabinet on a flat, stable, and level surface to prevent tipping.
- Keep children and pets away from the assembly area.
- Regularly inspect the cabinet for any signs of wear, damage, or loose fasteners. Tighten fasteners as needed.
- This product is intended for outdoor use.

## 3. PACKAGE CONTENTS

The package contains all necessary wooden panels, hardware, and accessories required for the assembly of the Outsunny Wooden Garden Storage Cabinet. Please verify that all parts are present and undamaged before proceeding with assembly.



Image 1: Fully assembled Outsunny Wooden Garden Storage Cabinet in light grey finish.

#### 4. SETUP (ASSEMBLY)

Assembly of the Outsunny Wooden Garden Storage Cabinet is required. Follow the step-by-step instructions provided with the included hardware kit. It is recommended that 1-2 individuals perform the assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your hardware kit to identify each component.
3. **Assemble Frame:** Begin by assembling the main frame of the cabinet according to the diagrams.
4. **Install Shelves:** Insert the detachable shelves into the desired positions. These can be adjusted later.
5. **Attach Doors:** Secure the double doors to the cabinet frame using the provided hinges.
6. **Install Locking Mechanism:** Attach the locking latches to the doors for security.
7. **Final Check:** Ensure all screws and fasteners are securely tightened.



Image 2: The cabinet with its double doors open, revealing the internal shelving structure.

## 5. USAGE (OPERATING)

The Outsunny Garden Storage Cabinet is designed for efficient organization of your outdoor items.

- **Zoned Storage:** Utilize the upper and lower compartments to separate different types of tools or garden



supplies.

- **Adjustable Shelves:** The two internal shelves are detachable, allowing you to customize the storage space to accommodate items of various heights. Simply lift and reposition the shelves as needed.
- **Easy Access:** The double doors open independently, providing convenient access to either the upper or lower section without needing to open both.
- **Security:** Engage the robust locking latches on both doors to secure your tools and prevent unauthorized access.



## DOUBLES PORTES VERROUILLABLES

Peut être ouvert séparément, avec des loquets pour plus de sécurité

Image 3: Detail of the lockable latch mechanism on the cabinet door, ensuring secure storage.

## 6. MAINTENANCE

To ensure the longevity and appearance of your Outsunny Wooden Garden Storage Cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe down the cabinet regularly with a damp cloth to remove dirt and debris. Avoid harsh chemicals that may damage the wood finish.

- **Wood Treatment:** Although the cabinet is made of fir wood and is waterproof, periodic application of a wood sealant or stain designed for outdoor use can help protect the wood from UV rays, moisture, and prolong its lifespan.
- **Inspection:** Annually inspect all hardware, including hinges and latches, for rust or looseness. Tighten any loose screws and replace corroded parts if necessary.
- **Ventilation:** Ensure adequate airflow around the cabinet to prevent moisture buildup, which can lead to mold or mildew.

## 7. TROUBLESHOOTING

If you encounter any issues with your Outsunny Wooden Garden Storage Cabinet, consider the following:

- **Doors not closing properly:** Check if the cabinet is on a level surface. Inspect hinges for damage or misalignment. Ensure no items inside are obstructing the doors.
- **Stability issues:** Verify that all assembly screws are securely tightened. Ensure the cabinet is placed on a firm, level ground.
- **Water leakage:** While the product is waterproof, extreme weather conditions or prolonged exposure to standing water can affect it. Ensure proper sealing and consider additional weatherproofing if necessary.

For persistent issues, please refer to the warranty and support section.

## 8. SPECIFICATIONS

Brand	Outsunny
Model Number	84H-179V00LG
Color	Light Grey
Material	Fir Wood
Overall Dimensions (L x W x H)	60 cm x 60 cm x 160 cm
Covered Area	0.33 m²
Body Dimensions (L x W)	58 cm x 58 cm
Single Door Dimensions (L x H)	45.5 cm x 68 cm
Shelf Dimensions (L x W x H)	51 cm x 53 cm x 32.5 cm
Height from bottom to ground	9 cm
Max. Recommended Load (per shelf)	25 kg
Item Weight	23.5 kg
Water Resistance Level	Waterproof



Image 4: Dimensional diagram of the Outsunny Garden Storage Cabinet, illustrating key measurements.

## 9. WARRANTY AND SUPPORT

Information regarding product warranty and availability of spare parts is not included in this manual. For details concerning warranty coverage, spare parts, or customer support, please refer to your original purchase documentation or contact Outsunny customer service directly through their official website or the retailer where the product was purchased.

Related Documents - 84H-179V00LG

	<p><a href="#">Outsunny 84H-178V00 Outdoor Storage Cabinet Assembly Guide</a></p> <p>Comprehensive assembly instructions for the Outsunny 84H-178V00 wooden outdoor storage cabinet. Includes parts list, hardware details, and step-by-step assembly guidance.</p>
	<p><a href="#">Outsunny 84H-159V00 Outdoor Storage Cabinet Assembly Instructions</a></p> <p>Comprehensive assembly guide for the Outsunny 84H-159V00 outdoor storage cabinet. Learn how to build your garden tool shed with clear, step-by-step instructions and parts list.</p>
	<p><a href="#">Outsunny 6 x 4ft Garden Shed Parts and Assembly Guide</a></p> <p>Comprehensive parts list and assembly guidance for the Outsunny 6 x 4ft Garden Shed, a durable plastic outdoor tool shed with floor, window, and lockable door.</p>
	<p><a href="#">Outsunny 8x4 ft Metal Garden Shed Assembly Instructions</a></p> <p>Comprehensive assembly instructions for the Outsunny 8x4 ft Metal Garden Shed, including preparation, tools, safety guidelines, and maintenance tips. This guide covers all steps for a successful and safe build.</p>
	<p><a href="#">Outsunny 84H-200V01 7ft x 4ft Metal Pent Garden Shed Assembly Instructions</a></p> <p>Comprehensive assembly guide for the Outsunny 84H-200V01 7ft x 4ft Metal Pent Garden Shed. This document provides detailed step-by-step instructions, a complete parts list, and textual descriptions of diagrams for easy construction.</p>
	<p><a href="#">Outsunny 84H-164V00 Metal Outdoor Storage Shed Assembly Manual</a></p> <p>This document provides comprehensive assembly instructions, parts list, safety guidelines, and maintenance tips for the Outsunny 84H-164V00 metal outdoor storage shed. It is designed for easy assembly and long-term use.</p>

