

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Nautica](#) /
- › [Nautica Men's NCT Windrose 46.5mm Watch Instruction Manual](#)

Nautica NAPWRS501

Nautica Men's NCT Windrose 46.5mm Watch Instruction Manual

Model: NAPWRS501

1. INTRODUCTION

Thank you for choosing the Nautica Men's NCT Windrose 46.5mm Watch. This timepiece combines robust design with practical functionality, featuring a durable stainless steel case, a multifunction dial, and 100-meter water resistance. This manual provides essential information for the proper setup, operation, and maintenance of your watch to ensure its longevity and performance.



Figure 1: Front view of the Nautica NCT Windrose Watch, showcasing the blue dial and silicone strap.

2. SETUP

Before using your watch, please follow these steps to set the time and date.

2.1 Setting the Time

1. Unscrew the crown (located on the right side of the watch case) by turning it counter-clockwise until it is loose.
2. Pull the crown out to position 2 (the outermost position).
3. Turn the crown clockwise to advance the hour and minute hands until the correct time is displayed. Ensure the AM/PM is correctly set if your watch has a 24-hour indicator.
4. Push the crown back into position 0 (normal operating position) and screw it in tightly to ensure water

resistance.

2.2 Setting the Date and Day

1. Unscrew the crown by turning it counter-clockwise.
2. Pull the crown out to position 1 (the first click).
3. Turn the crown clockwise or counter-clockwise to adjust the date and day indicators. Refer to the specific sub-dial markings for day and date.
4. Once the date and day are set, push the crown back into position 0 and screw it in tightly.



Figure 2: Close-up view of the watch dial, showing the crown and multifunction sub-dials for time and date adjustment.

2.3 Strap Adjustment

The watch features an adjustable blue PU Fiber strap designed to fit various wrist sizes up to 8 inches in

circumference. Adjust the buckle to achieve a comfortable and secure fit on your wrist.

3. OPERATING YOUR WATCH

Your Nautica NCT Windrose watch is equipped with several features for daily use.

3.1 Multifunction Dial

The watch features a multifunction quartz movement with three sub-dials on the main face. These sub-dials typically display:

- **Day of the Week:** Indicates the current day (e.g., MON, TUE).
- **Date:** Displays the current numerical date.
- **24-Hour Indicator:** Shows the time in a 24-hour format, useful for distinguishing AM/PM.

The main hour and minute hands are treated with luminous infill for improved visibility in low-light conditions.

3.2 Water Resistance

This watch is water-resistant to 100 meters (330 feet). This rating means it is suitable for swimming, snorkeling, and recreational diving. However, it is **not** suitable for scuba diving. Always ensure the crown is fully screwed down before exposing the watch to water to maintain its water resistance.

Important: Do not operate the crown or pushers while the watch is wet or submerged in water.

4. MAINTENANCE

Proper care will help preserve the appearance and functionality of your Nautica watch.

4.1 Cleaning

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dirt and moisture.
- For the silicone strap, a mild soap solution and water can be used, followed by thorough rinsing and drying.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish or seals.

4.2 Water Resistance Care

- Always ensure the screw-down crown and case back are securely tightened after any adjustments or maintenance to maintain water resistance.
- Avoid exposing the watch to extreme temperature changes, which can affect the water-resistant seals.
- It is recommended to have the water resistance checked periodically by a qualified watch technician, especially after several years of use or if the watch has been subjected to impacts.



Figure 3: Rear view of the watch, highlighting the screw-down case back and the model number (NAPWRS501).

4.3 Battery Replacement

Your watch is powered by a quartz movement, which requires a battery. When the battery runs low, the watch may stop or the second hand may skip. Battery replacement should be performed by a qualified watch technician to ensure the proper sealing and water resistance are maintained.

5. TROUBLESHOOTING

If you encounter issues with your watch, refer to the following common troubleshooting steps.

5.1 Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in and screwed down. If it's pulled out, the watch will not run.
- **Battery:** The battery may need replacement. Consult a professional watch technician.

5.2 Incorrect Time or Date

- **Reset Time/Date:** Follow the instructions in Section 2 to reset the time and date.

- **Crown Position:** Ensure the crown is fully pushed in and screwed down after setting.

5.3 Condensation Under Crystal

- If condensation appears under the crystal, it may indicate a breach in the water resistance. Have the watch inspected by a qualified technician immediately to prevent further damage.

6. SPECIFICATIONS

| Feature | Detail |
|-------------------|--------------------------------|
| Model Number | NAPWRS501 |
| Case Material | Recycled (90%) Stainless Steel |
| Case Diameter | 46.5 mm |
| Case Thickness | 11.2 mm |
| Crystal | Mineral Glass |
| Movement Type | Quartz, Multifunction |
| Water Resistance | 100 Meters (330 Feet) |
| Strap Material | PU Fiber (Polyurethane) |
| Strap Width | 22 mm |
| Clasp Type | Buckle |
| Dial Color | Blue |
| Luminous Features | Hands with luminous infill |
| Item Weight | 2.5 Grams (0.09 ounces) |
| UPC | 656086112047 |

7. WARRANTY

Your Nautica NCT Windrose watch comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects under normal use. Damage resulting from improper handling, accidents, or unauthorized repairs is generally not covered.

8. SUPPORT

For further assistance, technical support, or warranty claims, please contact Nautica customer service. You can find contact information on the official Nautica website or through the retailer where you purchased the watch.

Online Resources: For additional product information and FAQs, visit the official Nautica website.

