

QW55

# Full Size Upholstered Platform Bed with Hydraulic Storage System

Model: QW55 | Brand: Generic

## PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Full Size Upholstered Platform Bed with Hydraulic Storage System, Model QW55. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.

### Key Features:

- **Additional storage space:** The hydraulic storage system underneath the mattress is perfect for you to store quilts, bed sheets and other necessities. Functional and aesthetic, this bed will enhance any bedroom.
- **Elegant Design:** Upholstered in carefully selected linen fabric, and with decorative details, this platform bed not only suits any home décor, but is timeless in its design. The soft textile bedhead creates coziness, while the single color of the design creates versatility.
- **Solid Sturdy:** The bed frame is made of pine wood and plywood, providing a dense and strong support for up to 400lbs. The construction ensures both a lifetime of use, and a sturdy bed frame with a head which won't wobble.
- **No Box Spring required:** With 24 reinforced slats, the mattress (not included) will be well supported and your body weight will be evenly distributed for a great sleeping experience. Enjoy the convenience and unparalleled ease of use that this full size wood platform bed provides. Headboard is included as a comfy linen fabric backrest that brings you and your partner a cozy feeling.



Figure 1: The Full Size Upholstered Platform Bed with its elegant gray linen fabric and decorative headboard.

## SETUP AND ASSEMBLY

Before beginning assembly, ensure all parts are present and accounted for. It is recommended to assemble the bed with at least two people. Clear a spacious area for assembly.

### Required Tools (Not Included):

- Phillips Head Screwdriver
- Allen Wrench (often included with hardware, but a personal set can be helpful)
- Rubber Mallet (optional, for gentle tapping)

### Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches. Verify all hardware and components are present against the parts list (refer to included assembly

diagram).

2. **Assemble Side Rails and Footboard:** Connect the side rails to the headboard and footboard using the provided bolts and nuts. Ensure all connections are secure but do not fully tighten until the frame is squared.
3. **Install Center Support Beam:** Attach the center support beam(s) to the frame. This provides crucial support for the slats and mattress.
4. **Attach Hydraulic Mechanism:** Secure the hydraulic lifting mechanism to the bed frame according to the diagram. Ensure the pistons are correctly oriented for smooth operation.
5. **Place Slats:** Lay the wooden slats across the bed frame. Many slats are connected by a strap; ensure they are evenly spaced. Secure them to the frame if attachment points are provided.
6. **Install Upholstery Panels:** If the bed includes separate upholstered panels for the base, attach them as per instructions, often using velcro or clips.
7. **Final Tightening:** Once the entire frame is assembled and squared, go back and fully tighten all bolts and screws.



Figure 2: The bed frame structure, showing the slat system and hydraulic mechanism before mattress placement.



Figure 3: Example of fabric attachment using velcro, often found on the base or headboard.

## OPERATING INSTRUCTIONS

---

### Using the Hydraulic Storage System:

1. **Clear the Bed:** Ensure there are no items on the bed that could fall off when the mattress is lifted.
2. **Lift the Mattress:** Grasp the designated lifting handle or edge of the bed frame (usually at the foot end). With a firm and steady motion, lift the mattress platform upwards. The hydraulic pistons will assist in the lifting, making it relatively easy.
3. **Access Storage:** Once lifted, the mattress platform will stay in the raised position, providing full access to the storage compartment underneath.
4. **Lower the Mattress:** To close, gently pull the mattress platform downwards. The hydraulic system will control the descent, preventing it from slamming shut. Ensure no hands or objects are in the way as it closes.

**Important:** Do not attempt to lift the mattress platform by yourself if it feels too heavy. Always use the designated lifting points. Avoid placing excessive weight on the lifted platform.



Figure 4: The hydraulic storage system in action, providing ample space underneath the mattress.



Figure 5: Front view of the bed with the mattress platform lifted, showcasing the full access to the storage area.

## MAINTENANCE AND CARE

### Upholstery Care:

- **Regular Cleaning:** Vacuum the fabric regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner specifically designed for upholstery. Test on an inconspicuous area first. Do not saturate the fabric.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading of the fabric.

### Frame and Hydraulic System:

- **Check Connections:** Periodically check all bolts and screws to ensure they remain tight. Retighten if necessary to prevent squeaking or instability.

- **Hydraulic Pistons:** The hydraulic pistons are generally maintenance-free. If you notice any difficulty in lifting or lowering, or unusual noises, contact customer support. Do not attempt to disassemble the pistons.
- **Slats:** Ensure all wooden slats are in place and not damaged. Replace any broken slats to maintain proper mattress support.

## TROUBLESHOOTING

| Problem                                  | Possible Cause                                       | Solution   |
|--|--|--|
| Bed Squeaks                              | Loose bolts; friction between parts.                 | Tighten all assembly bolts. Apply a small amount of lubricant (e.g., silicone spray) to contact points if necessary.                           |
| Hydraulic system difficult to lift/lower | Incorrect mattress weight; hydraulic pistons faulty. | Ensure mattress weight is within recommended limits. If problem persists, contact customer support for assistance. Do not force the mechanism. |
| Slats falling out of place               | Improper installation; damaged slat holders.         | Re-position slats correctly. Check if slat holders are damaged and replace if necessary. Ensure mattress is evenly distributing weight.        |
| Bed feels unstable/wobbly                | Loose connections; uneven floor.                     | Re-tighten all bolts. Ensure the bed is on a level surface; use shims under legs if needed.  |

## SPECIFICATIONS

**Brand:** Generic

**Model:** QW55

**Size:** Full

**Color:** Grey

**Product Dimensions (Overall):** 77.9"L x 58.8"W x 48.6"H

**Mattress Compatibility:** 75"L x 54"W (Full Size, Mattress Not Included)

**Weight Capacity:** 400 lbs

**Material:** Pine wood, Plywood, Linen Fabric

**Item Weight:** 88 pounds

**Special Feature:** Hydraulic Storage System

# SIZE: INCH




Figure 6: Detailed dimensions of the Full Size Upholstered Platform Bed.

## WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the manufacturer directly. This product is typically covered by a limited manufacturer's warranty against defects in materials and workmanship.

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact our customer support team. Details for customer support can usually be found on the product packaging or the seller's information page.

**Customer Support:** Refer to your purchase receipt or the seller's contact information for direct support.

