

Manuals.plus /

- › NOVOO /
- › NOVOO SmartCard Tracker Card (Model NFC1-207C) User Manual


NOVOO NFC1-207C

NOVOO SmartCard Tracker Card (Model NFC1-207C) User Manual

Your guide to setting up and using your NOVOO SmartCard Tracker Card.

1. PRODUCT OVERVIEW

The NOVOO SmartCard Tracker Card is a slim, durable Bluetooth tracker designed for iOS devices, integrating seamlessly with Apple's Find My network. It helps you locate personal items such as wallets, bags, and passports.




The diagram illustrates the four steps to set up the NOVOO SmartCard Tracker Card on an iPhone:


- 1** With your thumb, firmly press the center of the power button. A tune will play, then pairing mode begins.
- 2** Turn on the "Find My" app and "Bluetooth".
- 3** Turn to "Item" Page, Tap "Other Supported Item".
- 4** Connect "NOVOO Smart Tag" and named it.

The NOVOO SmartCard Tracker Card features a slim design, 6-year battery, IP68 waterproof rating, 60-80dB loud sound, Apple certification, and up to 40m/131ft Bluetooth range.

This tracker card is 1.6mm thick, comparable to two credit cards, allowing it to fit easily into wallets without adding significant bulk. It is IP68 waterproof and dust resistant, capable of withstanding submersion up to 1.5 meters for 30 minutes.



The NOVOO Tracker Card is 1.6mm thick, significantly slimmer than typical coins or other tag-type smart trackers.



The NOVOO SmartCard Tracker Card is IP68 waterproof, capable of withstanding submersion in water.

2. SETUP AND PAIRING

2.1 Initial Activation

To activate the SmartCard, firmly press the center of the power button with your thumb. A tune will play, indicating the device is powered on and entering pairing mode. If it doesn't turn on, press harder.

2.2 Pairing with Apple Find My

The NOVOO SmartCard Tracker Card is designed exclusively for iOS devices and integrates with the Apple Find My app. Ensure Bluetooth is enabled on your iOS device.

1. Open the Apple "Find My" app on your iPhone, iPad, or Mac.
2. Navigate to the "Items" tab.
3. Tap "Add New Item" and then select "Other Supported Item."
4. The app will search for nearby devices. Select "NOVOO Smart Tag" when it appears and tap "Connect."
5. Follow the on-screen prompts to name your tracker and complete the setup.



Visual guide for pairing the NOVOO SmartCard with the Apple Find My app.

Note: Android devices are not supported.



The NOVOO SmartCard is compatible with iPhone, iPad, and Mac via the Apple Find My network.

2.3 Resetting the Device

If you need to reset your NOVOO SmartCard, follow these steps:

1. Press the button on the card 5 times in quick succession until you hear three "Di-Di-Di" sounds.
2. Immediately after the three sounds, press and hold the button for 6 seconds.
3. Two "Di-Di" sounds will confirm that the reset was successful.

Video demonstrating the reset process for the NOVOO SmartCard Tracker. This video shows how to press the button 5 times and then hold it for 6 seconds to reset the device.

3. OPERATING INSTRUCTIONS


3.1 Locating Your Items

Once paired, you can locate your items using the Apple Find My app:

- **Play Sound:** If your item is within Bluetooth range (up to 131 feet or 40 meters), you can use the Find My app to make the SmartCard play an 80dB sound, helping you pinpoint its exact location.
- **View Last Known Location:** If the tracker is out of Bluetooth range, the Find My app will display its last known location on a map, utilizing the vast Apple network.
- **Get Directions:** You can get directions to the last known location of your item directly through the Find My app.

Worldwide Tracking

Hundreds of millions of Apple Find My users to locate your lost items.



The 80dB sound feature helps locate your items, even when hidden.

Anti-Tracking Protection

Receive alerts if an unknown tracker is detected with your belongings.



Use the Find My app to pinpoint and navigate to your NOVOO SmartCard.

Video demonstrating the NOVOO SmartCard's tracking capabilities, including alerts for items left behind and playing a sound to locate them.

3.2 Smart Reminder Alerts

Your iPhone will notify you if the tracker moves out of Bluetooth range, helping to prevent items from being left behind.

Privacy Protection

NOVOO Tracker works with Apple "Find My" for anonymous, encrypted data.



Receive notifications if you leave your card behind or it goes out of range.

3.3 Lost Mode

Activate Lost Mode in the Find My app to leverage Apple's network of devices. If your tracker is detected by another Apple device, you will automatically receive a notification of its location. You can also set contact details so a finder can reach you.

Apple Find My Compatible


Locate items effortlessly with Find My on iPhone, iPad, or Mac.



Note: Android devices are not supported.



Set contact details in Lost Mode so finders can reach you.



Share with Loved Ones

Share your card's location with family and friends via the "Find My" app.

Benefit from worldwide tracking through hundreds of millions of Apple Find My users.

3.4 Sharing Location

You can share your card's location with up to 5 other devices via the Find My app, allowing family or friends to help track important items.



Share your card's location with loved ones through the Find My app.

3.5 Privacy Protection

The NOVOO SmartCard uses AES-128 encryption to ensure your data remains secure. You will receive alerts if an unknown tracker is detected following you, enhancing your privacy and safety.



Receive alerts if an unknown tracker is detected with your belongings.




NOVOO Tracker works with Apple Find My for anonymous, encrypted data, ensuring privacy protection.

4. MAINTENANCE

4.1 Battery Life

The NOVOO SmartCard features a 540mAh battery designed to last up to 6 years. The battery is non-rechargeable and non-replaceable. You will receive notifications on your smartphone when the battery level drops below 20%.



The NOVOO Smart Tracker offers up to 6 years of battery life without charging or replacement.

4.2 Water and Dust Resistance

With an IP68 rating, the SmartCard is protected against dust ingress and can withstand immersion in water up to 1.5 meters (4.92 feet) for 30 minutes. This makes it suitable for various environments and accidental exposure to water.

5. TROUBLESHOOTING

- **Device Not Turning On:** If the device does not respond after pressing the power button, ensure you are pressing firmly in the center.
- **Device Not Connecting/Found:** If the SmartCard is not connecting to your iPhone or is not found in the Find My app, try resetting the device as described in Section 2.3. Ensure Bluetooth is enabled on your iOS device and the device is within range.
- **Inaccurate Location:** Location accuracy can be affected by environmental factors and obstacles. For precise location, ensure you are in an open area or close to the device.

6. SPECIFICATIONS

Feature	Detail
Brand	NOVOO
Model Number	NFC1-207C
Connectivity Technology	Bluetooth
Supported Application	Find My
Specific Uses	Personal use (wallet, luggage, personal items)
Material	Plastic
Battery Average Life	6 years
Compatible Devices	iOS device Only
Battery Capacity	540 Milliamp Hours
Item Dimensions	3.37 x 0.07 x 2.13 inches
Item Weight	12.82 Grams
Enclosure Material	Plastic

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The NOVOO SmartCard Tracker Card comes with a 2-year limited warranty. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For further assistance, technical support, or warranty inquiries, please contact NOVOO customer service through the official NOVOO website or your retailer's support channels.