

PLZOIT CB-M-L50

PLZOIT No Bottom Bar Hardware Mounted Baby Gate

Model: CB-M-L50

IMPORTANT SAFETY INFORMATION

WARNING:

- This gate is NOT suitable for drywall or plasterboard.
- Only applicable to wooden walls, concrete walls, and brick walls.
- NOT suitable for round or irregular staircases.
- Ensure that the upper and lower drilling positions of the gate wall hinges are on the same vertical plane for proper installation and safety.
- Always ensure the gate is securely latched when closed.
- Never leave children unattended near the gate.



Figure 1: Wall compatibility for installation. The gate is not compatible with drywall or plasterboard. It is suitable for brick, wooden, and concrete walls.

PRODUCT OVERVIEW

The PLZOIT No Bottom Bar Hardware Mounted Baby Gate is designed for securing stairs, doorways, and hallways. Its adjustable width and hardware-mounted design provide a secure barrier without a tripping hazard.

- **Adjustable Width:** Fits openings from 29.5 inches to 43 inches.
- **Height:** 30 inches.
- **No Bottom Bar:** Eliminates tripping hazards, ideal for stairs.
- **Auto-Close Feature:** Gate automatically closes when opened less than 90 degrees.
- **Stay-Open Feature:** Gate stays open at 90 degrees for convenient passage.
- **Dual-Swing Opening:** Swings 180 degrees in both directions.
- **One-Hand Operation:** Easy to open and close with one hand.
- **Double Lock Design:** Enhances security.
- **Material:** Durable Metal and Plastic construction.



Figure 2: The PLZOIT gate installed, demonstrating its adjustable width and 30-inch height. The image highlights the 2.0-inch gap at the latch side, which is normal before installation.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- (A) Support bars: 1
- (B) Gate Frame: 1
- (C) Hexagonal wrench: 1
- (D) Replace the screws: 4
- (E) Screw: 8
- (F) Wall Anchor: 8

Suitable for Most Openings



Figure 3: Illustrated list of all components included in the package, labeled A through F.

SETUP AND INSTALLATION

Follow these steps for secure hardware-mounted installation:

1. **Measure and Plan:** Before installation, measure your opening to ensure it is between 29.5 and 43 inches wide. Identify suitable mounting surfaces (wooden, concrete, or brick walls).
2. **Position the Gate:** Place the gate frame in the desired opening. Ensure the gate is level and centered. The gate may appear to have a gap at the latch side before installation; this is normal and will close upon tightening.
3. **Mark Drilling Points:** Hold the gate firmly against the wall. Use a pencil to mark the vertical rod holes where the mounting brackets will be installed. Ensure the upper and lower drilling positions are on the same vertical plane.
4. **Drill Holes:** Using an appropriate drill bit for your wall type, drill pilot holes at the marked positions. Insert wall anchors (F) if installing into concrete or brick.
5. **Install Vertical Rods:** Attach the support bars (A) to the wall using the screws (E).
6. **Connect Gate Frame:** Connect the main gate frame (B) to the installed support bars.
7. **Adjust and Secure:** Use the hexagonal wrench (C) to adjust the width of the gate by turning the adjustment screws. Ensure the gate fits snugly and the latch mechanism aligns properly. Tighten all screws securely.
8. **Remove Setup Tie:** If a tie was used to hold the gate together during setup, cut and remove it carefully after installation is complete.



Figure 4: Visual guide for quick installation, detailing steps from marking holes to tightening the gate.



Figure 5: The setup tie should only be cut after the gate is fully installed and secured.

OPERATING INSTRUCTIONS

Opening the Gate:

The gate features a double-lock design for enhanced safety and one-handed operation.

1. **Press:** Locate the button on the top of the latch mechanism. Press this button down.
2. **Lift:** While holding the button down, lift the gate handle upwards.
3. **Open:** Swing the gate open in either direction (180-degree dual-swing).




Figure 6: Detailed steps for opening the gate using the one-handed double-lock mechanism.

Closing the Gate:

- **Auto-Close:** If the gate is opened less than 90 degrees, it will automatically swing shut and latch securely.
- **Manual Close:** If the gate is opened past 90 degrees, gently push it until it swings back and latches.
- **Stay-Open Feature:** The gate will remain open at a 90-degree angle, allowing for continuous passage when needed.



Figure 7: Illustration of the gate's auto-close function (for openings less than 90 degrees) and stay-open feature (at 90 degrees), along with its 180-degree dual-swing capability.

MAINTENANCE

- **Cleaning:** Wipe the gate regularly with a soft, damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all mounting hardware, screws, and latch mechanisms to ensure they are secure and functioning correctly. Tighten any loose screws.
- **Lubrication:** If the gate hinges become stiff, apply a small amount of silicone-based lubricant to ensure smooth operation.

TROUBLESHOOTING

- **Gate does not close automatically:**

Ensure the gate is installed correctly and is level. Check that the mounting brackets are securely fastened and the gate is not obstructed. The auto-close feature activates when the gate is opened less than 90 degrees.
- **Gate feels loose or wobbly:**

Re-check all screws and wall anchors for tightness. Ensure the gate's width adjustment is set correctly for your opening and that the gate is firmly mounted to a suitable wall type.
- **Difficulty opening the latch:**

Ensure you are pressing the button and lifting the handle simultaneously. If the mechanism feels stiff, a small amount of lubricant may be applied to the moving parts.

SPECIFICATIONS

Feature	Detail
Brand	PLZOIT
Model Number	CB-M-L50
Adjustable Width	29.5" - 43" (74.9 cm - 109.2 cm)
Height	30" (76.2 cm)
Material	Metal, Plastic
Mounting Type	Hardware Mount
Closure Type	Button, Auto-Close
Swing Direction	180-degree Dual-Swing
Item Weight	7 Pounds (3.17 kg)

WARRANTY AND SUPPORT

For warranty information or technical support, please contact PLZOIT customer service. Keep your purchase receipt as proof of purchase.

- **Customer Service:** Refer to the contact information provided with your product packaging or visit the official PLZOIT website.
- **Product Registration:** Register your product online to receive updates and streamline warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question