Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SUKACH 5000PWPR001

SUKACH Dual Motor Power Lift Recliner Chair with Heat & Massage (Model 5000PWPR001)

Instruction Manual

Introduction

Thank you for choosing the SUKACH Dual Motor Power Lift Recliner Chair. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.



Image: The SUKACH Dual Motor Power Lift Recliner Chair, showcasing its comfortable design.

Important Safety Information

WARNING: To reduce the risk of injury, read all instructions before using this product.

- Always ensure the chair is on a stable, level surface.
- Do not exceed the maximum weight recommendation of 350 pounds.
- Use the power lift mechanism with caution, keeping hands and fingers away from moving parts.
- Always follow the assembly instructions carefully to ensure the chair is properly assembled and stable.
- Keep children and pets away from the chair's moving parts.
- Do not allow anyone to sit on the footrest when it is extended.
- Unplug the chair from the power outlet before cleaning or maintenance.

Setup and Assembly

Your SUKACH Power Lift Recliner Chair is designed for easy assembly, typically requiring only a few steps without extra tools. The chair is packed in two boxes, which may arrive separately. Please ensure you have both boxes before beginning assembly.

Unpacking the Components



Image: Components are distributed across two boxes for shipping. Box A contains the chair base and pillow. Box B contains the upholstered backrest, two armrests, phone holder, lift remote, massage remote, and power adapter.

Step-by-Step Assembly Guide

1. **Armrests Installation:** Position the armrests on either side of the chair base. Ensure the brackets on the armrests align with the corresponding slots on the chair base. Push down firmly until they click into place.
2. **Backrest Installation:** Carefully slide the upholstered backrest onto the metal brackets at the rear of the chair base. Ensure it is fully seated and secured.

3. **Cable Connections:** Locate the various cables for the power, lift, and massage functions. Connect the cables by matching the same colors (e.g., white to white, red to red). Connect the power adapter to the chair's power input and then plug it into a wall outlet.
4. **Phone Holder Installation:** Insert the goose-neck phone holder into the designated port on the armrest.

For a visual guide, please refer to the assembly video below:

Your browser does not support the video tag.

Video: This video demonstrates the step-by-step assembly process for the SUKACH Power Lift Recliner Chair, including connecting the armrests, backrest, and electrical components.

Operating Instructions

Your SUKACH recliner offers multiple features for enhanced comfort and convenience. Familiarize yourself with the remote controls and functions.

Dual Motor System and Infinite Position Adjustment

The recliner features a dual-motor system, allowing independent adjustment of the backrest and footrest. This enables you to find your most comfortable position, with a maximum reclining angle of 173 degrees. The power lift function assists users in standing up effortlessly.



Image: The recliner's dual motor system allows for various positions, including napping, watching TV, reading, and assisted standing.

Preset Positions

The lift remote control includes preset positions for convenience:

- **TV Mode:** Adjusts the chair to an optimal viewing position.
- **Sleep Mode:** Lays the chair flat for comfortable rest.
- **Home Button:** Returns the chair to an upright position.
- **Memory Button:** Allows you to customize and save your favorite position.

Detachable Armrests & Cup Holder

The armrests are detachable, secured by Velcro straps and snap buttons. Removing the armrest tops creates a wider space, ideal for sitting cross-legged or napping. A retractable cup holder tray table is located on the left side; press the button at the bottom to lift or retract it.




Image: Detachable armrests provide flexibility for wider seating or napping. The image also shows the cup holder tray.

Charging Ports & Phone Holder

The right side of the recliner features two charging ports (one USB and one Type-C) for low-power devices. A bendable, 360-degree rotatable, and detachable goose-neck phone holder is also installed on the same side, providing hands-free convenience.

Massage & Heating Functions

The massage chair includes 8 vibrating nodes across the back, lumbar, thigh, and leg areas. It offers 3 intensity options and 4 different vibrating modes. Additionally, there is one lumbar heating point that operates independently from the massage function, providing full-body relaxation and pain relief.



Image: The recliner features 8 vibrating massage nodes and a lumbar heating function, controlled by a remote.

Watch the display video for a demonstration of the recliner's features:

Your browser does not support the video tag.

Video: This video showcases the various features and operational modes of the SUKACH Power Lift Recliner Chair, including reclining, lifting, and massage functions.

Maintenance

To ensure the longevity and optimal performance of your SUKACH recliner, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the textile fabric.
- **Regular Inspection:** Periodically check all connections and moving parts to ensure they are secure and functioning correctly.
- **Power Cord Care:** Ensure the power cord is not pinched or damaged. Keep it away from high-traffic areas.

Troubleshooting

If you encounter any issues with your SUKACH Power Lift Recliner Chair, please consider the following common solutions:

- **Chair Not Responding:** Ensure the power adapter is securely plugged into both the chair and a working wall outlet. Check if the power switch on the chair (if present) is in the 'ON' position.
- **Remote Control Issues:** Verify that the remote control cables are properly connected to the chair's internal wiring.
- **Unusual Noises:** Inspect the reclining mechanism for any obstructions. Ensure all assembly connections are tight.

If the problem persists after attempting these steps, please contact customer support for further assistance.

Specifications

Feature	Detail
Brand	SUKACH
Model Name	Power Lift Chair (Model 5000PWPR001)
Color	Gray (Textile)
Product Dimensions	28.74"D x 40.16"W x 45.28"H
Size	Large
Maximum Weight Recommendation	350 Pounds
Material	Textile, Sponge Fill
Special Features	Dual Motor Power Lift System, Separately Adjustable Backrest & Base, 360° Rotatable Phone Holder & Charging Ports (1 USB, 1 Type-C), Cup Holder Tray Table & Storage Bags, Detachable Arm Rests, Lumbar Heating, 8-Point Vibrating Massage
Reclining Position Count	4 (including infinite adjustment)
Item Weight	125 pounds
Product Care Instructions	Wipe Clean



Image: Detailed dimensions of the SUKACH Power Lift Recliner Chair.

Warranty and Support

SUKACH provides the following warranty for your recliner chair:

- **1-Year Warranty:** Covers upholstery materials and electric parts.
- **2-Year Warranty:** Covers the chair frame and reclining mechanisms.

For any warranty claims, technical support, or further inquiries, please feel free to contact us via Amazon. Our customer service team is ready to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F298KKFV

More documents and user manuals: **https://manuals.plus/**