

XFHDHR deng17546yapin

XFHDHR Juicer Push Rod Instruction Manual

Compatible with Braun J500 and 4293 Juicers

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your XFHDHR Juicer Push Rod. This accessory is designed to be compatible with Braun J500 and 4293 juicer models, ensuring efficient and safe juicing. Please read these instructions carefully before use.

2. PRODUCT OVERVIEW

The XFHDHR Juicer Push Rod is a replacement accessory designed to guide fruits and vegetables into the juicer's feeding chute. It is constructed from durable plastic material, engineered to withstand the pressure required during the juicing process.

- **Efficient Juice Extraction:** Designed to help your juicer process ingredients effectively.
- **Durable Construction:** Made from high-quality plastic for longevity and resilience.
- **Ergonomic Design:** Shaped to fit securely and comfortably in the juicer's feeding port.
- **Pressure Resistance:** Capable of withstanding the force applied when pushing food.



Figure 2.1: Full view of the XFHDHR Juicer Push Rod. This image shows the complete push rod, illustrating its cylindrical shape and the top handle.



Figure 2.2: Close-up of the bottom end of the XFHDHR Juicer Push Rod. This image highlights the textured, perforated surface designed to safely push ingredients into the juicer's mechanism.

3. SETUP

The XFHDHR Juicer Push Rod is designed for easy integration with compatible Braun juicer models. Follow these steps for proper setup:

1. **Ensure Juicer is Off:** Before installing or removing any parts, always ensure your Braun juicer is unplugged from the power outlet for safety.
2. **Identify Feeding Port:** Locate the feeding port (chute) on the upper cover of your Braun J500 or 4293 juicer.
3. **Insert Push Rod:** Gently insert the XFHDHR Juicer Push Rod into the feeding port. It should fit snugly without excessive force. The design ensures a proper fit to prevent accidental contact with moving parts.
4. **Verify Fit:** Confirm that the push rod sits correctly within the feeding port, allowing for smooth up-and-down movement.

4. OPERATING INSTRUCTIONS

Once the push rod is correctly installed, you can proceed with juicing. Always prioritize safety during operation.

1. **Prepare Ingredients:** Wash and cut fruits and vegetables into appropriate sizes that fit comfortably into the juicer's feeding port.
2. **Power On Juicer:** Plug in your Braun juicer and turn it on according to its manufacturer's instructions.
3. **Feed Ingredients:** Place prepared ingredients into the feeding port.
4. **Use Push Rod:** Use the XFHDHR Juicer Push Rod to gently and steadily push the ingredients down into the juicer's mechanism. *Do not apply excessive force or use any other object to push food.* The push rod is specifically designed for this purpose.
5. **Continue Juicing:** Repeat the process until all ingredients are juiced.
6. **Power Off Juicer:** After juicing, turn off and unplug the juicer before disassembling or cleaning.

5. MAINTENANCE

Regular cleaning and proper care will extend the life of your XFHDHR Juicer Push Rod.

- **Cleaning:** After each use, remove the push rod from the juicer. Wash it with warm, soapy water. Rinse thoroughly to remove any food residue.
- **Drying:** Allow the push rod to air dry completely or wipe it with a clean cloth before storing.
- **Storage:** Store the push rod in a clean, dry place, preferably with your juicer accessories.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or harsh chemical detergents, as these can damage the plastic material.

6. TROUBLESHOOTING

The XFHDHR Juicer Push Rod is a simple accessory, and issues are typically related to its fit or general juicer operation.

- **Push Rod Does Not Fit:**
Action: Ensure your juicer is a Braun J500 or 4293 model. Verify that the push rod is oriented correctly. Do not force the rod into the feeding port.
- **Difficulty Pushing Ingredients:**
Action: Ensure ingredients are cut to an appropriate size. Do not overfill the feeding port. Apply steady, gentle pressure rather than sudden force.
- **Push Rod Appears Damaged:**
Action: Discontinue use immediately. A damaged push rod could pose a safety risk or affect juicer performance. Replace with a new, undamaged push rod.

7. SPECIFICATIONS

Attribute	Value
Brand	XFHDHR
Model Number	deng17546yapin
Compatible Juicer Models	Braun J500, Braun 4293
Material	Plastic
Item Weight	1.76 ounces (50 Grams)
Package Dimensions	1.18 x 0.79 x 0.39 inches
Number of Pieces	1

8. WARRANTY AND SUPPORT

Specific warranty information for this XFHDHR Juicer Push Rod is not provided in the product details. For any inquiries regarding product defects or compatibility, please contact the retailer or manufacturer directly through their official support channels. Always refer to your original Braun juicer manual for warranty and support related to the main appliance.