

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ChunHee](#) /

› [ChunHee Dog Door Bell Instruction Manual](#)

ChunHee CC27

ChunHee Dog Door Bell Instruction Manual

Model: CC27

PRODUCT OVERVIEW

The ChunHee Dog Door Bell system is an innovative solution designed to facilitate potty training and enhance communication between you and your canine companion. This system includes a plug-in receiver and two durable, battery-free buttons, making it a convenient and eco-friendly choice for pet owners. It is particularly well-suited for larger dogs, generally those weighing 20 lbs or more, due to the pressure required to activate the buttons.



Image: The complete ChunHee Dog Door Bell system, showing the receiver and two pressure-activated buttons, with a dog demonstrating interaction.

PACKAGE CONTENTS

- 1 x ChunHee Dog Door Bell Receiver
- 2 x ChunHee Dog Door Buttons (No Batteries Required)
- Installation Hardware (e.g., adhesive pads)
- Instruction Manual

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Receiver Placement:** Plug the receiver into a standard electrical outlet in a central location within your home, ensuring the sound can be easily heard throughout the desired area.
3. **Button Placement:**
 - Identify suitable locations for the two dog buttons. These can be on a door frame, glass, or floor, depending on your dog's size and preferred method of interaction.

- Ensure the buttons are placed where your dog can easily press them with their paw or nose.
- Use the provided installation hardware (e.g., adhesive pads) to securely mount the buttons.

A Doorbell That Is More Suitable for Big Dogs (20 lbs. or More)



It is not suitable for small dogs. It requires a certain amount of pressure to press the transmitter



No Batteries Needed



Easy to Install



Large-sized Dog Training



Potty Training

Image: A dog demonstrating how to press the button. The buttons are designed for easy installation and do not require batteries.

4. **Initial Pairing (Pre-paired):** The buttons are pre-paired with the receiver from the factory. No manual pairing is typically required for initial use.

OPERATING INSTRUCTIONS

The ChunHee Dog Door Bell system offers adjustable volume, multiple ringtones, and voice options to suit your preferences and aid in training.

Adjusting Volume and Ringtones




Image: Detailed diagram showing the controls on the receiver and the button's press area, along with dimensions and ringtone cycle time settings.

- **Volume Control:** The receiver has a dedicated volume button. Each press cycles through 5 levels of volume, ranging from silent (0 dB) to loud (110 dB).
- **Ringtone Selection:** Use the "Previous Tone" and "Next Tone" buttons on the receiver to cycle through the 32 available ringtones and voice options.
- **Voice Options:** Available voice options include practical commands such as "outside," "come back," "play," and "hungry." These can be particularly useful for specific training commands.




Image: The receiver displaying musical notes and a list of available voice commands, highlighting the variety of sounds.

- **Indicator Light:** The receiver features an LED indicator light that illuminates when a button is pressed, providing a visual alert.
- **Ringtone Cycle Time:** The system allows for adjustment of how long the ringtone plays (e.g., once for 8 seconds, twice for 16 seconds, or 100 times for 12 minutes). Refer to the provided diagram for specific settings.

POTTY TRAINING GUIDE

This system is an effective tool for teaching your dog to communicate their need to go outside. Consistency and positive reinforcement are crucial for successful training.

Your Furry Friend Needs It!



Potty Training

Go Outside

Enhance Communication with Your Dog

Build Self-Discipline

Image: A dog using the doorbell, illustrating its benefits for potty training and communication.

- 1. Introduce the Button:** Place the button near the door your dog typically uses to go outside for potty breaks.
- 2. Associate with Going Out:** Every time you take your dog out for a potty break, gently guide their paw to press the button. As they press it, clearly say a command like "Outside" or "Potty."
- 3. Immediate Reward:** As soon as the button is pressed and the sound plays, immediately open the door and take your dog outside. Praise them enthusiastically and offer a treat once they relieve themselves outside.
- 4. Consistency:** Repeat this process consistently. Your dog will begin to associate pressing the button with going outside.
- 5. Encourage Independent Use:** Once your dog starts to understand, wait for them to initiate pressing the button on their own. If they nudge it or show interest, encourage them to press it fully.
- 6. Coming Back In:** You can also use a second button for your dog to signal they want to come back inside. Follow a similar training process.

Know at any time that your pet needs to go outside or come back




Image: The system allows dogs to signal both when they need to go outside and when they want to come back in.

7. **Patience:** Training takes time and patience. Some dogs learn faster than others. Avoid scolding if mistakes happen.
8. **Suitable for Larger Dogs:** Please note that the buttons require a certain amount of pressure to activate, making them more suitable for dogs weighing 20 lbs or more.

MAINTENANCE

- **Cleaning:** Wipe the receiver and buttons with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Button Care:** While the buttons are IP55 rated waterproof and weatherproof, avoid prolonged exposure to direct sunlight or heavy rain to ensure longevity.
- **No Battery Replacement:** The dog buttons are designed to be battery-free and do not require battery replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doorbell not ringing	Receiver unplugged or power outage	Ensure receiver is securely plugged into a working electrical outlet.

Problem	Possible Cause	Solution
Doorbell not ringing	Button not pressed firmly enough	Ensure your dog applies sufficient pressure to the button. This system is designed for dogs over 20 lbs.
Doorbell not ringing	Button out of range of receiver	Ensure the button is within effective range of the receiver. Large obstacles or thick walls may reduce signal range.
Sound is too loud/quiet	Volume setting is incorrect	Press the volume button on the receiver to adjust to your desired level.
Incorrect ringtone playing	Ringtone selection is incorrect	Use the "Previous Tone" or "Next Tone" buttons on the receiver to select the desired ringtone or voice option.

SPECIFICATIONS

- Model:** CC27 (CH-CC27WH-AT01WH 2-1)
- Brand:** ChunHee
- Item Weight:** 6.7 ounces
- Package Dimensions:** 4.29 x 3.15 x 3.03 inches
- Volume Levels:** 5 (0-110 dB)
- Ringtones/Voice Options:** 32
- Button Type:** Pressure-activated, battery-free
- Waterproof Rating (Buttons):** IP55
- Target Audience:** Dogs (recommended for dogs over 20 lbs)

WARRANTY AND SUPPORT

This ChunHee Dog Door Bell system comes with a **1 Year Manufacturer Warranty**.

For technical support, troubleshooting assistance, or warranty claims, please contact ChunHee customer service through the retailer where you purchased the product. Please retain your proof of purchase for warranty purposes.

Related Documents - CC27

	<p><u>ChunHee Wireless Intercom User Manual and Specifications</u></p> <p>User manual, technical specifications, and warranty information for the ChunHee wireless intercom system. Details operation, features, and product specs.</p>
	<p><u>ChunHee Wireless Intercom System User Guide</u></p> <p>Instructions for using the ChunHee Wireless Intercom System, covering setup, pairing, usage scenarios, and important notes for effective two-way communication.</p>

	<p><u>ChunHee HI05 Wireless Intercom User Manual - Features, Specifications, and Operation Guide</u></p> <p>Comprehensive user manual for the ChunHee HI05 Wireless Intercom. Learn about its features, specifications, setup, operation, and troubleshooting for clear and reliable communication up to 1640ft.</p>
	<p><u>ChunHee WT26 Wireless Intercom User Manual Features, Specs, Operation</u></p> <p>Comprehensive user manual for the ChunHee WT26 Wireless Intercom. Learn about its features, specifications, operation, troubleshooting, and FCC compliance. Features 16 channels, VOX hands-free, 1640ft range, and more.</p>
	<p><u>ChunHee HI03 Wireless Intercom System User Manual</u></p> <p>Comprehensive user manual for the ChunHee HI03 Wireless Intercom system, detailing features, operation, specifications, troubleshooting, and customer support for this 16-channel, 1640ft range intercom.</p>
	<p><u>ChunHee CK01 Wireless Queue Calling System User Manual</u></p> <p>User manual for the ChunHee CK01 Wireless Queue Calling System. This guide details features, specifications, setup, operation, and customer service for the CK01 queue management system.</p>