

Ear Clip Headphones

User Manual: Earbuds Pro Wireless Bluetooth Open Ear Earbuds

Brand: Generic | Model: Ear Clip Headphones

INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your Earbuds Pro Wireless Bluetooth Open Ear Earbuds. Designed for comfort and awareness, these earbuds feature an open-ear design, Bluetooth 5.2 connectivity, and a durable, water-resistant build. Please read this manual thoroughly before using your earbuds to ensure optimal performance and longevity.



Image: Overview of the Earbuds Pro, showing the charging case, the earbuds themselves, and the LED display on the case.

WHAT'S INCLUDED

Please verify that all items listed below are present in your package:

- Earbuds Pro (Left and Right)
- Charging Case
- Charging Cable
- User Manual (this document)

SETUP GUIDE

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features an LED intelligent display to show battery levels.

1. Place the earbuds into the charging case. Ensure they are correctly seated.

2. Connect the charging cable to the charging port on the case and to a USB power source.
3. The LED display on the case will indicate charging status. A full charge takes approximately 40 minutes for the earbuds.



Image: Close-up of the Earbuds Pro charging case displaying battery levels for both left and right earbuds, and the case itself.

2. Bluetooth Pairing

The Earbuds Pro utilize Bluetooth 5.2 for fast and stable connections.

1. Ensure the earbuds are charged and removed from the charging case. They will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
3. Search for available devices and select "Earbuds Pro" (or similar name) from the list.
4. Once connected, a voice prompt or indicator light on the earbuds will confirm successful pairing.
5. The earbuds support seamless switching between two paired devices.

Bluetooth V5.2 chip

Upgrade Bluetooth 5.2 chip for faster and more stable connection, clearer and smoother listening to music and playing games




Image: Internal view of an earbud highlighting the Bluetooth V5.2 chip, indicating advanced connectivity.

3. Wearing the Earbuds

These open-ear earbuds are designed for comfortable, pain-free wear, allowing you to remain aware of your surroundings.

1. Gently place the earbud over your ear, ensuring the clip rests securely on your ear cartilage.
2. Adjust the position for a comfortable and stable fit. The design avoids direct insertion into the ear canal.

Make You To Decrypt Painless Wear

- In-ear design
- Ear buckle support



Image: Illustration demonstrating the ear clip design for painless wear, highlighting its secure fit without entering the ear canal.

Healthy design, Not in-ear

Wearing Long time without pain



S03 not in-ear

○ pressure and no pain
Never fall off while exercising



In-ear earphone

Pressure on the ear causing pain
Fall off when exercising

Image: A visual comparison illustrating the "not in-ear" healthy design of the Earbuds Pro against a traditional in-ear earphone, emphasizing comfort and lack of pressure.

OPERATING INSTRUCTIONS

The Earbuds Pro are designed for intuitive use. While specific button controls are not present on the earbuds themselves, control is primarily managed through your connected device or a dedicated app (if available).

Basic Functions (via Connected Device)

- **Power On/Off:** Earbuds typically power on automatically when removed from the case and power off when returned to the case.
- **Play/Pause:** Control playback directly from your connected audio source (e.g., phone's music player).
- **Volume Control:** Adjust volume using your connected device's volume buttons.
- **Call Management:** Answer, end, or reject calls using your connected device's call interface.

For advanced features or customized settings, check if a companion application is available for download on your device's app store, as indicated by the "Control Method: App" specification.



Image: The Earbuds Pro in black, demonstrating their secure fit when worn, suitable for sports and active use.

MAINTENANCE AND CARE

Proper care will extend the lifespan of your Earbuds Pro.

- **Cleaning:** Wipe the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The earbuds are "Life waterproof," meaning they are resistant to sweat and light rain. Do not submerge them in water or expose them to strong jets of water. Dry them thoroughly before placing them back in the charging case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Battery Care:** Avoid fully depleting the battery frequently. Charge regularly to maintain battery health.

life waterproof



Image: The Earbuds Pro charging case and earbuds shown on a wet surface, demonstrating their "life waterproof" capability.

TROUBLESHOOTING

If you encounter issues with your Earbuds Pro, try the following solutions:

Problem	Possible Solution
Earbuds do not pair with device.	<ul style="list-style-type: none">◦ Ensure earbuds are fully charged.◦ Make sure Bluetooth is enabled on your device.◦ Forget "Earbuds Pro" from your device's Bluetooth list and attempt to re-pair.◦ Restart your device and try pairing again.

Problem	Possible Solution
Only one earbud is working.	<ul style="list-style-type: none"> ◦ Ensure both earbuds are charged. ◦ Place both earbuds back into the charging case, close the lid for a few seconds, then remove them to reset the connection. ◦ Re-pair the earbuds with your device.
No sound or low volume.	<ul style="list-style-type: none"> ◦ Increase the volume on both your connected device and the earbuds (if app control allows). ◦ Ensure earbuds are properly connected to your device. ◦ Try playing different audio sources.
Charging case LED display is not working.	<ul style="list-style-type: none"> ◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Try a different charging cable or power adapter.

SPECIFICATIONS

Feature	Detail
Model Name	Ear Clip Bone Conduction Headphones
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.2
Transmission Distance	Approx. 10 meters (32.81 ft)
Endurance (Battery Life)	8 hours (earbuds), up to 32 hours with charging case
Charging Time	Approx. 40 minutes (earbuds)
Battery Capacity	300mA (charging bin), 35mA (headphone)
Water Resistance Level	Life waterproof
Control Method	App
Compatible Devices	Smartphones, Tablets, Laptops, Bluetooth-enabled Devices
Audio Driver Type	Bone Conduction Driver
Ear Placement	Open Ear
Noise Control	Active Noise Cancellation (as per specifications, though not a primary feature in description)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller/manufacturer directly. Keep your proof of purchase for any warranty claims.

No official product videos from the seller were available for embedding in this manual.

© 2025 Generic. All rights reserved.