

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Wkzay](#) /
- › [Wkzay SM-07 Sunrise Alarm Clock with Noise Machine User Manual](#)

## Wkzay SM-07

# Wkzay SM-07 Sunrise Alarm Clock with Noise Machine

## USER MANUAL

### Introduction

---

The Wkzay SM-07 Sunrise Alarm Clock with Noise Machine is designed to enhance your sleep and wake-up experience. This device combines a natural sunrise simulation, a wide selection of soothing sounds, and adjustable lighting to promote a gentle transition into and out of sleep. It also functions as a digital clock, night light, and features convenient charging ports.

### Safety Information

---

- Always unplug the device when not in use.
- Do not use the device if the power cord or plug is damaged.
- Keep the device dry.
- Do not expose the device to extreme temperatures.
- Do not use the device for more than 8 hours at a time to avoid noise exposure.
- This device is not a toy and should not be used as such.
- Always follow the instructions provided with the device.

### Package Contents

---

- Wkzay SM-07 Sunrise Alarm Clock with Noise Machine
- Power Adapter (5V, 2A)
- USB-C Cable
- User Manual

### Product Overview

---

The Wkzay SM-07 features intuitive controls and a sleek design. Below is an overview of its components and controls.



Figure 1: Front view of the Wkzay SM-07 Sunrise Alarm Clock, displaying the time and light panel.

## Top Panel Controls

- **Snooze/Selector Switch:** Press to snooze alarm; rotate to select options.
- **RGB Light Button:** Activates and cycles through RGB light modes.
- **Main Light Button:** Turns on/off the main light and adjusts brightness.
- **Alarm Setup Buttons:** Set and manage up to two alarms.
- **Volume Control:** Adjusts sound volume.

## Rear Panel Ports

- **USB-A Port:** For charging external devices (e.g., smartphones).
- **USB-C Port:** For powering the alarm clock.
- **Speakers:** Output for alarm tones, nature sounds, and Bluetooth audio.

## Setup

### 1. Powering On

1. Connect the provided USB-C cable to the USB-C port on the rear of the device.

2. Plug the other end of the USB-C cable into the power adapter.
3. Plug the power adapter into a wall outlet. The digital display will illuminate.

## 2. Setting the Time

1. Press and hold the 'Time Set' button (usually located near the main dial). The hour display will begin to flash.
2. Rotate the main dial (snooze/selector switch) to adjust the hour.
3. Press the main dial down to confirm the hour and move to setting the minutes.
4. Rotate the main dial to adjust the minutes.
5. Press the main dial down to confirm the minutes and move to setting the day of the week.
6. Rotate the main dial to select the correct day.
7. Press the main dial down to confirm and exit time setting mode.

## Operating Instructions


### 1. Sunrise Simulation Wake-Up

The alarm clock simulates a natural sunrise, gradually increasing light intensity before your set alarm time to gently wake you.

# Wake Up Gently with a Gradual Sunrise


 Sunrise brightness  
1-12 Levels

 Sunrise duration  
10-60 Minutes



  
6:00 AM



  
6:30 AM



  
7:00 AM

Figure 2: Illustration of the gradual sunrise simulation over time.

1. When setting an alarm (see 'Alarm Settings' below), you can choose the duration for the sunrise simulation (e.g., 10-60 minutes).
2. The light will gradually brighten from a dim red to a bright white over the selected duration before your alarm sounds.

## 2. Alarm Settings

The device supports setting up to two independent alarms.

1. Press and hold one of the 'Alarm Setup' buttons (Alarm 1 or Alarm 2). The hour display will flash.
2. Rotate the main dial to set the desired hour. Press the dial to confirm.
3. Rotate the main dial to set the desired minutes. Press the dial to confirm.
4. You will then be prompted to select an alarm tone (from 30 options) and the wake-up light brightness level (1-20). Rotate the main dial to cycle through options and press to confirm each selection.
5. Finally, set the sunrise simulation duration (10-60 minutes) or disable it.
6. To activate/deactivate an alarm, short press the corresponding 'Alarm Setup' button. An alarm icon will appear/disappear on the display.

## 3. Snooze Function


When an alarm sounds, tap the top of the device (snooze-selector switch) to activate the 9-minute snooze function.



Figure 3: Hand tapping the top of the alarm clock to activate snooze.

## 4. Soothing Sounds for Sleep & Focus

Choose from 30 relaxing sounds, including nature sounds (birdsong, ocean, rain, stream, campfire) and white noise variations (white, pink, brown noise, fan sound).



# 30 non looping sounds

Delivers a restful night's sleep by blocking out noise and masking distractions

Figure 4: Visual representation of various sound options available.

1. Short press the 'Music Note' button to turn on/switch nature sounds.
2. Short press the 'Sound Wave' button to turn on/switch white noises.
3. Rotate the 'Volume Control' dial to adjust the sound volume (30 levels).
4. Long press the 'Music Note' or 'Sound Wave' button to turn off sounds.

## 5. Sleep Timer & Sunset Wind-Down Mode

The sleep timer allows you to set a duration after which the light and sound will gradually fade out.

# Fall Asleep Faster with Sunset Simulation



Figure 5: Illustration of the sunset simulation helping a user fall asleep.

1. Press the 'Sleep Timer' button (often integrated with other controls) to activate the timer.
2. Cycle through available durations (e.g., 30, 60, 90 minutes) by pressing the button.
3. The light and/or sound will gradually decrease and turn off after the set time.
4. Hold the 'Sleep Timer' button to turn off the sleep timer.

## 6. Night Light & RGB Lighting

The device functions as a multi-use night light with adjustable brightness and color options.

1. Short press the 'Main Light' button to turn on the main light. Continue pressing to cycle through 13 brightness levels.
2. Short press the 'RGB Light' button to activate RGB color modes. Continue pressing to cycle through various colors and a color-changing mode.
3. Long press the 'Main Light' or 'RGB Light' button to turn off the respective light.

## 7. Dimmable LED Display

The digital time display can be dimmed manually for a light-free sleeping environment.

1. During normal operation, short press the 'Dimmer' button (often integrated with 'Time Set') to cycle through different display brightness levels.

2. Select the desired brightness, including an option to turn the display off completely.

## 8. Bluetooth Connectivity

The alarm clock can connect to your smartphone or other Bluetooth-enabled devices to play audio.

1. Activate Bluetooth on your external device.
2. The alarm clock will automatically enter Bluetooth pairing mode when no other audio is playing.
3. Select 'Wkzay SM-07' (or similar device name) from your device's Bluetooth list to pair.
4. Once paired, you can play audio through the alarm clock's speakers.

## Maintenance

---

- Clean the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Ensure the device is unplugged before cleaning.
- Avoid blocking the speaker grilles to maintain optimal sound quality.

## Troubleshooting

---

- **Device not powering on:** Ensure the USB-C cable is securely connected to both the device and the power adapter, and the adapter is plugged into a working outlet.
- **Time/Alarm not saving:** The device has an internal battery to retain settings during power outages. If settings are not saved, ensure the device has been powered on for a sufficient period to charge the internal battery.
- **Sound not working:** Check the volume level. Ensure no other audio source (e.g., Bluetooth) is actively playing and interfering.
- **Bluetooth pairing issues:** Ensure the device is in pairing mode and within range of your external device. Try restarting both devices.

## Specifications

---

- **Product Dimensions:** 3.74 x 3.74 x 7.08 inches; 15.2 ounces
- **Item Model Number:** SM-07
- **Batteries:** 1 LR44 batteries required (included)
- **Brand:** Wkzay
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Power Source:** Corded Electric
- **Color:** Wood Grain

## Warranty and Support

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact Wkzay customer service directly. Protection plans may be available for extended coverage.

## Official Product Video

---

Your browser does not support the video tag.

Video 1: An official overview of the Wkzay White Noise Sound Machine with Sunrise Alarm Clock, demonstrating its features and functionality.

