KARDV V06

KARDV V06 Cordless Vacuum Cleaner Instruction Manual

Model: V06

Introduction

Thank you for choosing the KARDV V06 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.



Figure 1: KARDV V06 Cordless Vacuum Cleaner with various attachments.

Setup and Assembly

Your KARDV V06 Cordless Vacuum Cleaner comes with several components designed for versatile cleaning. Follow these steps to assemble your vacuum and prepare it for use.

Included Components

- Cordless Vacuum Cleaner Main Unit

- Battery Pack
- Adjustable Extension Tube
- V-Shape Anti-tangle Flexible Floor Brush
- 2-in-1 Crevice Tool
- Long Crevice Nozzle
- Sofa Flat Brush
- 2 HEPA Filters (one pre-installed, one spare)
- Hair Cleaning Tool
- Charger
- Wall-mounted Bracket
- Manual Instructions

Assembly Instructions

1. **Attach the Extension Tube:** Align the adjustable extension tube with the main vacuum cleaner unit and push until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the V-shape anti-tangle flexible floor brush to the other end of the extension tube. Ensure it clicks firmly.
3. **Install Battery:** Insert the battery pack into the designated slot on the main unit until it locks.

Charging the Battery

Before first use, fully charge the battery. The KARDV V06 offers convenient charging options:

- **Direct Charging:** Plug the charger directly into the battery pack.
- **Wall-Mounted Charging:** Install the provided wall-mounted bracket in a convenient location. The vacuum can be charged while stored on the wall mount.



Figure 2: Wall-mounted charging station for convenient storage and charging.

A full charge typically takes approximately 4 hours. The Smart LED Display will indicate the charging status.

Operating Instructions

Power Modes and LED Display

The KARDV V06 features a sensitive button touch sensor system and a colorful smart LED display for easy control and monitoring.

- **Power On/Off:** Press the power button on the main unit to turn the vacuum on or off.

- **Adjust Suction Power:** Touch the screen to cycle between two adjustable suction power levels:
  - **Min Mode:** Provides up to 60 minutes of runtime for lighter cleaning tasks.
  - **Max Mode:** Delivers 40Kpa powerful suction for 20-25 minutes for deep cleaning.
- **Monitor Status:** The LED display shows important information such as the current suction mode, remaining battery power, and a brush winding reminder.



Figure 3: Smart LED Display for real-time vacuum status.

Cleaning Different Surfaces

The V-shape anti-tangle flexible floor brush is designed for effective cleaning across various floor types.

- **Hard Floors:** The soft bristles and powerful suction efficiently pick up dust, debris, and pet hair without scratching delicate surfaces.
- **Carpets:** The V-shape design and strong suction are effective at lifting embedded dirt and pet hair from carpets.
- **LED Headlights:** The upgraded green LED light on the floor brush illuminates hidden dirt and dust in dark areas, such as under furniture, ensuring thorough cleaning.




Figure 4: LED headlights on the flexible floor brush for enhanced visibility.

Using Multi-functional Accessories

The 8-in-1 multi-functional accessories allow you to convert your cordless vacuum into a versatile handheld cleaner for various tasks.

- **2-in-1 Crevice Tool:** Ideal for narrow gaps, corners, and upholstery.
- **Long Crevice Nozzle:** Perfect for reaching deep into tight spaces like sofa crevices or car seats.
- **Sofa Flat Brush:** Designed for cleaning fabrics, pet cushions, and curtains.



Figure 5: KARDV V06 configured as a handheld vacuum with attachments.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your KARDV V06 Cordless Vacuum Cleaner.

Emptying the Dust Cup

The 1.5L large dust cup features a one-touch emptying design, minimizing contact with dirt.

1. Position the dust cup over a trash bin.
2. Press the one-touch release button on the dust cup to open the bottom flap and empty the contents.
3. Close the flap securely after emptying.



Figure 6: One-touch dust cup emptying process.

Cleaning the Filters

The multi-layer filtration system includes washable HEPA filters to prevent secondary air pollution.

1. Remove the dust cup from the main unit.
2. Twist and pull out the HEPA filter from the dust cup.
3. Rinse the HEPA filter under running water until clean.
4. Allow the filter to air dry completely for at least 24 hours before re-installing. Do not use the vacuum with a wet filter.



Figure 7: Step-by-step guide to cleaning the HEPA filter.

Anti-Tangle Roller Brush Maintenance

The V-shape anti-tangle roller brush minimizes hair entanglement. If necessary, use the provided hair cleaning tool to remove any wrapped hair or debris.

1. Turn off the vacuum and detach the floor brush.
2. Locate the release mechanism for the roller brush (usually a latch or button on the side of the brush head).
3. Remove the roller brush.
4. Use the hair cleaning tool to cut and remove any tangled hair or fibers.
5. Reinsert the roller brush and secure the release mechanism.

Specifications

Feature	Detail
Brand	KARDV
Model Name	KARDV V06
Suction Power	40Kpa (MAX mode)
Motor Power	500W
Battery Life	Up to 60 minutes (Min mode), 20-25 minutes (Max mode)
Dust Cup Capacity	1.5 Liters
Filter Type	HEPA Filter
Special Features	Anti-tangle design, Smart LED Display, Flexible green light LED floor brush, Wall-mounted charging
Product Dimensions	11"L x 7"W x 16"H
Item Weight	5 pounds
Power Source	Battery Powered

Troubleshooting

If you encounter any issues with your KARDV V06 Cordless Vacuum Cleaner, please refer to the following common solutions:

- **No Power:** Ensure the battery is fully charged and correctly installed. Check the charger connection.
- **Reduced Suction:** Empty the dust cup. Clean or replace the HEPA filter. Check the roller brush for any obstructions or tangles. Ensure all connections are secure.
- **Brush Not Rotating:** Check the LED display for a brush winding reminder. Remove any tangled hair or debris from the roller brush. Ensure the brush head is correctly attached.
- **Unusual Noise:** Turn off the vacuum immediately. Check for any foreign objects lodged in the brush head, extension tube, or dust cup.

For further assistance, please contact KARDV customer support.

Warranty and Support

KARDV products are designed for quality and reliability. For warranty information, product registration, or technical support, please refer to the contact details provided in your product packaging or visit the official KARDV website. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why has the brush on my KARDV V06 cordless vacuum stopped rotating even though the vacuum is running and the brush has been cleaned?

If the brush on your KARDV V06 has stopped rotating while the motor is running and you have already cleaned it, please check the following troubleshooting steps based on the manual:Check the LED Display:...

Read full answer