**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## JieSuDa SQQ-64G Card

# JieSuDa 2K Full HD WiFi Security Camera (Model: SQQ-64G Card) Instruction Manual

Brand: JieSuDa | Model: SQQ-64G Card

## Introduction

This instruction manual provides detailed guidance for the installation, operation, and maintenance of your JieSuDa 2K Full HD 2.4Ghz WiFi Security Camera. This camera offers advanced features such as 2K ultra-clear spotlight color night vision, stable dual-band WiFi, flexible storage options, smart AI human detection, and seamless integration with smart home devices for comprehensive security monitoring.

## What's in the Box

- JieSuDa 2K Full HD WiFi Security Camera
- Instruction Manual
- Mounting Screws
- Power Adapter
- 64GB SD Card (pre-installed or included)




Image: All components included in the product package.

## Setup and Installation

### 1. Physical Installation

The JieSuDa security camera is designed for versatile installation, suitable for both indoor and outdoor environments. It features a unique dual-lens design that can be configured for various mounting scenarios, including flat surfaces or 90-degree corners.

1. **Choose a Location:** Select a mounting location that provides optimal coverage and a stable surface. Ensure the location is within range of your Wi-Fi network and has access to a power outlet.
2. **Prepare the Mounting Surface:** For flat surfaces, align the camera's base and mark the screw holes. For 90-degree corner installations, adjust the camera's two heads to form a corner shape and mark the appropriate screw points.
3. **Drill Pilot Holes:** Use a drill to create pilot holes at the marked locations. If mounting into drywall or other non-stud material, insert the provided wall anchors before screwing.
4. **Secure the Camera:** Attach the camera to the surface using the provided mounting screws. Ensure it is firmly secured.

5. **Connect Power:** Plug the power adapter into the camera and then into a power outlet. The camera will power on, indicated by an LED light.
6. **Insert SD Card:** Locate the SD card slot, typically protected by a rubber cover. Insert the provided 64GB SD card into the slot until it clicks. Ensure the cover is securely closed to maintain waterproofing.




Image: The camera installed on a corner, demonstrating its adaptable design.




Image: Illustration of flexible installation methods for the camera.

### 2. App Download and Pairing

To access and control your camera, download the official JieSuDa app on your smartphone (compatible with Android and Apple HomeKit). Follow the in-app instructions to create an account and pair your camera. The app will guide you through connecting the camera to your 2.4GHz or 5GHz Wi-Fi network.

Your browser does not support the video tag.

Video: Official JieSuDa video demonstrating the setup process and key features of the 2K Full HD Security Camera.

## Operating Instructions

### Live View and Controls

Once paired, you can access the live feed from both camera lenses via the app. The app provides controls for pan, tilt, and zoom (PTZ) functionality, allowing you to adjust the viewing angle as needed. The dual-lens design offers a wide 270-degree field of view, eliminating blind spots.




Image: Live view of the camera feed on a smartphone.




Image: Dual lens providing two angle views.

## Night Vision and Spotlight

The camera features 2K ultra-clear spotlight color night vision, capturing clear and vibrant color images even in complete darkness. It also includes a built-in light that can illuminate the area upon motion detection, enhancing visibility and acting as a deterrent.




Image: Smart night vision capabilities with color, infrared, and floodlight options.

## Motion Detection and Alerts

Advanced AI algorithms accurately identify human figures, filtering out animals, vehicles, and insects to reduce false alarms. You will receive real-time notifications on your smartphone when motion is detected, ensuring you are aware of important events.





Image: Intelligent Humanoid Detection with automatic rotation tracking.

## Two-Way Audio

Utilize the built-in microphone and speaker for two-way audio communication. This allows you to speak to visitors or deter intruders directly through the camera via the app.

## Storage Options

The camera supports both local storage via the included 64GB SD card and cloud storage services (subscription may be required after an initial trial). This enables 24/7 continuous video recording, allowing you to review important moments at any time.




Image: Flexible storage options including SD card and cloud storage.

### Smart Home Integration

The camera is fully compatible with Amazon Alexa and Google Home smart devices. Use simple voice commands to effortlessly control and access your camera's features.

## Maintenance

- **Cleaning:** Regularly wipe the camera lenses and body with a soft, damp cloth to remove dust and debris. Avoid using harsh chemicals that could damage the device.
- **SD Card Management:** Periodically check the SD card for storage capacity. Back up important recordings and format the card as needed to ensure continuous recording.
- **Firmware Updates:** Check the app regularly for firmware updates to ensure your camera has the latest features and security enhancements.
- **Power Connection:** Ensure the power connection remains secure and free from damage, especially for outdoor installations.

## Troubleshooting

- **No Power:** Check the power adapter and ensure it is securely plugged into both the camera and a working power outlet. Verify the LED indicator on the power cable is lit.
- **Wi-Fi Connectivity Issues:** Ensure your Wi-Fi router is working correctly and the camera is within range. Try restarting your router and the camera. Confirm you are connecting to a 2.4GHz or 5GHz network as supported.
- **App Pairing Failure:** Ensure your smartphone's Bluetooth and Wi-Fi are enabled. Follow the app's instructions carefully, including any reset procedures for the camera if necessary.
- **Poor Video Quality:** Check your Wi-Fi signal strength. Ensure the camera lens is clean and free from obstructions. Adjust the video quality settings in the app if your network bandwidth is limited.

- **Motion Detection Not Working:** Verify that motion detection is enabled in the app settings. Adjust sensitivity levels and detection zones to suit your environment.
- **SD Card Not Recording:** Ensure the SD card is correctly inserted and formatted within the app. Check if the card is full or corrupted. Consider replacing the SD card if issues persist.

## Specifications

| | |
|---|---|
| **Brand** | JieSuDa |
| **Model Name** | SQQ-64G Card |
| **Video Capture Resolution** | 1440p (2K Full HD) |
| **Connectivity Technology** | Wired, Wireless (Wi-Fi 2.4Ghz & 5Ghz) |
| **Special Features** | 2-Way Audio, Built-In Light, Motion Sensor, Night Vision (Spotlight Color), PTZ Technology |
| **Indoor/Outdoor Usage** | Indoor, Outdoor |
| **Compatible Devices** | PC, Smartphone (Amazon Alexa, Android, Apple HomeKit) |
| **Power Source** | Corded Electric |
| **Mounting Type** | Wall Mount |
| **Included Components** | Instruction Manual, Mounting Screw, Power Adapter, 64GB SD Card |
| **Product Dimensions** | 6.3 x 6.3 x 4 inches |
| **Item Weight** | 1.7 Pounds |
| **Video Capture Format** | AVI |

## Warranty and Support

For warranty information and technical support, please refer to the contact details provided in the packaging or visit the official JieSuDa website. Keep your purchase receipt for warranty claims.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0F2BDR769**

More documents and user manuals: **https://manuals.plus/**