

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [TOPPERFUN](#) /
- › [TOPPERFUN Coffee Carafe Lid Replacement User Manual](#)

TOPPERFUN QT06K17FV4649P9GR5MT

TOPPERFUN Coffee Carafe Lid Replacement User Manual

Model: QT06K17FV4649P9GR5MT

PRODUCT OVERVIEW

The TOPPERFUN Coffee Carafe Lid Replacement is engineered to provide a secure and efficient seal for your thermal coffee kettle, ensuring extended heat retention and a consistent beverage temperature. Constructed from durable PP material, this lid is designed for both home and restaurant environments, offering a practical and long-lasting solution for worn-out or damaged carafe lids.



Figure 1: The TOPPERFUN Coffee Carafe Lid Replacement. This image displays the overall design of the lid, featuring its black body and red pour lever.

Key Features:

- **Extended Heat Retention:** Keeps coffee hot for prolonged periods, maintaining ideal serving temperature.
- **Simple and Practical Design:** Suitable for various settings, offering straightforward functionality.
- **Durable Construction:** Made from safe and robust PP material for longevity.
- **Secure Closure:** Features a strong, precise seal to prevent leaks and maintain insulation.

WHAT'S IN THE BOX

- 1 x Coffee Carafe Lid Replacement

SPECIFICATIONS

Attribute	Value
Product Dimensions	3.94 x 3.15 x 1.97 inches
Item Weight	1.92 ounces
Model Number	QT06K17FV4649P9GR5MT
Manufacturer	TOPPERFUN
Material	PP (Polypropylene)

SETUP AND INSTALLATION

This section guides you through the proper installation of your new coffee carafe lid.

- 1. Remove Old Lid:** Carefully remove the existing lid from your coffee carafe. If the old lid is stuck, gently twist and pull.
- 2. Inspect Carafe Opening:** Ensure the rim of your coffee carafe is clean and free from any debris or residue that might prevent a proper seal.
- 3. Align New Lid:** Place the new TOPPERFUN carafe lid onto the opening of your carafe. Ensure the lid is centered.
- 4. Secure the Lid:** Gently press down and twist the lid clockwise until it feels secure and forms a tight seal. Do not overtighten.
- 5. Test Seal:** With the carafe empty, fill it with a small amount of water and tilt it to check for any leaks around the lid. If leaks occur, re-adjust the lid.



Figure 2: Dimensions of the TOPPERFUN Coffee Carafe Lid. This image illustrates the height (5cm/1.97in) and width (8cm/3.14in) of the lid, providing visual guidance for compatibility.



Figure 3: Underside of the Lid. This close-up shows the robust sealing rings designed to ensure a strong, leak-proof connection with your carafe.

OPERATING INSTRUCTIONS

Using your TOPPERFUN Coffee Carafe Lid is straightforward. Follow these steps for optimal performance:

1. **Filling the Carafe:** Remove the lid by twisting counter-clockwise and lifting. Fill your carafe with your desired hot or cold beverage. Do not overfill.
2. **Securing the Lid:** Place the lid back onto the carafe and twist clockwise until it is firmly sealed. Ensure the pour spout mechanism is in the closed position to maintain temperature.
3. **Pouring:** To pour, locate the red lever or button on the top of the lid. Press or push this mechanism to open the pour spout. Pour your beverage slowly and steadily.
4. **Closing After Pouring:** Release the lever or button to close the pour spout immediately after pouring. This helps to maintain the beverage's temperature and prevent spills.



Figure 4: Ergonomic Design. This image shows the lid comfortably held in a hand, highlighting its compact and user-friendly size for easy handling.



Figure 5: Versatile Placement. The lid is shown on a kitchen counter, demonstrating its seamless integration into various kitchen environments.



Figure 6: Ready for Brewing. The lid is positioned on a coffee machine, indicating its readiness to be used with your freshly brewed coffee.



Figure 7: Controlled Pouring. This image demonstrates the smooth and controlled pouring action when the lid is properly installed on a carafe.



Figure 8: Pour Mechanism. This diagram clearly shows how to activate the pour function by pressing the red button, allowing for easy dispensing of liquids.

MAINTENANCE AND CARE

Proper maintenance will extend the life of your TOPPERFUN Coffee Carafe Lid and ensure its continued performance.

- **Regular Cleaning:** After each use, rinse the lid thoroughly with warm water.
- **Deep Cleaning:** For a more thorough clean, use mild dish soap and a soft sponge or brush. Pay attention to the sealing rings and the pour mechanism to remove any coffee residue.
- **Drying:** Allow the lid to air dry completely before reattaching it to the carafe or storing it. This prevents mold or mildew buildup.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or harsh chemicals, as these can damage the PP material and sealing components.
- **Dishwasher Safety:** While the PP material is generally durable, hand washing is recommended to preserve the integrity of the sealing rings and internal mechanisms over time.

TROUBLESHOOTING

If you encounter any issues with your coffee carafe lid, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lid leaks when pouring.	Lid not properly sealed; sealing rings are dirty or damaged.	Ensure the lid is twisted on tightly. Remove the lid, clean the sealing rings and carafe rim, then re-attach. Inspect rings for damage; if damaged, replacement may be needed.
Pour spout is stuck or difficult to press.	Coffee residue buildup in the mechanism.	Rinse the lid thoroughly with warm water, focusing on the pour mechanism. Use a small brush if necessary to dislodge any debris.
Beverage does not stay hot/cold.	Lid not sealed correctly; pour spout left open.	Verify the lid is securely twisted onto the carafe. Always ensure the pour spout is closed immediately after dispensing.

WARRANTY AND SUPPORT

This product is designed for durability and performance. For specific warranty information or support inquiries, please refer to the retailer or manufacturer's official website where the product was purchased. Keep your purchase receipt as proof of purchase.

© 2025 TOPPERFUN. All rights reserved.
For more information, visit [the product page](#).