Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOPET W03

WOPET Wireless Pet Water Fountain Instruction Manual

Model: W03 | Brand: WOPET

Introduction

The WOPET Wireless Cat Water Fountain (Model W03) is a stylish and functional ceramic pet water dispenser designed to provide fresh, clean water for your cats and dogs. Featuring a 3-liter capacity and a powerful 5000 mAh battery, this ultra-quiet fountain ensures your pets stay hydrated with minimal refilling and maintenance. Its wireless design offers flexible placement options throughout your home.



Image: The WOPET Wireless Cat Water Fountain, showcasing its sleek design and compact size.

Setup

Setting up your WOPET Wireless Cat Water Fountain is a straightforward process. Follow these steps for proper assembly and initial use:

1. **Unpack Components:** Carefully remove all parts from the packaging. You should have the main ceramic bowl, the pump unit, filter, and the top cover with the flower spout.
2. **Insert Filter:** Place the filter into its designated slot within the pump unit. Ensure it is seated correctly for optimal filtration.
3. **Assemble Unit:** Place the pump unit into the main ceramic bowl. Then, position the top cover securely over the bowl, aligning the spout with the pump.
4. **Fill with Water:** Fill the ceramic bowl with fresh, clean water up to the indicated maximum fill line. The 3L capacity allows for extended use between refills.
5. **Connect Power:** Plug the charging cable into the designated port on the base of the fountain. Ensure the cable is

routed through the provided channel to prevent tangling.

6. **Power On:** Press the power button to activate the fountain. The indicator lights will confirm operation.

Your browser does not support the video tag.

Video: A demonstration of the WOPET Wireless Cat Water Fountain setup process, including assembly and initial water filling.



Image: Disassembled components of the WOPET fountain, highlighting its easy-to-clean design.

Operating Instructions

The WOPET Wireless Cat Water Fountain offers flexible operation modes to suit your pet's needs and conserve energy.

Dual Water Modes:

- **Induction Mode:** This mode utilizes an advanced radar sensor to detect your pet within 5 feet (150cm). The

fountain will dispense water for 20 seconds only when a pet is sensed, preserving battery life and encouraging hydration.

- **Continuous Flow Mode:** For constant water availability, select this mode. The fountain will continuously circulate water, ensuring fresh water is always accessible.




Image: Visual representation of the Induction Mode and Continuous Flow Mode.

Battery Life & Charging:

The fountain is equipped with a powerful 5000 mAh rechargeable built-in battery. In timer mode (Induction Mode), a single full charge can continuously supply fresh water for up to 30 days. The easily removable battery section simplifies recharging without needing to move the entire product.




Image: Illustration highlighting the 30-day battery life and 5000mAh capacity.

Ultra-Quiet Operation:

The advanced flow structure of the WOPET fountain significantly reduces noise, operating at a whisper-quiet 30dB. This ensures a peaceful environment for both you and your pets.



Image: A graphic illustrating the ultra-quiet operation of the WOPET fountain compared to other common sounds.

Maintenance

Regular maintenance is crucial to ensure the longevity and hygienic operation of your WOPET Wireless Cat Water Fountain.

Cleaning:

The ceramic body and components are designed for easy cleaning. Disassemble the fountain as shown in the setup section. Wash all parts (except the base, which is not washable) with mild soap and water. Rinse thoroughly to remove any soap residue.



Image: Disassembled components of the WOPET fountain in a sink, demonstrating ease of cleaning. Note: The base is not washable.

Filter System:

The fountain utilizes an upgraded WOPET filter with a circulation filtration system to provide pure, fresh water. This multi-filtering system includes:

- Removal of larger food scraps and hair.
- Coconut Shell Activated Carbon to filter out odors and chlorine.
- Microporous Cotton Filter to filter out large residue hair and debris.

Regular replacement of the filter is recommended to maintain water quality. The fountain also features low water and low battery reminders to alert you when attention is needed.



Image: Diagram illustrating the multi-layer filtration system of the WOPET fountain.

Troubleshooting

If you encounter any issues with your WOPET Wireless Cat Water Fountain, please refer to the following common troubleshooting tips:

- **Fountain Not Dispensing Water:**
  - Check if the fountain is powered on and fully charged.
  - Ensure the water level is above the minimum line.
  - Verify that the pump unit is correctly installed and not obstructed.
  - Clean the pump and filter to remove any debris that might be blocking water flow.
- **Unusual Noise:**
  - Check the water level; low water can cause pump noise.

- Ensure all components are securely assembled and not vibrating.
- Clean the pump for any trapped debris or mineral buildup.

- **Water Quality Issues (e.g., odor, cloudiness):**
  - Replace the filter as per recommended schedule.
  - Thoroughly clean all parts of the fountain.
  - Use fresh, clean water.

- **Battery Not Holding Charge:**
  - Ensure the charging cable is properly connected to both the fountain and a power source.
  - Allow sufficient time for a full charge (approximately 5 hours for a fast charge).
  - If issues persist, contact customer support.

Specifications

Brand	WOPET
Model Name	W03
Item Weight	8.14 pounds
Item Package Dimensions L x W x H	11.34 x 11.26 x 7.72 inches
Material	Ceramic
Color	White Orange
Capacity	3 Liters (101 oz)
Power Source	Battery Powered (5000 mAh)
Batteries Required	1 C battery (built-in)
Specific Uses for Product	Indoor

Warranty

The WOPET Wireless Cat Water Fountain comes with a**1-Year Warranty**. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the product packaging or contact WOPET customer service.

Customer Support

For any questions, concerns, or technical assistance regarding your WOPET Wireless Cat Water Fountain, please contact WOPET Customer Service. WOPET is committed to providing 24-hour customer service to ensure your satisfaction.
Visit the official WOPET store or website for contact information and additional resources.

© 2025 WOPET. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2DKYCND

More documents and user manuals: **https://manuals.plus/**