

Uvital LD-265

Uvital Big Button Phone for Seniors

Model: LD-265

Brand: Uvital

INTRODUCTION

The Uvital Big Button Phone for Seniors, Model LD-265, is designed for ease of use, particularly for elderly individuals or those with visual or hearing impairments. It features large, high-contrast buttons, two programmable one-touch speed dial keys, and a dedicated SOS emergency button. The phone also includes an adjustable ringer and handset volume, along with a visual ringing indicator to ensure important calls are not missed. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting.



Image: Front view of the Uvital Big Button Phone for Seniors, showcasing its large, clearly labeled buttons, M1, SOS, and M2 speed dial keys, and the handset.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- 1 x Uvital Big Button Phone (Model LD-265)
- 1 x Handset
- 1 x Handset Cord
- 1 x Phone Line Cord
- 1 x User Manual



Image: Diagram showing the phone, handset, handset cord, phone line, and user manual, with their respective dimensions.

PRODUCT FEATURES

- **Large, High-Contrast Buttons:** Oversized buttons with clear numbering for easy visibility and dialing.
- **2 One-Touch Speed Dial Keys (M1, M2):** Programmable buttons for quick access to frequently called numbers.
- **SOS Emergency Button:** A dedicated button for immediate dialing of a pre-programmed emergency contact.
- **Adjustable Volume:** Ringer volume (LO-HI, up to 120dB) and handset volume (MED-HI-VHI) can be adjusted to suit user preference.
- **Visual Ringing Indicator:** A bright LED light flashes during incoming calls, providing a visual alert.
- **No Battery Required:** Operates solely on phone line power, eliminating the need for batteries or external power adapters.

Office Starts Here

Founded in 2017, Uvital is a very strong office equipment and landline accessories sales company.

We have an extensive product line and a professional production team dedicated to bringing more complete, more efficient, better quality products and service to every consumer.

Image: Detailed view highlighting the large buttons, M1/M2 speed dial keys, SOS button, and the visual ringing indicator.

SETUP INSTRUCTIONS

Follow these steps to set up your Uvital Big Button Phone:

1. **Connect the Handset:** Plug one end of the coiled handset cord into the handset and the other end into the designated port on the side of the phone base.
2. **Connect the Phone Line:** Plug one end of the phone line cord into the 'LINE' port on the back of the phone base. Plug the other end into your wall telephone jack.
3. **Verify Connection:** Lift the handset. You should hear a dial tone, indicating a successful connection.

Correctly Insert the Lines



Image: Visual guide demonstrating the correct insertion of the handset cord and the phone line into their respective ports on the phone.

OPERATING INSTRUCTIONS

Making a Call

1. Lift the handset.
2. Dial the desired phone number using the large numeric keypad.
3. Wait for the call to connect.
4. To end the call, place the handset back on the cradle.

Receiving a Call

1. When the phone rings and the LED indicator flashes, lift the handset to answer the call.
2. To end the call, place the handset back on the cradle.

Programming Speed Dial Keys (M1, M2)

The M1 and M2 buttons allow for one-touch dialing of stored numbers.

1. Lift the handset.
2. Press the **STORE** button.
3. Dial the phone number you wish to save (up to 16 digits).
4. Press the **STORE** button again.
5. Press either **M1** or **M2** to assign the number to that key.
6. Place the handset back on the cradle to save.

Note: Do not unplug the phone line after programming, as this may result in the loss of stored contact numbers.

Using the SOS Emergency Button

The SOS button is pre-programmed to dial a specific emergency number. This number must be programmed following the speed dial instructions above, assigning it to the SOS button.

1. Lift the handset.
2. Press the **SOS** button.
3. The phone will automatically dial the pre-programmed emergency number.

2 One-Touch Dial Keys & SOS Key



After the storage is finished, pick up the receiver and press M key to dial out.

Image: A detailed view of the M1, SOS, and M2 buttons, indicating their function for one-touch dialing.

Adjusting Volume

The phone features adjustable ringer and handset volumes:

- **Ringer Volume:** On the side of the phone base, locate the switch labeled 'RINGER'. Slide it to 'LO' for low volume or 'HI' for high volume (up to 120dB).
- **Handset Volume:** On the side of the phone base, locate the switch labeled 'HANDSET VOLUME'. Slide it to 'MED' for medium, 'HI' for high, or 'VHI' for very high volume.



Image: A close-up of the side of the phone, showing the physical switches for adjusting ringer volume (LO-HI) and handset volume (MED-HI-VHI).

Visual Ringing Indicator

The phone is equipped with a bright LED light that flashes when there is an incoming call. This feature provides an additional visual alert, which is particularly useful in noisy environments or for individuals with hearing difficulties.

Visual Ringing Indicator



The telephone lights up for incoming calls, so you never miss important ones.

Image: The phone on a table, with a red LED light flashing to indicate an incoming call, demonstrating the visual ringer feature.

MAINTENANCE

To ensure the longevity and proper functioning of your Uvital Big Button Phone, follow these maintenance guidelines:

- **Cleaning:** Wipe the phone's surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cord Care:** Avoid tangling or excessive pulling of the handset and line cords to prevent damage.
- **Power Source:** Since the phone is line-powered, ensure the phone line connection is secure and free from damage.

TROUBLESHOOTING

If you encounter any issues with your Uvital Big Button Phone, refer to the following troubleshooting tips:

Problem	Possible Cause	Solution
No dial tone	Phone line not connected or damaged.	Ensure the phone line is securely plugged into both the phone and the wall jack. Test with another phone if possible.
Cannot hear caller / Caller cannot hear me	Handset volume too low; Handset cord loose or damaged.	Adjust the handset volume switch. Check if the handset cord is securely connected.
Phone does not ring	Ringer volume set to 'LO'; Phone line issue.	Adjust the ringer volume switch to 'HI'. Verify phone line connection.
Speed dial numbers lost	Phone line was unplugged.	Reprogram the speed dial numbers. Avoid unplugging the phone line.

SPECIFICATIONS

- **Model Number:** LD-265
- **Product Dimensions:** 1 x 1 x 1 inches
- **Item Weight:** 1.21 pounds (0.55 Kilograms)
- **Brand:** Uvital
- **Color:** White
- **Telephone Type:** Corded
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Power Source:** Corded Electric (Phone Line Powered)
- **Dialer Type:** Single Keypad
- **Answering System Type:** Digital
- **Multiline Operation:** Single-Line Operation

WARRANTY AND SUPPORT

Uvital is committed to providing quality products and customer satisfaction. For any questions, technical support, or warranty inquiries regarding your Uvital Big Button Phone, please contact Uvital customer service.

- **Technical Support:** Assistance with product setup, operation, and troubleshooting.
- **Returns & Replacements:** Information regarding product returns or replacement procedures.



Image: An infographic detailing Uvital's customer care services, including 24/7 quick reply, technical support, fast delivery, and returns & replacements.

© 2025 Uvital. All rights reserved.