Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LUXOAK BMB011+CNS004

LUXOAK 3 Piece King Size LED Bed Frame with 2 Drawers and 2 Nightstands Instruction Manual

Model: BMB011+CNS004

Introduction

Thank you for choosing the LUXOAK 3 Piece King Size LED Bed Frame with 2 Drawers and 2 Nightstands. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new bedroom set. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

Always follow the assembly instructions carefully to avoid injury. Keep sharp edges away from children and ensure drawers are securely closed when not in use. Do not exceed the weight limit of the bed frame and drawers to prevent tip-over risks. Ensure all electrical connections for the LED lights and charging stations are properly secured and conform to local electrical codes. Do not overload the charging ports.

Package Contents

Your LUXOAK 3 Piece Bedroom Set will arrive in two separate packages, which may be delivered on different days. Please verify all components are present before beginning assembly.

- King Size LED Bed Frame (Components for headboard, frame, slats, and 2 storage drawers)
- 2 Nightstands with Integrated Charging Stations
- Assembly Hardware (screws, bolts, tools)
- LED Remote Control
- Instruction Manuals for Bed Frame and Nightstands

Setup and Assembly

Assembly typically takes approximately 90 minutes. It is recommended to have two people for assembly. Ensure you have adequate space and a clean, flat surface to work on. All parts are numbered for easy identification.

General Assembly Steps:

1. Unpack all components and lay them out, checking against the parts list in the included detailed instructions.
2. Begin by assembling the bed frame according to the specific instructions provided in the bed frame manual. This typically involves attaching side rails, support legs, and then the headboard and footboard.
3. Install the metal bed slats onto the frame, ensuring they are securely fastened.
4. Assemble the two under-bed storage drawers, then slide them into position under the bed frame.
5. Assemble each nightstand following its dedicated instruction manual. This usually involves attaching the legs, assembling the drawer components, and installing the charging station unit.
6. Connect the LED light strips to the headboard and plug in the power adapter.
7. Plug in the power cords for the headboard and nightstand charging stations into appropriate wall outlets.



Figure 1: Overall view of the LUXOAK 3 Piece Bedroom Set, showing the King size LED bed frame with drawers and two nightstands with charging stations.



Figure 2: Detailed view of the bed frame structure, illustrating the robust metal slats for mattress support.



Figure 3: Bed frame with two storage drawers pulled out, showing ample space for clothing and other essentials, with smooth bottom rollers for easy access.

Operating Instructions

LED Bed Frame Lighting:

The integrated LED lights in the headboard offer multiple customization options:

- **Control:** Use the included remote control or a compatible smartphone application to manage the lighting.
- **Colors:** Choose from 20 different LED colors to match your mood or decor.
- **Dynamic Effects:** Select from 19 dynamic lighting effects for an enhanced ambiance.
- **Adjustment:** Adjust the brightness and speed of effects with 10-level adjustment settings.



Figure 4: King size LED bed frame with RGB lighting, illustrating remote control, 10-level adjustment speed, 19 dynamic effects, 20 colors, and app control options.

Integrated Charging Stations:

Both the headboard and the two nightstands are equipped with convenient charging stations.

- **Headboard Charging Station:** Features 2 standard AC outlets (110V/12A) and 2 USB ports (5V/3A). It has a 6.5-foot power cord.
- **Nightstand Charging Stations:** Each nightstand includes 2 standard AC outlets (125V/12A) and 2 USB ports (5V/2.1A). Each nightstand has a 4.9-foot power cord.
- **Usage:** Simply plug your devices into the available outlets or USB ports to charge. Ensure the power cords for the charging stations are plugged into a functional wall outlet.



Figure 5: Detailed view of the headboard's integrated charging station, showing two AC outlets, two USB ports, and a 6.5-foot power cord.



Figure 6: Close-up of a nightstand's charging station, highlighting two AC outlets, two USB ports, and a 4.9-foot power cord.

Maintenance

Cleaning:

- For the bed frame and nightstands, wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- The PU headboard surface is smooth and easy to clean. Use a mild soap solution if necessary, then wipe dry.
- Dust the LED lights and charging ports regularly with a dry cloth to prevent accumulation.

General Care:

- Periodically check all screws and bolts to ensure they remain tight. Retighten as needed to maintain structural integrity.
- Avoid placing excessively hot or wet items directly on the nightstand surfaces without protection.

- Do not drag the furniture when moving; lift it to prevent damage to legs and floor.



Figure 7: Illustration of the PU headboard material, highlighting its smooth and easy-to-clean surface, and the 11.8-inch under-bed clearance for additional storage.

Troubleshooting

Problem	Possible Cause	Solution
LED lights not turning on	Power adapter unplugged; Remote battery dead; Loose connection.	Ensure power adapter is securely plugged into an outlet and the LED strip. Replace remote battery. Check all cable connections.
Charging station not working	Power cord unplugged; Wall outlet not functional; Device cable faulty.	Verify the charging station's power cord is plugged into a live wall outlet. Test the wall outlet with another device. Try a different charging cable for your device.

Problem	Possible Cause	Solution
Drawers are stiff or difficult to open/close	Obstruction; Rollers need lubrication; Misalignment during assembly.	Check for items blocking the drawer path. Apply a silicone-based lubricant to the rollers. Review assembly steps for correct drawer runner installation.
Bed frame feels unstable	Loose hardware; Uneven floor.	Tighten all screws and bolts on the bed frame. Ensure the bed is on a level surface; use shims if necessary.

Specifications

- **Brand:** LUXOAK
- **Model Number:** BMB011+CNS004
- **Color:** Grey
- **Size:** King
- **Bed Frame Dimensions:** 86"L x 77.5"W x 39"H
- **Nightstand Dimensions:** 15.7"D x 17.7"W x 24"H
- **Item Weight:** Approximately 154 pounds (total for the set)
- **Material:** High-quality engineered wood and metal frame, PU headboard
- **Under-bed Clearance:** 11.8 inches
- **Headboard Charging:** 2 AC Outlets (110V/12A), 2 USB Ports (5V/3A), 6.5-foot power cord
- **Nightstand Charging:** 2 AC Outlets (125V/12A), 2 USB Ports (5V/2.1A), 4.9-foot power cord (per nightstand)
- **LED Features:** RGB lighting, 20 colors, 19 dynamic effects, 10-level adjustment speed, remote and app control.

Warranty Information

LUXOAK products are manufactured with quality and durability in mind. While specific warranty details are not provided in this manual, please refer to your purchase documentation or contact LUXOAK customer support for information regarding warranty coverage and terms.

Customer Support

If you encounter any issues during assembly, operation, or maintenance that are not covered in this manual, or if you require replacement parts, please contact LUXOAK customer support. Have your model number (BMB011+CNS004) and purchase information ready when contacting support.
For further assistance, please visit the LUXOAK store on Amazon or refer to the contact information provided with your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2DV9R1G

More documents and user manuals: **https://manuals.plus/**